

[Manuals.plus](#) /

› [Swiss Eagle](#) /

› Swiss Eagle SE 9005-11 Sea Ranger Chronograph Watch User Manual

Swiss Eagle SE 9005-11

Swiss Eagle SE 9005-11 Sea Ranger Chronograph Watch User Manual

MODEL: SE 9005-11



This image shows the Swiss Eagle SE 9005-11 Sea Ranger Chronograph Watch, featuring a black dial, silver-tone stainless steel case and bracelet, and chronograph sub-dials.

INTRODUCTION

Welcome to the user manual for your Swiss Eagle SE 9005-11 Sea Ranger Chronograph Watch. This timepiece combines precision Swiss quartz movement with robust design, featuring a chronograph function, unidirectional bezel, date window, and scratch-resistant sapphire crystal. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your watch to ensure its longevity and optimal performance.

GETTING STARTED (SETUP)

Setting the Time

1. Pull the crown out to the second click position.
2. Turn the crown to set the hour and minute hands to the desired time.
3. Push the crown back into the normal position.

Setting the Date

1. Pull the crown out to the first click position.
2. Turn the crown clockwise or counter-clockwise (depending on the movement) to set the date.
3. Push the crown back into the normal position. Avoid setting the date between 9 PM and 3 AM, as this may interfere with the automatic date change mechanism.

Adjusting the Bracelet

The stainless steel bracelet can be adjusted by adding or removing links to achieve a comfortable fit. It is recommended to have this procedure performed by a qualified watch technician to prevent damage to the bracelet or clasp.



This image displays the Swiss Eagle SE 9005-11 watch worn on a wrist, illustrating how the bracelet should fit.

Battery Information

Your watch is powered by a product-specific battery, which is included. The typical lifespan of a watch battery varies, but it is generally several years. When the battery needs replacement, it is advisable to have it done by a professional watchmaker to ensure proper sealing and maintain water resistance.

OPERATING YOUR WATCH

Using the Chronograph Function

The chronograph allows you to measure elapsed time independently of the main time display.

1. **Start:** Press the upper pusher (button A) to start the chronograph. The chronograph second hand will begin to move.
2. **Stop:** Press the upper pusher (button A) again to stop the chronograph. The elapsed time will be indicated by the chronograph hands.
3. **Reset:** After stopping, press the lower pusher (button B) to reset the chronograph hands to their zero positions.

Unidirectional Bezel

The bezel rotates in one direction only (counter-clockwise) to prevent accidental changes that would indicate a shorter elapsed time. It can be used to measure elapsed time from a specific point. Align the zero marker on the bezel with the minute hand at the start of an event. The minute hand will then point to the elapsed time on the bezel scale.



This close-up image highlights the watch dial, showing the chronograph sub-dials, pushers, crown, and the unidirectional bezel with its markings.

Water Resistance

Your Swiss Eagle SE 9005-11 watch is water resistant to 100 meters (330 feet). This rating makes it suitable for snorkeling, swimming, and general water activities. **It is not suitable for diving.**

- Ensure the crown is fully pushed in before any contact with water.
- Do not operate the crown or pushers while the watch is wet or submerged.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly with a soft cloth.

CARE AND MAINTENANCE

Cleaning Your Watch

Regular cleaning helps maintain the appearance and hygiene of your watch. Use a soft, damp cloth to wipe the case and bracelet. For stainless steel bracelets, a soft brush with mild soapy water can be used to clean between links, followed by a thorough rinse with fresh water and drying.

Sapphire Crystal Care

The sapphire crystal is highly scratch-resistant. However, it is not entirely scratch-proof and can be damaged by extreme impacts or contact with materials harder than sapphire. Avoid unnecessary impacts and clean the crystal with a soft, lint-free cloth.

Water Resistance Maintenance

The gaskets that ensure water resistance can degrade over time. It is recommended to have your watch's water resistance checked by a professional watchmaker every 2-3 years, especially if it is frequently exposed to water.

Battery Replacement

When the battery runs out, have it replaced promptly by a certified watch technician. This ensures the correct battery type is used and the watch's water resistance is maintained after the case back is opened and resealed.

TROUBLESHOOTING

Watch Not Running

If your watch stops running, the most common cause is a depleted battery. Refer to the "Battery Replacement" section. If the battery is new or recently replaced, ensure the crown is fully pushed in. If the issue persists, professional inspection may be required.

Date Not Changing

Ensure the time is set correctly, especially the AM/PM cycle, as the date typically changes around midnight. If the date is stuck, try manually advancing it using the crown in the first click position. If the problem continues, seek professional assistance.

Water Condensation Inside Crystal

If you notice condensation under the crystal, it indicates that water has entered the watch. This requires immediate attention from a professional watchmaker to prevent further damage to the movement. Do not attempt to dry it yourself.

SPECIFICATIONS

Feature	Detail
Model Number	SE 9005-11
Movement Type	Swiss Quartz Chronograph
Case Diameter	44 Millimetres

Band Material	Stainless Steel
Crystal Type	Sapphire
Water Resistance	100 Meters (330 feet)
Product Dimensions	8.99 x 10.01 x 10.01 cm
Item Weight	204 Grams
Batteries	1 Product Specific battery (included)



This diagram provides a visual guide to different watch case diameters, helping to contextualize the 44mm size of the SE 9005-11 model.

WARRANTY AND SUPPORT

Warranty Information

For warranty-related inquiries and service, please contact the seller of record from whom you purchased the watch. They will provide details regarding the specific warranty terms and conditions applicable to your purchase.

Customer Support

For any further questions or assistance not covered in this manual, please reach out to the customer support channels provided by your retailer or the official Swiss Eagle website for guidance.