

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ESPRIT](#) /

› [ESPRIT A.ES102841004 Men's Quartz Chronograph Watch Instruction Manual](#)

ESPRIT ES102841004

ESPRIT A.ES102841004 Quartz Chronograph Watch Instruction Manual

Model: ES102841004

1. INTRODUCTION

This manual provides detailed instructions for the proper use and care of your ESPRIT A.ES102841004 Quartz Chronograph Watch. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece. This watch combines precise quartz movement with chronograph and alarm functionalities, encased in a durable stainless steel body with a comfortable leather strap.

2. PRODUCT OVERVIEW

The ESPRIT A.ES102841004 is a men's quartz chronograph watch featuring a black dial, multiple sub-dials, and a black leather strap. It includes chronograph (stopwatch) and alarm functions, along with a date display.

2.1 Watch Components



This image displays the intricate details of the ESPRIT A.ES102841004 watch. The main dial is black with prominent white hour and minute hands, and white indices for hours. Three sub-dials are visible: one at 3 o'clock for 24-hour display, one at 6 o'clock for chronograph seconds, and one at 9 o'clock for chronograph minutes, highlighted in blue. A date window is positioned between 4 and 5 o'clock. The watch features a robust black case and two pushers on the right side, flanking the crown.

- **Crown (A):** Used for setting time and date.
- **Pusher (B):** Activates/stops the chronograph.
- **Pusher (C):** Resets the chronograph.
- **Main Dial:** Displays hours, minutes, and seconds.
- **Sub-dial (3 o'clock):** 24-hour indicator.
- **Sub-dial (6 o'clock):** Chronograph seconds.

- **Sub-dial (9 o'clock):** Chronograph minutes.
- **Date Window:** Displays the current date.
- **Leather Strap:** Secures the watch to the wrist.

3. SETUP AND INITIAL ADJUSTMENT

3.1 Setting the Time

1. Pull the crown (A) out to the second click position.
2. Turn the crown to set the hour and minute hands to the desired time. Ensure AM/PM is correctly set if your watch has a 24-hour indicator that synchronizes with the main time.
3. Push the crown back to the normal position.

3.2 Setting the Date

1. Pull the crown (A) out to the first click position.
2. Turn the crown clockwise or counter-clockwise (depending on the movement) to set the date. Avoid setting the date between 9 PM and 3 AM, as this may interfere with the automatic date change mechanism.
3. Push the crown back to the normal position.

3.3 Chronograph Hand Reset (Zero Position Adjustment)

If the chronograph hands (seconds and minutes) do not return to the zero position after resetting, they may need adjustment.

1. Pull the crown (A) out to the second click position.
2. Press pusher (B) to advance the chronograph second hand to the 12 o'clock position.
3. Press pusher (C) to advance the chronograph minute hand to the 12 o'clock position.
4. Once all chronograph hands are at the 12 o'clock position, push the crown back to the normal position.

4. OPERATING THE WATCH

4.1 Using the Chronograph (Stopwatch)

1. To **start** the chronograph, press pusher (B). The chronograph second hand (6 o'clock sub-dial) and minute hand (9 o'clock sub-dial) will begin to move.
2. To **stop** the chronograph, press pusher (B) again. The elapsed time will be indicated by the chronograph hands.
3. To **reset** the chronograph, press pusher (C). The chronograph hands will return to their zero positions.

4.2 Using the Alarm Function

Specific instructions for setting and activating the alarm function are typically detailed in the movement's specific module manual. Generally, the alarm is set using the crown in a specific position or a dedicated pusher, and its time is often indicated by a small hand on one of the sub-dials. Please refer to the detailed movement guide if available, or consult a professional watch technician for precise instructions.

4.3 Water Resistance

Your ESPRIT A.ES102841004 watch is rated for **10 BAR (100 meters/330 feet)** water resistance. This means it is suitable for swimming, snorkeling, and showering. However, it is *not* suitable for high-impact water sports or scuba diving. Do not operate the crown or pushers while the watch is wet or submerged, as

this can compromise the water resistance.

5. MAINTENANCE AND CARE

5.1 Cleaning

Wipe the watch case and crystal regularly with a soft, dry cloth to remove dust and smudges. For the leather strap, avoid excessive moisture and harsh cleaning agents. If the watch gets wet, dry it thoroughly with a soft cloth.

5.2 Battery Replacement

The watch is powered by a quartz battery. When the battery runs low, the second hand may start to move in two-second intervals (End-of-Life indicator). It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

5.3 Strap Care

The black leather strap is designed for comfort and style. To prolong its life, avoid prolonged exposure to direct sunlight, extreme temperatures, and excessive moisture. Clean with a damp cloth and mild soap if necessary, then allow to air dry completely.

6. TROUBLESHOOTING

- Watch not running:** Check if the crown is pushed in completely. If not, set the time and push the crown back in. If the watch still does not run, the battery may need replacement.
- Date not changing:** Ensure the time is set correctly, especially the AM/PM cycle. Avoid setting the date between 9 PM and 3 AM.
- Chronograph hands not resetting to zero:** Perform the chronograph hand reset procedure as described in section 3.3.
- Water inside the watch:** Immediately take the watch to a professional watch repair service. Do not attempt to open it yourself.

7. SPECIFICATIONS

Feature	Specification
Model Number	ES102841004
Movement	Quartz Chronograph
Case Material	Stainless Steel
Strap Material	Leather
Dial Color	Black
Water Resistance	10 BAR (100 meters / 330 feet)
Weight	105 grams




This image shows the ESPRIT A.ES102841004 watch on a human wrist, illustrating its proportions and how it appears when worn. The black leather strap with white stitching is visible, securing the watch comfortably. This view helps to visualize the watch's presence and style on the wearer.

8. WARRANTY AND SUPPORT

Your ESPRIT A.ES102841004 watch is covered by a manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details. For technical support, service, or warranty claims, please contact your authorized ESPRIT dealer or the official ESPRIT customer service department.


Related Documents - ES102841004

	<p><u>Esprit V1 Wall Mirror - Limited Edition</u></p> <p>Detailed information about the Esprit V1 wall mirror, featuring a resin frame, specific dimensions, and limited edition details. Part of the Edizione Limitata Collection.</p>
	<p><u>Esprit V2 Wall Mirror - Limited Edition by ARTEM</u></p> <p>Discover the Esprit V2 wall mirror, a limited edition piece from ARTEM. Crafted from hand-molded plaster and mirror, it measures 86x19.5x123 cm and is available as 150 numbered and signed units with a 7-week lead time.</p>
	<p><u>Thermorossi Esprit 490/540/600 Installations-, Betriebs- und Wartungsanleitung</u></p> <p>Umfassende Anleitung für die Installation, den Betrieb und die Wartung der Thermorossi Esprit Pelletöfen (Modelle 490, 540, 600). Enthält technische Spezifikationen, Sicherheitshinweise und Fehlerbehebung.</p>




[Thermorossi ESPRIT 490-540-600: Installation, Use, and Maintenance Guide](#)

This comprehensive guide provides essential information for the installation, operation, and maintenance of Thermorossi ESPRIT 490, 540, and 600 pellet inserts, ensuring safe and efficient use.



[Well FMTRANS-BT-ESPRIT-WL Bluetooth Hands-Free Car Kit Instruction Manual](#)

Read the Well FMTRANS-BT-ESPRIT-WL Bluetooth Hands-Free Car Kit instruction manual for setup, operation, features, and safety precautions. Learn how to stream music and make calls wirelessly.



[TRIANGLE ESPRIT Ez Owner's Manual & Warranty](#)

Comprehensive owner's manual and warranty information for the TRIANGLE ESPRIT Ez loudspeaker series, covering setup, connections, placement, and technical specifications.