

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bose](#) /

› [Bose FreeSpace 3 Surface Satellite Speakers User Manual](#)

Bose Freespace 3

Bose FreeSpace 3 Surface Satellite Speakers User Manual

Model: FreeSpace 3

INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your Bose FreeSpace 3 Surface Satellite Speakers. Please read this manual thoroughly before using the product to ensure optimal performance and safety.



Image: Bose FreeSpace 3 Surface Satellite Speakers. These compact speakers are designed for surface mounting and deliver clear audio.

PACKAGE CONTENTS

Verify that all components are present in the package:

- 2 x FreeSpace 3 Satellite Speakers
- Mounting brackets (if included with your specific purchase)
- Instruction Manual (this document)

SETUP AND INSTALLATION

Proper setup is crucial for optimal sound performance. These speakers are designed for surface mounting.

1. Choosing a Location

- Select a location that provides clear sound dispersion and is structurally sound to support the speaker's weight.

- Avoid placing speakers near heat sources or in direct sunlight.
- Ensure adequate space for wiring and ventilation.

2. Mounting the Speakers

1. Attach the mounting brackets to the desired surface using appropriate hardware (not included). Ensure the brackets are securely fastened.
2. Carefully attach the FreeSpace 3 satellite speakers to the installed mounting brackets.
3. Adjust the speaker angle for optimal sound direction.

3. Wiring Connections

Connect the speakers to a compatible amplifier or audio system. Ensure the system is powered off before making any connections.

- Use high-quality speaker wire.
- Connect the positive (+) terminal of the speaker to the positive (+) terminal of the amplifier.
- Connect the negative (-) terminal of the speaker to the negative (-) terminal of the amplifier.
- Ensure all connections are secure to prevent short circuits.

OPERATING INSTRUCTIONS

Once installed and connected, your Bose FreeSpace 3 speakers are ready for operation.

1. **Power On:** Turn on your amplifier or audio system.
2. **Volume Control:** Start with the volume at a low level and gradually increase it to your desired listening level.
3. **Audio Source:** Select your preferred audio source (e.g., laptop, television, music player).
4. **Voice Control (if applicable):** If your system supports voice control and is configured, you may use voice commands to manage playback. Refer to your amplifier's manual for specific voice control setup.

Note: These speakers are designed to reproduce mid and upper range audio frequencies. For full-range sound, they are typically paired with a subwoofer (sold separately).

MAINTENANCE

Regular maintenance ensures the longevity and performance of your speakers.

- **Cleaning:** Use a soft, dry cloth to wipe the speaker surfaces. Do not use abrasive cleaners or solvents.
- **Dust Removal:** Gently remove dust from the speaker grilles using a soft brush or vacuum cleaner with a brush attachment.
- **Environmental Conditions:** Keep speakers away from excessive moisture, extreme temperatures, and direct sunlight.
- **Cable Inspection:** Periodically check speaker cables for any signs of wear or damage. Replace damaged cables immediately.

TROUBLESHOOTING

If you encounter issues with your FreeSpace 3 speakers, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No Sound	Power not on Incorrect wiring Source not selected Volume too low	Ensure amplifier is powered on. Check all speaker wire connections (positive to positive, negative to negative). Verify the correct audio source is selected on your amplifier. Increase volume gradually.
Distorted Sound	Volume too high Damaged speaker wire Incorrect impedance match	Reduce volume. Inspect and replace damaged speaker wires. Consult your amplifier's manual for compatible impedance.
One Speaker Not Working	Loose connection Faulty speaker wire	Check connections for the non-working speaker. Swap speaker wires with a working speaker to isolate the issue.

If the problem persists after trying these solutions, contact Bose customer support or a qualified service technician.

SPECIFICATIONS

Key technical specifications for the Bose FreeSpace 3 Surface Satellite Speakers:

- **Brand:** Bose
- **Model Name:** FreeSpace 3
- **Speaker Type:** Satellite
- **Color:** White
- **Included Components:** 2 x Satellite Speakers
- **Mounting Type:** Surface Mount
- **Speaker Maximum Output Power:** 100 Watts
- **Audio Output Mode:** Stereo, Mono
- **Compatible Devices:** Laptop, Television (as part of an audio system)
- **Connectivity Technology:** Wi-Fi (Note: This refers to system compatibility, speakers are wired.)
- **Control Method:** Voice (Requires compatible audio system)
- **Water Resistance:** Not Water Resistant
- **Audio Driver Type:** Dynamic Driver
- **Item Weight:** 3.54 pounds (per pair)
- **Package Dimensions:** 11.4 x 5.1 x 3.7 inches
- **UPC:** 017817391535

Note: Specifications are subject to change without notice. For the most current information, please refer to the official Bose website.

WARRANTY INFORMATION

Bose FreeSpace 3 Surface Satellite Speakers come with a Limited Warranty. The duration and terms of the warranty may vary by region and purchase date. Please retain your proof of purchase for warranty claims.

For detailed warranty terms and conditions, please visit the official Bose website or contact Bose customer support. The warranty typically covers manufacturing defects but does not cover damage caused by misuse, accidents, unauthorized

modifications, or normal wear and tear.

CUSTOMER SUPPORT

For technical assistance, product inquiries, or warranty service, please contact Bose customer support:

- **Online Support:** Visit the official [Bose Support Website](#) for FAQs, troubleshooting guides, and contact information.
- **Telephone Support:** Refer to the Bose website for regional contact numbers.

When contacting support, please have your product model (FreeSpace 3) and serial number ready.

© 2024 Bose Corporation. All rights reserved. Bose and FreeSpace are trademarks of Bose Corporation.