

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Accutime](#) /

› U.S. Polo Assn. Men's Sport Watch User Manual

Accutime US9061

U.S. Polo Assn. Men's Sport Watch User Manual

Model: US9061

PRODUCT OVERVIEW

The U.S. Polo Assn. Men's Sport Watch, Model US9061, is a versatile timepiece featuring both analog and digital displays. It boasts a brushed silver-tone case and buckle, complemented by a black finish rubber bezel and a silver dial. The watch includes silver-tone luminous hour and minute hands, a distinct red second timer hand, and silver-tone white numeral and line hour markers. Black 24-hour markers are present on the outer dial, alongside white minute markers on the bezel. Designed for an active lifestyle, it includes functions such as a timer, alarm, day and date display, and a backlight for visibility in low light conditions. Its robust 45mm case with a mineral crystal and black silicone strap ensure durability and comfort.



Figure 1: Front view of the U.S. Polo Assn. Men's Sport Watch, highlighting its analog and digital displays.

Video 1: An overview of the U.S. Polo Assn. Sport Men's US9061 Watch, showcasing its design and features.

KEY FEATURES

- Sport-inspired design with an extra-wide black silicone band featuring silver-tone stripes and texturing.
- Multi-function dial with a silver finish, including a 24-hour dial ring, numbered bezel, and luminous indices.
- Silver-tone luminous hour and minute hands, and a prominent red second timer hand.
- Digital multi-function sub-dials for enhanced utility.
- Integrated daily alarm, timer, and backlight functions.
- Displays day and date.
- Durable 45mm brushed silver-tone case with a mineral crystal dial window.
- Reliable Japanese quartz movement with both analog and digital displays.
- Secure buckle closure on the silicone strap.

SETUP AND INITIAL CONFIGURATION

Setting Analog Time

1. Pull out the crown (the knob on the right side of the watch case) to the first position.
2. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. Once the analog time is set, push the crown back in to its original position to start the watch.

Setting Digital Time and Date

The digital display features multiple modes, typically accessed via the "MODE" button (bottom left). The buttons are generally labeled as follows:

- **LIGHT:** Top left button, activates backlight.
- **ST/STOP:** Top right button, typically for stopwatch start/stop.
- **MODE:** Bottom left button, cycles through digital modes (Time, Alarm, Timer, Stopwatch).
- **RESET:** Bottom right button, typically for resetting stopwatch or adjusting settings.

1. Press the **MODE** button repeatedly until the digital time display flashes or enters setting mode.
2. Use the **RESET** button to select the digit or setting you wish to adjust (e.g., hours, minutes, year, month, day).
3. Use the **ST/STOP** button to increase the value of the selected digit or setting.
4. Continue pressing **RESET** and **ST/STOP** until all desired settings (time, date, day of week) are correct.
5. Press the **MODE** button again to exit the setting mode and save changes.

OPERATING INSTRUCTIONS

Using the Alarm Function

1. Press the **MODE** button until the alarm time is displayed.
2. Press the **RESET** button to select the hour or minute digit to set.
3. Use the **ST/STOP** button to adjust the alarm hour and minute.
4. Press **MODE** to confirm and exit.
5. To activate/deactivate the alarm, typically press **ST/STOP** while in alarm display mode. A small alarm icon will appear/disappear.

Using the Stopwatch/Timer

1. Press the **MODE** button until the stopwatch or timer mode is displayed (usually indicated by "00:00:00").
2. Press **ST/STOP** to start the stopwatch/timer.
3. Press **ST/STOP** again to pause.
4. Press **RESET** to clear the stopwatch/timer to zero.

Activating the Backlight

To illuminate the digital display in low light conditions, press the **LIGHT** button (top left). The backlight will typically stay on for a few seconds.

CARE AND MAINTENANCE

To ensure the longevity and optimal performance of your U.S. Polo Assn. Sport Watch, follow these care guidelines:

- **Cleaning:** Wipe the watch case and strap regularly with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.
- **Water Resistance:** This watch is designed with water resistance up to 90 feet (approximately 30 meters). This rating is generally suitable for splashes, rain, and brief immersion in water, such as showering or swimming in a pool. *It is not suitable for diving or prolonged underwater activities.* Ensure the crown is fully pushed in before any water exposure.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures, both hot and cold, as this can affect battery life and movement accuracy.
- **Impact:** Protect the watch from strong impacts or shocks, which can damage the internal components or the glass dial window.
- **Battery Replacement:** When the digital display dims or the watch stops functioning, it may require battery replacement. This model uses 2 Lithium Metal batteries. It is recommended to have batteries replaced by a qualified watch technician to ensure proper sealing and water resistance.



Figure 2: The watch worn on a wrist, illustrating its size and fit.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Analog hands not moving.	Battery depleted or crown is pulled out.	Push the crown fully in. If still not working, replace battery.
Digital display is blank or dim.	Battery depleted.	Replace battery.

Problem	Possible Cause	Solution
Time/Date is incorrect.	Not set correctly or accidentally reset.	Refer to "Setup and Initial Configuration" section to reset time and date.
Alarm does not sound.	Alarm is not activated or set incorrectly.	Ensure alarm is activated (check for alarm icon) and set to the correct time.

SPECIFICATIONS

Model Number	US9061
Case Diameter	45mm
Case Thickness	16mm
Strap Width	31mm
Strap Material	Silicone (Rubber)
Case Material	Metal (Brushed Silver Tone)
Movement	Japanese Quartz
Display Type	Analog-Digital
Water Resistance	90 feet (30 meters)
Batteries	2 Lithium Metal batteries (included)
Product Dimensions	3.94 x 2.76 x 3.15 inches
Item Weight	9.1 ounces
Country of Origin	China





Figure 3: The U.S. Polo Assn. Men's Sport Watch presented in its original box.

WARRANTY AND SUPPORT

This U.S. Polo Assn. Sport Watch is manufactured by Accutime. For specific warranty details and support inquiries, please refer to the warranty card included with your purchase or visit the official Accutime website. Keep your proof of purchase for any warranty claims.

For further assistance or technical support, please contact Accutime customer service. Contact information can typically be found on the product packaging or their official website.

