



[Manuals.plus](#) /

› [Any Command](#) /

› Universal AC Remote Control User Manual

Any Command ACR-10

Any Command Universal AC Remote Control

Model: ACR-10 User Manual

1. INTRODUCTION

The Any Command ACR-10 is a universal remote control designed to operate a wide range of electronic window air conditioners from over 60 different brands. This lightweight and portable remote offers multiple modes and a magnetic back for convenient storage. This manual provides detailed instructions for setting up, operating, and maintaining your universal AC remote control.




Image: Front view of the Any Command ACR-10 Universal AC Remote Control.

2. KEY FEATURES

- **Universal Compatibility:** Compatible with most electronic window air conditioners, supporting over 60 brands.
- **Magnetic Backing:** Features a magnetic back for easy attachment to metal surfaces, preventing misplacement.
- **Simple Programming:** Easy-to-read buttons and straightforward programming for quick setup.
- **Multiple Modes:** Offers various operational modes including Fan, Timer, Auto, Sleep, and Energy Saver.
- **Adjustable Fan Speeds:** Control fan speed with Slow, Medium, and Fast options.
- **Compact and Lightweight:** Ergonomically designed for comfortable handling and portability.

Universal Remote

Pairs with over 60 different brands



x60

COMPATIBLE WITH:



AUX



Midea



MAYTAG

Rosewill

Image: Remote shown with text indicating compatibility with over 60 brands.

Magnetic Backing

Avoid misplacing the remote



Image: Remote demonstrating its magnetic backing on a refrigerator.

Multiple Modes

Fan, Auto, Speed Options & Timer



Image: Remote highlighting various operational modes.

Lightweight & Compact

4.92" x 2.44" x 0.63"




Image: Diagram showing the compact dimensions of the remote (4.92" x 2.44" x 0.63").

3. SETUP

3.1 Battery Installation

The remote requires one CR2032 battery (included). To install or replace the battery:

1. Locate the battery compartment on the back of the remote.
2. Open the battery cover by sliding or gently prying it open.
3. Insert the CR2032 battery with the positive (+) side facing up.
4. Close the battery cover securely.

3.2 Programming the Remote

The ACR-10 can be programmed using a direct code entry or an automatic search method. Refer to the included code list for your specific AC brand.

Method 1: Direct Code Entry

1. Turn on your air conditioner manually.
2. Press and hold the **SETUP** button on the remote until the red indicator light stays solid.
3. Enter the 4-digit code for your AC brand using the number buttons (0-9).
4. Point the remote at the AC unit and press the **POWER** button. If the AC turns off, the code is correct.
5. If the AC does not respond, try the next code listed for your brand.

Method 2: Automatic Search

1. Turn on your air conditioner manually.
2. Press and hold the **SETUP** button until the red indicator light starts flashing. Release the button.
3. The remote will begin searching for the correct code, sending power signals every few seconds.
4. When your AC unit turns off, immediately press any button (e.g., **POWER**) to stop the search and save the code.
5. Test other functions (e.g., temperature, fan speed) to ensure full compatibility.

Easy to Use

Setup is a breeze



Image: Hands demonstrating the ease of setting up the remote.

4. OPERATING INSTRUCTIONS

Once programmed, your Any Command remote provides full control over your air conditioner's functions.

4.1 Button Functions Overview

Button	Function
POWER	Turns the AC unit On or Off.
TEMP/TIME ▲ / ▼	Adjusts temperature settings or timer duration.
MODE (1)	Cycles through operating modes (e.g., Cool, Dry, Fan, Auto).
FAN (2)	Activates fan-only mode.
AUTO (3)	Sets the AC to automatically adjust settings based on room temperature.
SLOW (4)	Sets fan speed to slow.
MED (5)	Sets fan speed to medium.
FAST (6)	Sets fan speed to fast.
SLEEP (7)	Activates sleep mode for quiet, energy-efficient operation.
TIMER (8)	Sets a timer for the AC unit to turn On or Off automatically.
SAVER (9)	Activates energy saver mode.
CANCEL (0)	Cancels current timer or other settings.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Cleaning:** Wipe the remote with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace the CR2032 battery when the remote's response becomes sluggish or the indicator light does not illuminate. Ensure correct polarity.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Avoid Drops:** Protect the remote from physical impact, as this can damage internal components.

6. TROUBLESHOOTING

If you encounter issues with your remote, try the following solutions:

Problem	Possible Cause / Solution
Remote not responding to AC unit.	<ul style="list-style-type: none">◦ Ensure line of sight between remote and AC unit.◦ Check battery orientation and charge. Replace if necessary.◦ Re-program the remote using the correct code for your AC brand.◦ Try the automatic search method if direct code entry fails.

Problem	Possible Cause / Solution
Some functions not working correctly.	<ul style="list-style-type: none"> ◦ The programmed code might not be fully compatible. Try other codes for your brand. ◦ Ensure the AC unit supports the specific function (e.g., Sleep mode, Energy Saver).
Red indicator light not illuminating.	<ul style="list-style-type: none"> ◦ Battery is dead or incorrectly installed. Replace battery.

7. SPECIFICATIONS

Feature	Detail
Model Number	ACR-10
Product Dimensions	4.92 x 2.44 x 0.63 inches
Item Weight	1.92 ounces
Battery Type	1 x CR2032 (Lithium Coin Cell)
Compatible Devices	Most electronic window air conditioners (over 60 brands)
Special Features	Magnetic backing, Multiple modes (Fan, Timer, Auto, Sleep, Saver)

8. WARRANTY AND SUPPORT

The Any Command ACR-10 Universal AC Remote Control comes with a **1-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or warranty inquiries, please contact Any Command customer service through the retailer's platform or visit the official Any Command website for contact information.

Note: This remote works on most brands available today. It is not compatible with portable or mini split units.