

[manuals.plus](#) /

› [Lite-On](#) /

› [Lite-On DD-A100GX DVD Player/Recorder User Manual](#)

## Lite-On DD-A100GX

# Lite-On DD-A100GX DVD Player/Recorder User Manual

Model: DD-A100GX | Brand: Lite-On

## 1. INTRODUCTION

This manual provides essential instructions for the proper setup, operation, and maintenance of your Lite-On DD-A100GX DVD Player/Recorder. The DD-A100GX is designed to play various disc formats and record content onto DVD+R/RW discs, featuring DivX certified playback and a DV-Link input for digital camcorder connection.

## 2. SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following precautions:

- **Power Source:** Connect the unit only to the specified power supply.
- **Ventilation:** Ensure adequate ventilation. Do not block ventilation openings.
- **Liquids:** Do not expose the unit to rain or moisture. Avoid placing objects filled with liquids on the unit.
- **Cleaning:** Disconnect the power cord before cleaning. Use a soft, dry cloth.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.

## 3. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Lite-On DD-A100GX DVD Player/Recorder Unit
- Remote Control
- RCA Audio/Video Cables
- Blank DVD+RW Disc (4.7GB)
- Instruction Manual



Image 1: Contents of the Lite-On DD-A100GX package, including the silver DVD player/recorder unit, its remote control, RCA cables, a blank DVD+RW disc, and the printed instruction manual.

## 4. SETUP

---

### 4.1 Connecting to a Television

1. Ensure both the DVD player/recorder and your television are powered off.
2. Connect one end of the RCA audio/video cables (red for right audio, white for left audio, yellow for video) to the corresponding output jacks on the rear of the DD-A100GX.
3. Connect the other end of the RCA cables to the corresponding input jacks on your television. Note the input number (e.g., Video 1, AV In) for later selection on your TV.

### 4.2 Power Connection

1. Plug the power cord into the AC IN socket on the rear of the DD-A100GX.
2. Plug the other end of the power cord into a standard AC wall outlet.

### 4.3 Initial Power-On and Setup

1. Power on your television and select the correct video input source (e.g., AV1, Video 1) that corresponds to where you connected the DVD player/recorder.
2. Press the Power button on the front panel of the DD-A100GX or on the remote control.
3. Follow the on-screen instructions provided by the "Easy Guider" menu to complete initial setup, including language selection and aspect ratio.

## 5. OPERATING INSTRUCTIONS

---

## 5.1 DVD Playback

1. Press the OPEN/CLOSE button on the front panel or remote to open the disc tray.
2. Place a DVD disc onto the tray with the label side facing up.
3. Press the OPEN/CLOSE button again to close the disc tray.
4. Playback will typically begin automatically. If not, press the PLAY button on the remote control.

## 5.2 DVD Recording (DVD+R/RW)

The DD-A100GX supports recording to DVD+R and DVD+RW discs.

1. Insert a blank DVD+R or DVD+RW disc into the disc tray.
2. Select the input source you wish to record (e.g., TV tuner, external AV input).
3. Press the RECORD button on the remote control to begin recording. Press STOP to end recording.
4. For timed recordings, utilize the VCR Plus+ timer-recording programming guide. Refer to the on-screen menu for detailed VCR Plus+ setup.

## 5.3 DivX Playback

This unit is DivX Certified, allowing playback of DivX encoded video files. Insert a disc containing DivX files, and the player will automatically detect and play them.

## 5.4 DV-Link Input

The "DV-Link" input allows for direct connection of a digital camcorder. Connect your camcorder to the DV-Link port on the front or rear of the unit using a compatible DV cable. This enables easy transfer and recording of digital video content to DVD.

## 5.5 On-Screen Operating Menu

Navigate the unit's settings and functions using the remote control and the on-screen display. Press the MENU button on the remote to access the main menu, then use the arrow keys and ENTER button to make selections.

# 6. MAINTENANCE

---

## 6.1 Cleaning the Unit

Wipe the exterior of the unit with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents. For stubborn stains, a lightly dampened cloth may be used, followed by a dry cloth.

## 6.2 Disc Handling and Cleaning

- Always hold discs by their edges to avoid fingerprints.
- Store discs in their cases to protect them from dust and scratches.
- To clean a disc, wipe gently from the center outwards with a soft, lint-free cloth. Do not use solvents or abrasive cleaners.

# 7. TROUBLESHOOTING

---

If you encounter issues with your DD-A100GX, refer to the following common problems and solutions:

- **No Power:** Ensure the power cord is securely plugged into both the unit and the wall outlet. Try a different outlet.

- **No Picture:** Verify that the RCA video cable (yellow) is correctly connected to both the DVD player/recorder and the TV. Ensure your TV is set to the correct input source.
- **No Sound:** Check that the RCA audio cables (red and white) are correctly connected. Adjust the volume on both the TV and the DVD player/recorder.
- **Disc Not Playing/Recording:** Ensure the disc is clean and free of scratches. Verify the disc is inserted correctly (label side up). For recording, ensure you are using a compatible DVD+R or DVD+RW disc and that it is not full or finalized.
- **Remote Control Not Working:** Check the batteries and replace them if necessary. Ensure there are no obstructions between the remote and the unit's IR sensor.

If the problem persists, consult the Lite-On customer support resources.


## 8. SPECIFICATIONS

Feature	Specification
Product Dimensions	11 x 9.8 x 2 inches
Item Weight	5.1 pounds
Item Model Number	DD-A100GX
Brand	Lite-On
Media Type	DVD
Special Feature	Compact
Connector Type	RCA
Connectivity Technology	RCA
Color	Silver
Audio Output Mode	Stereo
Input Video Compatibility	NTSC
Number of Channels	2

## 9. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the official Lite-On website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.

### Related Documents - DD-A100GX

	<p><a href="#"><u>Lite-On LVW-5005 LVW-5001 DVD Recorder User Manual</u></a></p> <p>User manual for the Lite-On LVW-5005 and LVW-5001 DVD Recorder, covering setup, recording, playback, editing, and troubleshooting.</p>
	<p><a href="#"><u>LiteOn LVW-5006 &amp; LVW-5002 DVD Recorder User Manual</u></a></p> <p>Comprehensive user manual for the LiteOn LVW-5006 and LVW-5002 DVD recorders, covering setup, recording, playback, editing, and troubleshooting to help users maximize their device's functionality.</p>
	<p><a href="#"><u>LITE-ON WPX9926 Quick Start Guide</u></a></p> <p>Quick start guide for the LITE-ON WPX9926 wireless access point, including setup instructions, troubleshooting, and FCC compliance information.</p>
	<p><a href="#"><u>Lite-On LTST-C194KGKT SMD LED Product Data Sheet</u></a></p> <p>This document provides detailed specifications for the Lite-On LTST-C194KGKT SMD LED, including features, dimensions, electrical and optical characteristics, suggested soldering profiles, and reliability test data.</p>
	<p><a href="#"><u>FCC SAR Exclusion Report: LITE-ON SA8990 Wireless Controller</u></a></p> <p>Official FCC SAR Exclusion Report for the LITE-ON SA8990 Wireless Controller, detailing compliance with radiofrequency exposure standards by BTL Inc.</p>
	<p><a href="#"><u>Lite-On H4IKB8190 H4IMS8190 Wireless Mouse FCC Declaration Letter</u></a></p> <p>Official declaration letter from Lite-On Technology Corporation regarding label placement requirements for the H4IKB8190 and H4IMS8190 wireless mouse models, submitted to the Federal Communications Commission (FCC).</p>

