Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HQRP 884667406251248

HQRP Universal Remote Control Instruction Manual

Model: 884667406251248

Compatible with various Haier Air Conditioner models

Introduction

This HQRP Universal Remote Control is designed to operate various Haier air conditioner models. It features a large LCD display for easy operation, a built-in clock, and timing ON/OFF functions. The remote includes both automatic code searching and manual code input options for compatibility with your specific air conditioner unit. It also offers the flexibility to display temperature in either Fahrenheit or Celsius.

Important Note: This remote control is not compatible with portable and window air conditioners.



Front view of the HQRP Universal Remote Control, showing the LCD screen and various control buttons.

Setup

1. Battery Installation

1. Open the battery compartment cover located on the back of the remote control.
2. Insert two (2) AAA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
3. Close the battery compartment cover securely.



The remote requires two AAA batteries for operation.

2. Programming the Remote Control

The remote can be programmed using either an automatic code search or manual code input method.

Automatic Code Search

1. Ensure your air conditioner unit is powered on.
2. Point the remote control directly at the air conditioner.
3. Press and hold the **SET** button for approximately 3 seconds until the code on the remote's display starts to flash.
4. Repeatedly press the **TEMP UP** or **TEMP DOWN** buttons. The remote will cycle through codes. Stop when your air conditioner responds (e.g., turns on, changes mode, or makes a sound).
5. Once the air conditioner responds, press the **OK** button to confirm the code. The code on the display will stop flashing.
6. Test the remote's basic functions (ON/OFF, Mode, Temperature) to ensure proper operation. If not, repeat steps 3-5.

Manual Code Input

Refer to the code list provided with your remote (if available) or the instructions on the back of the remote for specific codes for Haier air conditioners.

1. Ensure your air conditioner unit is powered on.
2. Identify the specific code for your Haier air conditioner model from the code table.
3. Press and hold the **SET** button for approximately 3 seconds until the code on the remote's display starts to flash.
4. Use the **TEMP UP** or **TEMP DOWN** buttons to manually input the desired code.
5. Once the correct code is displayed, press the **OK** button to confirm. The code on the display will stop flashing.
6. Test the remote's functions. If the air conditioner does not respond correctly, repeat steps 3-5 with a different code from the list for your brand.





Instructions for manual code input are located on the back of the remote control.

Operating Instructions

Once programmed, your remote control provides access to various air conditioner functions:

- **ON/OFF Button:** Powers the air conditioner on or off.
- **MODE Button:** Cycles through operating modes such as Cool, Heat, Fan, Dry, and Auto.
- **TEMP Buttons (Up/Down):** Adjusts the desired temperature setting.
- **WIND Button:** Controls the fan speed.
- **M.SWING / A.SWING Buttons:** Controls the manual or automatic swing function of the air conditioner's louvers.
- **LIGHT Button:** Activates or deactivates the display light on the remote.
- **CLOCK Button:** Used to set the current time on the remote's display.
- **TIME ON / TIME OFF Buttons:** Sets scheduled times for the air conditioner to turn on or off automatically.
- **F.Cool / F.Heat Buttons:** These buttons may provide quick access to cooling or heating modes, or adjust specific temperature settings.
- **Temperature Display Option:** The remote supports displaying temperature in either Fahrenheit or Celsius. Consult the remote's display or specific button combinations for switching between units.



The remote control in use, demonstrating its function with an air conditioner unit.

Maintenance

Battery Replacement

Replace the two AAA batteries when the remote's display becomes dim, or if the remote becomes unresponsive to button presses. Always replace both batteries at the same time with new ones.

Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Avoid using liquid cleaners, aerosols, or abrasive materials, as these can damage the remote's surface or internal components.

Troubleshooting

- **Remote not responding:**

- Check if the batteries are inserted correctly and have sufficient power. Replace if necessary.
- Ensure there is a clear line of sight between the remote control and the air conditioner's receiver. Remove any obstructions.
- Re-program the remote control using either the automatic or manual code input method.

- **Display is dim or blank:**
  - Replace the batteries with new AAA batteries.

Specifications

Brand	HQRP
Model Number	884667406251248
UPC	884667929856
Max Number of Supported Devices	1
Compatible Devices	Air Conditioner
Connectivity Technology	Infrared
Controller Type	Button Control
Battery Type	AAA

Warranty

This HQRP Universal Remote Control comes with a 100 Days Warranty from the date of purchase. Please retain your proof of purchase for warranty claims.

Support

For further assistance, technical support, or inquiries regarding your HQRP Universal Remote Control, please contact HQRP customer service through their official channels or the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B008ETB2OM

More documents and user manuals: **https://manuals.plus/**