Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cambro 792619

Cambro DC5110 Deli Crock User Manual

Model: DC5110 / 792619

Product Overview

The Cambro DC5110 Deli Crock is a rectangular food storage and serving container designed for efficiency and durability in various settings. Its 2.2 quart capacity makes it suitable for a range of food items, from deli salads to condiments. The distinctive scalloped pattern adds a professional touch to food presentation. This product is made from a durable material, as specified.



This image displays the Cambro DC5110 Deli Crock, a rectangular food storage container in black. It features distinctive scalloped edges along the top rim, designed for both aesthetic appeal and practical use in deli or food service settings.

Setup and First Use

Before initial use, it is important to properly clean your Cambro DC5110 Deli Crock to ensure hygiene and product

longevity.

1. **Unpack:** Carefully remove the deli crock from its packaging. Inspect for any signs of damage during transit.
2. **Initial Cleaning:** Wash the deli crock thoroughly with warm, soapy water. Rinse completely to remove all soap residue.
3. **Drying:** Allow the deli crock to air dry completely or dry with a clean cloth before first use or storage.

Operating Instructions

The Cambro DC5110 Deli Crock is designed for versatile use in food service and storage.

- **Food Storage:** Use the crock to store various food items such as salads, fruits, vegetables, or condiments. Its rectangular shape allows for efficient use of space in refrigerators or display cases.
- **Serving:** The scalloped design makes it suitable for direct presentation on buffets, salad bars, or deli counters.
- **Temperature Use:** The product is listed as oven safe. If using in an oven, ensure the temperature does not exceed the material's heat tolerance and always use appropriate safety measures. It is primarily designed for cold or ambient food storage and serving.

Maintenance and Care

Proper care will extend the life and maintain the appearance of your deli crock.

- **Cleaning:** The manufacturer recommends *Hand Wash Only* for product care. While it is also listed as dishwasher safe, hand washing may help preserve the finish and integrity over time. Use a soft sponge or cloth and mild detergent. Avoid abrasive cleaners or scouring pads that could scratch the surface.
- **Stain Prevention:** To minimize staining, especially from highly pigmented foods, rinse the crock immediately after use.
- **Storage:** Store the deli crock in a clean, dry place when not in use. Stacking multiple crocks is possible for space efficiency.

Troubleshooting

This section addresses common concerns you might encounter with your deli crock.

- **Staining:** If the crock develops stains from food, try a solution of baking soda and water, or a diluted bleach solution for stubborn stains. Always rinse thoroughly afterward.
- **Odor Retention:** To remove lingering odors, wash thoroughly and then air out the crock in a well-ventilated area. A mixture of vinegar and water can also help neutralize odors.
- **Warping/Deformation:** Avoid exposing the deli crock to extreme heat sources beyond its intended use, as this can cause warping. While listed as oven safe, prolonged exposure to high temperatures not typical for food service plastic may affect its shape.

Specifications

Brand	Cambro
Model Number	DC5110 / 792619
Material	Stain

Shape	Rectangular
Capacity	2.2 Quarts (2.08 Liters)
Item Weight	0.01 Ounces (approx. 0.28 grams)
Product Care Instructions	Hand Wash Only (also listed as Dishwasher Safe)
With Lid	No
Is Oven Safe	Yes
UPC	099511344727
Package Dimensions	10.59 x 7.17 x 4.13 inches
Date First Available	December 19, 2012

Warranty and Support

For specific warranty information regarding your Cambro DC5110 Deli Crock, please refer to the documentation provided at the time of purchase or visit the official Cambro website. Warranty terms typically cover manufacturing defects.
For product support, technical assistance, or to inquire about replacement parts, please contact Cambro customer service through their official channels. You can often find contact information on the manufacturer's website or through your original retailer.
Note: This manual provides general guidance. Always refer to the latest information from the manufacturer for the most accurate and up-to-date details.

© 2024 Cambro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B008FQ10XM

More documents and user manuals: **https://manuals.plus/**