

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Instant Pot](#) /
- › [Instant Pot 6-Quart Tempered Glass Lid User Manual](#)

Instant Pot 213-0201-01

Instant Pot 6-Quart Tempered Glass Lid User Manual

1. PRODUCT OVERVIEW

The Instant Pot Tempered Glass Lid is designed for use with Instant Pot Multi-Use Programmable Pressure Cookers. This 9.1-inch, 6-quart lid features a steam vent, a durable stainless steel rim, and a stainless steel handle. It is specifically engineered to enhance the functionality of your Instant Pot during non-pressure cooking modes.



Image 1: Instant Pot 6-Quart Tempered Glass Lid, showcasing its clear glass, stainless steel handle, and rim.

2. KEY FEATURES

- **Tempered Glass Construction:** Provides clear visibility of food during cooking without lifting the lid.

- **Steam Vent:** Allows excess steam to escape, preventing condensation buildup and ensuring proper cooking conditions.
- **Stainless Steel Handle and Rim:** Offers durability, a secure grip, and complements the aesthetic of Instant Pot appliances.
- **Oven Safe:** Can be used with the stainless steel inner cooking pot in an oven up to 428°F (220°C).
- **Dishwasher Safe:** Facilitates easy cleaning and maintenance.
- **Compatibility:** Specifically designed for all 6-quart Instant Pot multi-cooker models.

3. SETUP AND COMPATIBILITY

The Instant Pot Tempered Glass Lid is designed for straightforward use. Simply place the lid onto the stainless steel inner pot of your 6-quart Instant Pot multi-cooker. Ensure the lid sits securely on the rim of the inner pot.




Image 2: The tempered glass lid placed on a 6-quart Instant Pot, demonstrating proper fit.

This lid is compatible with all 6-quart Instant Pot models. It is intended for use during cooking functions that do not require pressure, such as Sauté, Slow Cook, and Keep-Warm.

4. OPERATING INSTRUCTIONS

The tempered glass lid is an accessory that enhances the versatility of your Instant Pot for specific cooking methods:

- **Sauté Function:** Use the glass lid to cover the inner pot while sautéing to minimize splatter and retain heat, allowing you to observe the cooking process.
- **Slow Cook Function:** Replace the pressure lid with the glass lid when using the Slow Cook program. This allows for continuous monitoring and prevents pressure buildup, which is not required for slow cooking.
- **Keep-Warm Function:** After cooking, use the glass lid to cover the pot during the Keep-Warm cycle. This helps maintain food temperature and moisture while allowing easy access for serving.
- **Oven Use:** The lid can be used with the stainless steel inner pot in a conventional oven up to 428°F (220°C). Ensure the inner pot is removed from the Instant Pot base before placing it in the oven.

- **Serving:** The clear glass design makes this lid ideal for covering food when serving directly from the inner pot, keeping food warm and protected.

5. CARE AND MAINTENANCE

To ensure the longevity and hygiene of your Instant Pot Tempered Glass Lid, follow these cleaning instructions:

- **Dishwasher Safe:** The lid is safe for cleaning in a dishwasher. Place it on the top rack for best results.
- **Hand Washing:** For hand washing, use warm, soapy water and a non-abrasive sponge or cloth. Rinse thoroughly and dry completely before storage.
- **Avoid Abrasives:** Do not use harsh chemicals, abrasive cleaners, or scouring pads, as these can scratch the glass or damage the stainless steel finish.

6. TROUBLESHOOTING

The Instant Pot Tempered Glass Lid is a simple accessory with minimal troubleshooting requirements. Most issues relate to fit or cleaning.

- **Lid Does Not Fit:** Ensure you have the correct 6-quart size lid for your Instant Pot model. This lid is specifically designed for 6-quart Instant Pot inner pots.
- **Excessive Steam Escaping:** A small amount of steam escaping from the vent is normal. If steam is escaping excessively from around the rim, ensure the lid is seated correctly and the inner pot is not overfilled.
- **Stains or Residue:** For stubborn stains, a mixture of baking soda and water can be used as a gentle abrasive. For water spots, a vinegar solution can be effective.

7. PRODUCT SPECIFICATIONS

Model Number	213-0201-01
Size	6 Quart (9.1-inch diameter)
Material	Tempered Glass, Stainless Steel
Color	Clear Glass with Stainless Steel
Item Weight	12.8 ounces
Product Dimensions	9"L x 9"W
Dishwasher Safe	Yes
Oven Safe Temperature	Up to 428°F (220°C) with inner pot

8. WARRANTY INFORMATION AND SUPPORT

This Instant Pot Tempered Glass Lid comes with a **1-year manufacturer warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, product support, or further inquiries, please visit the official Instant Pot website or

contact their customer service department. Keep your proof of purchase for warranty validation.

For additional resources and frequently asked questions, please refer to the [Instant Pot Brand Store](#).