

Fun World 9898

Fun World 9898 50-Inch Posable Furry Spider Instruction Manual

Model: 9898

INTRODUCTION

Thank you for choosing the Fun World 50-Inch Posable Furry Spider. This decorative item is designed to add a unique touch to your themed displays. It features a soft, furry texture and adjustable legs, allowing for various poses and arrangements. This manual provides essential information for the proper handling, setup, and care of your spider.

SAFETY INFORMATION

- **Age Recommendation:** This product is not intended for children under the age of 15 years. The manufacturer recommends it for ages 18 years and up.
- **Indoor Use:** This item is primarily designed for indoor decorative use. Exposure to harsh outdoor weather conditions (rain, strong winds, prolonged sunlight) may cause damage or premature wear.
- **Material Components:** The spider contains metal components within its legs for posability. Handle with care to avoid pinching or injury.
- **Choking Hazard:** Small parts, if detached, could pose a choking hazard. Keep away from small children and pets.
- **Flammability:** Keep the product away from open flames, heat sources, and direct sunlight to prevent material degradation or fire hazards.

WHAT'S IN THE BOX

Upon opening the package, you will find:

- One (1) Faux Fur Spider (50-inch, assorted color)

SETUP

1. **Unpack:** Carefully remove the faux fur spider from its packaging.
2. **Inspect:** Check the spider for any signs of damage during transit.
3. **Initial Leg Adjustment:** The legs may be folded for packaging. Gently unfold and extend each leg to its desired position. The internal metal components allow for flexible posing.



This image shows the 50-inch posable furry spider. Its eight legs are covered in black faux fur and can be bent into various positions. The spider's body is also covered in black fur, and it features small red eyes. It is displayed on a light-colored wooden crate, with straw-like material scattered around, suggesting a decorative use.

OPERATING INSTRUCTIONS

Posing the Legs

The spider's legs contain bendable metal wires, allowing you to shape them as desired. To pose a leg:

1. Grasp the leg firmly but gently.
2. Slowly bend the leg at the desired points to create the pose. Avoid sharp, forceful bends to prevent damage to the internal wiring or outer fabric.
3. Repeat for all eight legs until the desired display is achieved.

The spider can be positioned on various surfaces, hung, or integrated into larger displays. Its lightweight design makes it versatile for different decorative applications.

MAINTENANCE

Cleaning

- **Dusting:** Gently dust the spider with a soft cloth or a feather duster.
- **Spot Cleaning:** For minor spots, use a damp cloth with a small amount of mild soap. Blot the area gently and allow it to air dry completely. Do not immerse the spider in water.
- **Avoid Harsh Chemicals:** Do not use bleach, abrasive cleaners, or solvents, as these can damage the faux fur and color.

Storage

When not in use, gently fold the legs inward to reduce the spider's footprint. Store in a cool, dry place away from direct sunlight and extreme temperatures to preserve its material and color. Keeping it in a protective bag or box can prevent dust accumulation and damage.

TROUBLESHOOTING

Legs Not Holding Position

- **Gentle Bending:** Ensure you are bending the legs gently and not over-stressing the internal wires. Repeated forceful bending in the same spot can weaken the wire.
- **Support:** For very extended or complex poses, consider providing additional support points or anchoring the spider to a surface to help maintain its shape.
- **Material Fatigue:** Over time, with extensive posing, the internal metal wires may experience fatigue. If a leg consistently fails to hold a pose, try to distribute the bends across different sections of the leg.

Faux Fur Shedding

- **Initial Shedding:** A small amount of shedding is normal, especially upon first unpacking. Gently shake the spider outdoors to remove loose fibers.
- **Gentle Handling:** Avoid excessive rubbing or pulling on the fur to minimize shedding.

SPECIFICATIONS

Product Dimensions	50 x 8 x 3 inches (approximate, when legs are extended)
Item Weight	3.52 ounces
Model Number	9898
Materials	Polyester, Plush, Metal Components
Colors	Assorted (Black, Brown, Grey/Silver, Purple - color cannot be specified)
Manufacturer Recommended Age	18 years and up

WARRANTY INFORMATION

Specific warranty details for this product are not provided. Please refer to the retailer's return policy or contact Fun World directly for information regarding product defects or issues.

SUPPORT

For further assistance or inquiries regarding your Fun World 50-Inch Posable Furry Spider, please contact the retailer from whom you purchased the product. You may also visit the official Fun World website for general product information.