

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SentrySafe](#) /

› [SentrySafe 1200 Fire-Resistant Money Safe with Key Lock \(0.18 cu. ft.\) Instruction Manual](#)

SentrySafe 1200

SentrySafe 1200 Fire-Resistant Money Safe with Key Lock (0.18 cu. ft.) Instruction Manual

Model: 1200 | Brand: SentrySafe

INTRODUCTION

This instruction manual provides essential information for the proper use and maintenance of your SentrySafe 1200 Fire-Resistant Money Safe. Designed to protect important documents, digital media, and other valuables from fire, this portable lock box offers a secure storage solution. Please read this manual thoroughly before operating your safe.



Figure 1: SentrySafe 1200 Fire-Resistant Money Safe with lid open, displaying various items for storage.

KEY FEATURES

- **Fire Resistance:** UL classified for fire protection, keeping contents safe for 1/2 hour up to 1550°F (843°C).
- **Digital Media Protection:** ETL verified for fire protection of digital media for 1/2 hour up to 1550°F (843°C).
- **Key Lock Security:** Features a flat key lock to prevent the lid from opening, ensuring privacy and security for your documents. Two keys are included.
- **Portable Design:** Equipped with convenient carrying grips for ease of transportation and portability.
- **Durable Construction:** Made from concrete with a resin body, providing robust protection.
- **Compact Size:** Ideal for storing important documents, passports, birth certificates, social security cards, and small valuables.



1/2 Hour Fire Protection



Privacy Key Lock



Carrying Handle

SETUP

1. **Unpacking:** Carefully remove the SentrySafe 1200 from its packaging. Inspect the safe for any signs of damage.
2. **Locate Keys:** The safe comes with two keys. These keys are typically attached to the handle or inside the safe. Keep one key in a secure, separate location as a backup.
3. **Initial Opening:** Insert one of the provided keys into the keyhole on the front of the safe. Turn the key clockwise to unlock the lid.
4. **Placement:** Choose a discreet and easily accessible location for your safe. While portable, consider a stable surface for storage.



2 Privacy Keys Included

Figure 2: Using the key to unlock the SentrySafe 1200.

OPERATING INSTRUCTIONS

- 1. To Open:** Insert the key into the lock and turn it clockwise. Lift the lid to open the safe.
- 2. To Close and Lock:** Ensure the contents are properly placed inside and the lid can close completely. Lower the lid firmly. Insert the key into the lock and turn it counter-clockwise to secure the safe. Remove the key.
- 3. Transporting:** Utilize the integrated carrying handle for easy and secure transport of the safe.



Portable & Discreet Fire Protection For Your Valuables

Figure 3: The SentrySafe 1200 is designed to be portable and discreet for fire protection.

MAINTENANCE

- **Cleaning:** Wipe the exterior of the safe with a soft, damp cloth. Avoid abrasive cleaners or solvents.
- **Key Care:** Keep keys clean and dry. Do not force the key if it feels stiff; apply a small amount of graphite lubricant if necessary.
- **Storage Environment:** Store the safe in a dry place to prevent moisture buildup, although the product is not water-resistant.

TROUBLESHOOTING

- **Key Lost:** If both keys are lost, contact SentrySafe customer support for assistance. Ensure you have your model and serial number ready.
- **Lid Not Closing Properly:** Check for any obstructions inside the safe that might be preventing the lid from closing completely. Ensure the locking mechanism is clear.

SPECIFICATIONS

Brand	SentrySafe
Model Number	1200
Exterior Dimensions (W x D x H)	14.3 in. x 11.2 in. x 6.1 in. (36.3 cm x 28.4 cm x 15.5 cm)
Interior Dimensions (W x D x H)	12 in. x 7.5 in. x 3.5 in. (30.5 cm x 19.1 cm x 8.9 cm)
Capacity	0.18 cubic feet (5.1 liters)
Item Weight	13.3 pounds (6.03 kg)
Lock Type	Key Lock
Material	Concrete with resin body
Fire Resistance	UL Classified for 1/2 hour up to 1550°F (843°C)
Digital Media Protection	ETL Verified for 1/2 hour up to 1550°F (843°C)
Water Resistance	Not Water Resistant
Included Components	Fire safe, two keys



ADVANCED PERIL PROTECTION

Fire Protection For 1/2 Hour At 1550°F



Interior Dimensions

3.5 in. 12 in. 7.5 in.
 8.9 cm 30 cm 19.1 cm

Weight Capacity

13.32 lbs. 0.18 cu. ft.
 6.04 kgs 5.1 liters



Figure 4: Visual representation of the SentrySafe 1200's exterior and interior dimensions.

PRODUCT VIDEOS

SentrySafe Fireproof Safe Box Overview

Your browser does not support the video tag.

Video 1: An overview of the SentrySafe Fireproof Safe Box, demonstrating its features and capacity for important items.

Experience with SentrySafe Fireproof Safe Box

Your browser does not support the video tag.




Video 2: A demonstration of the SentrySafe Fireproof Safe Box, highlighting its practical use for securing documents and valuables.

WARRANTY AND SUPPORT

The SentrySafe 1200 includes a **Limited Lifetime After-Fire Replacement Program**. In the event of a fire, SentrySafe will replace your fire-damaged unit. For details on this program or for any support inquiries, please refer to the contact information provided on the product packaging or visit the official SentrySafe website. For customer service, please contact SentrySafe directly. The product packaging often includes a QR code or a phone number for assistance.

© 2025 SentrySafe. All rights reserved.

Related Documents - 1200

	<p><u>SentrySafe Product FAQ and Support</u></p> <p>Frequently asked questions and support information for SentrySafe products, covering battery replacement, product testing, key and combination recovery, lock operation, warranties, and fire/water protection.</p>
	<p><u>SentrySafe Fire-Safe® Owner's Manual - Operation, Warranty, and Support</u></p> <p>Comprehensive owner's manual for the SentrySafe Fire-Safe® safe, covering operation of mechanical and electronic locks, bolting down, troubleshooting, warranty information, and customer service. Learn how to set up, use, and maintain your SentrySafe safe.</p>
	<p><u>SentrySafe Security Safe Owner's Manual: Operation, Installation, and Warranty</u></p> <p>Comprehensive owner's manual for SentrySafe security safes, detailing bolt-down installation, electronic and key lock operation, programming user codes, emergency access, replacement keys, and warranty terms. Includes instructions for various models.</p>

	<p>SentrySafe User Manual: Operating and Securing Your Safe</p> <p>Comprehensive guide for SentrySafe safes, covering operation of mechanical and electronic locks, light features, bolting down instructions, and troubleshooting. Learn how to secure your valuables with SentrySafe.</p>
	<p>SentrySafe Alarm Safe Owner's Manual: Setup, Operation, and Troubleshooting</p> <p>Comprehensive owner's manual for SentrySafe Alarm Safes. Learn how to set up, use, program codes, and troubleshoot your water and fire-resistant safe. Includes features, safety warnings, and customer care information.</p>
	<p>SentrySafe Security Safe Owner's Manual</p> <p>This owner's manual provides instructions for using and maintaining SentrySafe security safes, including key lock and digital combination models. It covers opening procedures, battery installation, programming user codes, troubleshooting common issues, and bolt-down instructions for enhanced security.</p>