

Schuller 14189

Schuller Paint Grid Instruction Manual

Model: 14189

1. PRODUCT OVERVIEW

The Schuller Paint Grid (Model 14189) is a practical accessory designed to assist in painting tasks. It is specifically sized at 10 x 17 cm and comes in a pack of 10 units. This grid is used to remove excess paint from brushes or rollers, ensuring an even application and preventing drips. Its durable plastic construction makes it lightweight and easy to clean.



Image 1: The Schuller 10 x 17 cm paint grid, showing its red color, grid pattern, integrated handle, and a small hook for attachment.

2. SETUP AND PREPARATION

Before beginning your painting project, ensure you have all necessary materials, including your paint bucket, brush or roller, and the Schuller Paint Grid.

- Unpack:** Carefully remove the paint grid from its packaging.
- Inspect:** Check the grid for any damage or defects. Do not use if the grid is broken or cracked.
- Position:** Place the paint grid inside your paint bucket or tray. The small hook on the grid is designed to rest on the rim of the bucket, holding the grid securely in place. Ensure the grid is stable and does not move excessively when

in use.

3. OPERATING INSTRUCTIONS

Follow these steps for effective use of the paint grid:

- Dip Brush/Roller:** Dip your paint brush or roller into the paint, ensuring it picks up a sufficient amount.
- Remove Excess Paint:** Gently drag the brush or roll the roller across the surface of the paint grid. The grid's pattern will help remove any excess paint, preventing drips and ensuring a more even coat. Repeat this action until the brush or roller has the desired amount of paint.
- Apply Paint:** Proceed to apply the paint to your desired surface.
- Re-dip as Needed:** Repeat the process of dipping and removing excess paint as required throughout your painting task.

4. CARE AND MAINTENANCE

Proper cleaning and storage will extend the life of your paint grid.

- Immediate Cleaning:** Clean the paint grid immediately after each use, before the paint dries.
- Water-Based Paints:** For water-based paints, rinse the grid thoroughly under running water. Use a brush or sponge to remove any stubborn paint residue from the grid squares.
- Oil-Based Paints:** For oil-based paints, clean the grid with an appropriate paint thinner or solvent as recommended by the paint manufacturer. Ensure proper ventilation and follow safety guidelines when using solvents.
- Drying:** Allow the grid to air dry completely before storing.
- Storage:** Store the clean, dry paint grids in a cool, dry place away from direct sunlight and extreme temperatures.

5. TROUBLESHOOTING

Common issues and their solutions:

Problem	Possible Cause	Solution
Grid slips in bucket.	Hook not properly engaged or bucket rim is too thick/thin.	Ensure the hook is securely resting on the bucket rim. Use with compatible bucket sizes.
Paint dries on grid.	Grid not cleaned immediately after use.	Clean the grid promptly after finishing your painting task. For dried paint, soak in appropriate solvent before scrubbing.
Ineffective paint removal.	Incorrect technique or grid is clogged.	Ensure you are dragging the brush/roller firmly across the grid. Clean the grid thoroughly to remove any clogs.

6. PRODUCT SPECIFICATIONS

- Brand:** Schuller
- Model Number:** 14189
- Part Number:** 40440
- Dimensions:** Approximately 10 x 17 cm (4 x 6.7 inches)

- **Material:** Durable Plastic
- **Quantity:** 10 pieces per pack (VE=10 st.)
- **Color:** Red
- **ASIN:** B008IAE7R6
- **First Available Date:** January 15, 2020

7. WARRANTY AND SUPPORT

This product is designed for durability and repeated use. For any questions regarding the product, or if you encounter issues not covered in this manual, please contact the manufacturer, Schuller, or your point of purchase for support. While specific warranty details are not provided in this document, standard consumer rights apply. Please retain your proof of purchase for any warranty claims.




For more information about Schuller products, you may visit the [Schuller Store on Amazon](#).



© 2023 Schuller. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.

Related Documents - 14189

	<p>Schuller Pendant Lamp Assembly Instructions - Item 553739</p> <p>Comprehensive assembly instructions for the Schuller pendant lamp (Item 553739). This guide provides detailed steps, safety warnings regarding wiring and cable management, notes on artisanal glass production, and contact information for technical support. Optimized for search engines.</p>
	<p>Schuller 157322 Pendant Lamp Assembly Instructions</p> <p>Step-by-step assembly instructions for the Schuller 157322 pendant lamp. Includes safety precautions, installation guide, and contact information.</p>
	<p>Schuller 794691B Bluetooth Dimmable Ceiling Lamp - Assembly Instructions & Smart Life App Guide</p> <p>Detailed assembly instructions and guide for the Schuller 794691B Bluetooth dimmable ceiling lamp. Learn how to install, connect, and control your lamp using the Smart Life app.</p>

Detailed assembly instructions for the Schuller 157308 pendant lamp, including safety precautions, step-by-step guidance, and contact information.

Detailed assembly instructions for the Schuller 364874 chandelier, including step-by-step guidance and important notes for installation.

Step-by-step assembly guide for the Schuller 292038 lamp, including electrical connection details and technical support contact information. Features textual descriptions of diagrams.