

Manuals.plus /

- › Nuova video suono /
- › SCART to 3.5mm Stereo Jack Adapter User Manual

## Nuova video suono 11/26

# SCART to 3.5mm Stereo Jack Adapter User Manual

Model: 11/26

## 1. INTRODUCTION

Thank you for choosing the Nuova video suono SCART to 3.5mm Stereo Jack Adapter. This adapter is designed to provide an audio output solution for televisions or other devices that lack a dedicated headphone jack, allowing you to connect headphones or external speakers via the SCART interface.

This monoblock adapter features a SCART passthrough, enabling you to connect another SCART device (such as a VCR, DVD player, or set-top box) simultaneously. Please note that for audio output, a signal must be present on the SCART input from a connected device.

## 2. SAFETY INFORMATION

- Ensure all devices are powered off before connecting or disconnecting the adapter.
- Do not expose the adapter to moisture, extreme temperatures, or direct sunlight.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to disassemble or modify the adapter. This will void the warranty and may cause damage.
- Keep out of reach of children.

## 3. PACKAGE CONTENTS

The package should contain the following item:

- 1 x Nuova video suono SCART to 3.5mm Stereo Jack Adapter

## 4. SETUP

Follow these steps to set up your SCART to 3.5mm Stereo Jack Adapter:

1. **Identify the SCART Port:** Locate an available SCART output port on your television or other audio/video source device. Ensure the device is powered off.



*Image 1: The SCART to 3.5mm Stereo Jack Adapter. This image shows the black adapter with a SCART connector on one end and a 3.5mm jack cable on the other.*

2. **Connect the Adapter:** Insert the SCART connector of the adapter firmly into the SCART port on your TV.
3. **Connect Audio Device:** Plug your headphones or external speakers (with a 3.5mm jack) into the 3.5mm stereo jack output on the adapter.
4. **Connect Passthrough Device (Optional):** If you wish to connect another SCART device (e.g., a DVD player, VCR, or set-top box) to your TV via the adapter, connect its SCART cable to the passthrough SCART input on the adapter.




Image 2: SCART Pinout Diagram. This diagram illustrates the internal wiring of the SCART connector, showing the audio output pins (AUDIO OUT - R, AUDIO OUT - L, GND) connected to the 3.5mm jack.

5. **Power On:** Power on your television and the connected audio/video source device.

## 5. OPERATING INSTRUCTIONS

Once connected, the adapter will output stereo audio from the SCART source to your connected 3.5mm audio device. The audio signal is derived from the SCART output of the television or the device connected to the passthrough SCART input.

- **Volume Control:** Adjust the volume directly on your connected headphones or external speakers. The TV's internal speaker volume may or may not be affected, depending on your TV model.
- **Source Selection:** Ensure your TV is set to the correct input source for the SCART connection to receive audio.
- **Passthrough Functionality:** If using the passthrough, the audio output will typically be from the device currently active and sending a signal through the SCART connection.

## 6. MAINTENANCE

The SCART to 3.5mm Stereo Jack Adapter requires minimal maintenance:

- **Cleaning:** Use a soft, dry cloth to wipe the adapter. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and moisture when not in use.
- **Handling:** Always grasp the connectors when plugging or unplugging, rather than pulling on the cable.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No audio output from headphones/speakers.	Adapter not fully inserted. Headphones/speakers not properly connected or faulty. TV/source device not outputting audio via SCART. Incorrect TV input source selected. Volume on headphones/speakers is too low or muted.	Ensure the SCART connector is fully seated in the TV port. Check the connection of your audio device. Test with another audio device if possible. Verify that your TV or source device is configured to output audio through the SCART port. Some TVs may require specific settings. Select the correct AV/SCART input on your TV. Increase the volume on your headphones/speakers.
Audio is distorted or has static.	Loose connection. Interference from other electronics. Faulty audio device or cable.	Ensure all connections are secure. Move the adapter away from other electronic devices that might cause interference. Test with different headphones/speakers or a different 3.5mm cable.

## 8. SPECIFICATIONS

- **Model:** 11/26
- **Brand:** Nuova video suono
- **Type:** SCART to 3.5mm Stereo Jack Adapter
- **Connectors:** SCART Male, SCART Female (Passthrough), 3.5mm Stereo Jack Female
- **Color:** Black
- **Dimensions:** Approximately 10.2 x 8.8 x 2.2 cm (4.02 x 3.46 x 0.87 inches)
- **Weight:** Approximately 49.9 grams (1.76 ounces)
- **Compatible Devices:** Headphones, Speakers, MP3 Players (via 3.5mm jack)
- **Recommended Use:** Connecting electronic devices like headphones, speakers, and MP3 players to a TV's SCART output.

## 9. WARRANTY INFORMATION

This product is covered by a standard manufacturer's warranty against defects in materials and workmanship. Please refer to your purchase documentation for specific warranty terms and duration. The warranty does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear.

## 10. SUPPORT

For technical support or customer service inquiries, please contact your retailer or visit the official Nuova video suono website. Please have your product model number (11/26) and purchase details ready when contacting support.

You can find more information and contact details at: [Nuova video suono on Amazon.it](#)

