

## Casio Tq-143-4

# Casio Tq-143-4 Table Top Travel Alarm Clock User Manual

Model: Tq-143-4

## INTRODUCTION

---

Thank you for choosing the Casio Tq-143-4 Table Top Travel Alarm Clock. This compact and reliable analog alarm clock is designed for convenience and portability, making it ideal for travel or everyday use. This manual provides essential information on how to set up, operate, and maintain your clock to ensure optimal performance.



This image displays the Casio Tq-143-4 Table Top Travel Alarm Clock. It features a square red casing with a round white analog dial. The dial has clear black numbers from 1 to 12, minute markers, and luminous hour and minute hands. The Casio logo is visible below the 12 o'clock position, and 'QUARTZ' is printed above the 6 o'clock position. A silver-colored bar is visible on top, likely for the alarm stop/snooze function.

## SETUP

---

### 1. Battery Installation

Your Casio Tq-143-4 clock operates on a single AA battery (included). To install or replace the battery:

1. Open the battery compartment cover located on the back of the clock.
2. Insert one AA battery, ensuring the positive (+) and negative (-) terminals are aligned correctly according to the diagram inside the compartment.
3. Close the battery compartment cover securely.

### 2. Initial Time Setting

Once the battery is installed, set the current time:

1. Locate the **TIME SET** knob on the back of the clock.

2. Rotate the knob in either direction to move the hour and minute hands until the correct time is displayed.

## OPERATING INSTRUCTIONS

---

### Setting the Alarm

To set the alarm time:

1. Locate the **ALARM SET** knob on the back of the clock.
2. Rotate this knob to move the small alarm hand to your desired alarm time.

### Activating/Deactivating the Alarm

To turn the alarm on or off:

- Locate the **ALARM ON/OFF** switch, typically on the side or back of the clock.
- Slide the switch to the **ON** position to activate the alarm.
- Slide the switch to the **OFF** position to deactivate the alarm.

### Using the Snooze/Light Function

When the alarm sounds, you can temporarily stop it and activate the dial light:

- Press the large button/bar located on the top of the clock. This will pause the alarm for a few minutes (snooze function) and illuminate the dial for easy viewing in the dark.
- The alarm will sound again after the snooze period. To stop the alarm completely, slide the **ALARM ON/OFF** switch to **OFF**.

## MAINTENANCE

---

### Battery Replacement

Replace the battery when the clock starts losing time or the alarm becomes weak. Refer to the 'Battery Installation' section for instructions.

### Cleaning

To clean your clock, wipe it with a soft, dry cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the casing or dial.

### Storage

If you plan not to use the clock for an extended period, remove the battery to prevent leakage and potential damage to the clock's internal components.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Clock not working / Hands not moving	Battery is dead or incorrectly installed.	Check battery polarity or replace with a new AA battery.

Problem	Possible Cause	Solution
Alarm does not sound	Alarm is not activated or alarm time is incorrectly set.	Ensure the ALARM ON/OFF switch is in the ON position. Verify the alarm hand is set to the desired time.
Time is inaccurate	Weak battery.	Replace the battery with a fresh one.

### SPECIFICATIONS

Brand:	Casio
Model:	Tq-143-4
Color:	Red
Display Type:	Analog
Power Source:	Battery Powered (1 x AA battery)
Dimensions:	2.83 x 0.01 x 2.95 inches (approximate)
Item Weight:	5 ounces / 0.31 Pounds (approximate)
Frame Material:	Plastic
Special Feature:	Alarm, Light, Snooze
Movement:	Quartz

### WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or visit the official Casio website. You may also contact Casio customer service directly for assistance with product inquiries or issues.

For more information, visit the [Casio Store on Amazon](#).