

[Manuals.plus](#) /

› [Wilton](#) /

› Wilton Decorating Tip, No.67 Leaf Instruction Manual

Wilton W418-67

Wilton Decorating Tip, No.67 Leaf Instruction Manual

Model: W418-67

PRODUCT OVERVIEW

The Wilton No.67 Leaf Decorating Tip is a high-quality tool designed for creating precise leaf and petal decorations on cakes, cupcakes, and other baked goods. Crafted from durable nickel-plated brass, this tip is engineered to hold its shape and deliver consistent, professional-looking results every time. It seamlessly integrates with Wilton Decorating Icing Pouches or Tubes, simplifying the process of adding intricate designs to your creations.



Image: The Wilton No.67 Leaf Decorating Tip displayed in its original packaging, highlighting the tip's design and potential decorative outcomes.

FEATURES

- **Durable Construction:** Made from high-quality nickel-plated brass for long-lasting use and shape retention.
- **Precise Design:** Specifically designed to create realistic leaf and petal shapes with ease.
- **Easy Compatibility:** Screws directly onto Wilton decorating icing pouches or tubes for quick setup.
- **Versatile Use:** Ideal for decorating cakes, cookies, cupcakes, and other desserts.

- **Simple to Clean:** Easy to wash and maintain for repeated use.

SETUP

1. **Prepare Piping Bag:** Insert a coupler base into your decorating bag, pushing it down to the narrow end. If not using a coupler, simply snip the end of the bag to allow the tip to fit snugly.
2. **Insert Decorating Tip:** Place the Wilton No.67 Leaf Tip over the coupler base (or directly into the bag opening if not using a coupler) from the outside of the bag.
3. **Secure Tip:** If using a coupler, screw the coupler ring onto the coupler base from the outside of the bag, securing the tip in place. Ensure the tip is firmly attached to prevent icing leakage.
4. **Fill Bag:** Fill the decorating bag with your desired icing, ensuring not to overfill (typically no more than two-thirds full).



Image: A detailed view of the Wilton No.67 Leaf Tip, showcasing its nickel-plated brass material and the precise opening for creating leaf designs.

OPERATING INSTRUCTIONS

The Wilton No.67 Leaf Tip is designed for creating realistic leaves and simple petals. Follow these steps for optimal results:

1. **Positioning:** Hold the decorating bag with the tip's opening positioned vertically, with the narrowest part of the opening pointing upwards.
2. **Apply Pressure:** Apply steady, even pressure to the decorating bag, allowing the icing to emerge from the tip.
3. **Forming the Leaf:** As icing emerges, gently pull the tip away from the surface while maintaining pressure. Release pressure as you finish the leaf, creating a natural tapered end. For a more defined leaf, you can slightly wiggle the tip as you pull away.
4. **Practice:** Practice on parchment paper or a practice board until you achieve your desired leaf shape and consistency.



Image: An example of the Wilton No.67 Leaf Tip in action, showing how it is used to pipe green icing leaves to complement floral designs on a cake.

MAINTENANCE

Proper care will extend the life of your Wilton Decorating Tip:

- **Immediate Cleaning:** After each use, remove any excess icing from the tip.
- **Hand Wash Recommended:** Wash the tip thoroughly with warm, soapy water. Use a small brush (like a bottle brush or a specialized tip brush) to clean inside the tip's opening and crevices.
- **Rinse Thoroughly:** Rinse the tip completely under clean running water to remove all soap residue.
- **Dry Completely:** Dry the tip immediately and thoroughly with a soft cloth or allow it to air dry completely before storing to prevent tarnishing or rust.
- **Storage:** Store the tip in a dry place, preferably in a tip organizer or container, to protect it from damage.

TROUBLESHOOTING

- **Icing Not Flowing Smoothly:**
 - Check icing consistency: Icing may be too stiff. Add a small amount of liquid (water, milk, or flavoring) and mix until desired consistency is reached.
 - Check for clogs: A piece of hardened icing or debris might be blocking the tip. Clear the tip using a clean skewer or a tip brush.
- **Tip Leaking from Bag:**
 - Ensure the tip is securely fastened with the coupler ring.
 - If not using a coupler, ensure the bag opening is cut small enough for the tip to fit snugly and prevent leakage.
- **Leaves Not Forming Correctly:**
 - Adjust pressure: Apply consistent, even pressure. Too little pressure will result in thin, broken lines; too much will create thick, undefined shapes.
 - Review technique: Ensure the tip is held correctly and the pulling motion is smooth and controlled. Practice helps improve technique.

SPECIFICATIONS

Brand	Wilton
Model Number	W418-67
Material	Nickel-plated brass
Color	Silver
Number of Pieces	1
Opening Shape	Leaf
Product Dimensions	11.81 x 11.81 x 11.81 inches (Packaging dimensions, actual tip is smaller)
Item Weight	0.16 ounces
UPC	070896117342, 070896042156
Date First Available	March 10, 2004

WARRANTY & SUPPORT

For specific warranty information or product support, please refer to the official Wilton website or contact Wilton customer service directly. Keep your purchase receipt as proof of purchase.

Wilton Customer Service:

- **Website:** www.wilton.com
- Refer to the website for contact numbers or online support options.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question