

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Simplicity](#) /

› [Simplicity Sewing Machine Spool Pin 188058121 User Manual](#)

Simplicity 188058121

Simplicity Sewing Machine Spool Pin 188058121 User Manual

Brand: Simplicity | Model: 188058121

1. PRODUCT OVERVIEW

The Simplicity Sewing Machine Spool Pin (Model 188058121) is a replacement or spare part designed to hold thread spools securely on compatible sewing machines. This essential component ensures smooth thread feeding during sewing operations, contributing to consistent stitch quality.



Figure 1: A metallic, cylindrical spool pin designed for various sewing machine models.

2. COMPATIBILITY

This spool pin is compatible with a wide range of sewing machine models from Simplicity, Baby Lock, and Brother. Please verify your machine's model number against the list below to ensure compatibility.

Compatible Simplicity Models:

- SL9240
- SL8020
- SL8130
- SL8220
- SL9130
- SL9150

Compatible Baby Lock Models:

- BL200

- BL702
- BL713
- BL722
- BL1500
- BL2400

Compatible Brother Models:

- BM2600
- BM3500
- L25
- L35
- LS590
- XL2120
- XL2121
- XL2130
- XL2140
- XL2150
- XL2220
- XL2230
- XL2240
- XL2250
- XL2600
- XL2610
- XL2620
- XL3500
- XL3500T
- XL3510
- XL3520
- XL3800

3. SETUP AND INSTALLATION

Installing the Simplicity Sewing Machine Spool Pin is typically a straightforward process. Refer to your sewing machine's specific user manual for exact instructions regarding spool pin replacement or installation, as locations and methods may vary.

1. **Identify the Spool Pin Location:** Locate the designated slot or hole on your sewing machine where the spool pin is inserted. This is usually on the top or back of the machine.
2. **Insert the Spool Pin:** Gently insert the Simplicity Spool Pin into the identified slot. Ensure it is seated firmly and securely. Do not force the pin if it does not fit easily.
3. **Test Stability:** Once inserted, lightly tug on the pin to ensure it is stable and does not wobble. A secure fit is crucial for proper thread feeding.

Note: If replacing an existing spool pin, carefully remove the old pin before inserting the new one. Some machines may require a slight twist or release mechanism to remove the old pin.

4. OPERATING INSTRUCTIONS

Once the spool pin is installed, it is ready for use with your thread spools.

- Place Thread Spool:** Slide your chosen thread spool onto the spool pin. Ensure the thread unwinds smoothly from the spool in the correct direction as indicated by your sewing machine's threading guide.
- Secure Spool (if applicable):** Some machines or spools may require a spool cap or felt pad to keep the spool secure and prevent tangling. Place these accessories onto the pin after the spool, if necessary.
- Thread the Machine:** Follow your sewing machine's specific threading path, guiding the thread from the spool pin through all tension discs, take-up levers, and guides, down to the needle.

5. MAINTENANCE

The Simplicity Sewing Machine Spool Pin is a durable metal component designed for longevity. Minimal maintenance is required to keep it in optimal condition.

- Cleaning:** Periodically wipe the spool pin with a soft, dry cloth to remove any dust or lint accumulation. Avoid using harsh chemicals or abrasive materials that could damage the metal finish.
- Storage:** If the spool pin is removed for storage or transport, keep it in a clean, dry place to prevent corrosion or damage.
- Inspection:** Occasionally inspect the pin for any signs of bending or damage. A damaged pin can affect thread feeding and should be replaced.

6. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--|---|--|
| Spool pin does not fit into the machine. | Incompatible machine model or incorrect insertion angle. | Verify your machine model against the compatibility list. Ensure the pin is aligned correctly with the slot. Do not force. |
| Thread spool wobbles or falls off. | Spool pin not fully seated, or missing spool cap/felt pad. | Ensure the pin is securely inserted. Use the appropriate spool cap or felt pad for your thread spool size. |
| Thread snags or breaks at the spool pin. | Rough edges on the pin (unlikely for new part), or incorrect thread path. | Inspect the pin for any damage. Re-thread the machine carefully, ensuring the thread unwinds smoothly from the spool. |

7. SPECIFICATIONS

| Attribute | Detail |
|--------------|--------------------------|
| Product Name | Sewing Machine Spool Pin |
| Model Number | 188058121 |
| Brand | Simplicity |
| Item Weight | 1 pounds |

| Attribute | Detail |
|-----------|-----------|
| ASIN | B008MKG08 |

8. CUSTOMER SUPPORT

For further assistance or inquiries regarding the Simplicity Sewing Machine Spool Pin, please contact your product retailer or refer to the support resources provided by your sewing machine manufacturer.

For information on Simplicity products, you may visit the official Simplicity store on Amazon:[Simplicity Store](#)

© 2025 Simplicity. All rights reserved. This manual is for informational purposes only.