Canyon CNR-FMSOW01

Canyon CNR-FMSOW01 Wireless Mouse User Manual

Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Canyon CNR-FMSOW01 Wireless Optical Mouse. Designed for efficiency and portability, this mouse offers precise control and seamless connectivity for your daily computing needs.



Image: The Canyon CNR-FMSOW01 Wireless Mouse with its compact USB receiver.

Setup Guide

1. Battery Installation

1. Locate the battery compartment on the underside of the mouse.

2. Open the battery compartment cover.
3. Insert two AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

2. Connecting the USB Receiver

1. Remove the nano USB receiver from its storage slot, usually located inside the battery compartment or on the underside of the mouse.
2. Plug the USB receiver into an available USB 2.0 port on your computer (PC or Laptop).
3. Your computer should automatically detect and install the necessary drivers. This may take a few moments.
4. Once installed, the mouse is ready for use.



Image: Product packaging illustrating key features like 2.4G Wireless, 1600 DPI, and OS compatibility.

Operating Instructions

Basic Functions

- **Left Button:** Primary click function, used for selecting items, opening files, etc.
- **Right Button:** Secondary click function, typically opens context menus.
- **Scroll Wheel:** Used for scrolling up and down documents or web pages. Can also function as a middle click button.

DPI Sensitivity

The Canyon CNR-FMSOW01 mouse operates at 1600 DPI (Dots Per Inch), providing precise and fast tracking for smooth cursor movement across your screen. This fixed DPI setting is optimized for general office and daily computing tasks.

Wireless Range

The mouse utilizes 2.4 GHz wireless technology, offering a reliable connection with minimal delay. Ensure the mouse is within a reasonable range of the USB receiver for optimal performance.

Maintenance

Cleaning

- To clean the mouse, use a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Avoid using harsh chemicals or abrasive materials, as they may damage the surface of the mouse.
- Do not immerse the mouse in water or any other liquid.

Battery Replacement

When the mouse performance degrades or the cursor becomes erratic, it may be time to replace the batteries. Follow the battery installation steps in the Setup Guide to replace the two AAA batteries.

Storage

When not in use for extended periods, it is recommended to remove the batteries to prevent leakage and potential damage to the mouse. Store the mouse and USB receiver in a cool, dry place.

Troubleshooting

Problem	Solution
Mouse not responding	Check if batteries are correctly installed and charged. Ensure the USB receiver is securely plugged into a working USB port. Try a different USB port.
Erratic cursor movement	Clean the optical sensor on the underside of the mouse. Ensure you are using the mouse on a suitable surface (non-reflective, non-transparent). Replace batteries if they are low.
Short wireless range or interference	Move the mouse closer to the USB receiver. Avoid placing the receiver near other wireless devices or large metal objects that may cause interference.
Mouse not detected by computer	Restart your computer. Try plugging the USB receiver into a different USB port. Ensure your operating system is up to date.

Specifications

Feature	Detail
Brand	Canyon
Item Model Number	CNR-FMSOW01
Color	Black
Connectivity Type	Wireless (2.4 GHz)
Movement Detection	Optical
DPI	1600 DPI
Number of Buttons	3
Hand Orientation	Ambidextrous
Batteries Required	2 AAA batteries (included)
Product Dimensions	10.5 x 7 x 3.5 cm
Item Weight	68.04 grams
Hardware Platform	Laptop, Personal Computer
Operating System Compatibility	Windows 2000/XP/Vista/7, Mac OS 10.1 or later
Recommended Uses	Office

Warranty and Support

The Canyon CNR-FMSOW01 Wireless Mouse comes with a standard manufacturer's warranty. Please refer to the product packaging or the official Canyon website for specific warranty terms and conditions.

For technical support, frequently asked questions, or to download the latest drivers, please visit the official Canyon support page. You may also find useful information and resources at http://goo.gl/Tnu0ML.

If you require further assistance, please contact Canyon customer service through their official channels.

© 2024 Canyon. All rights reserved.