

[Manuals.plus](#) /

> [Shad](#) /

> SHAD SH29 Top Case Instruction Manual

Shad SH29

SHAD SH29 Top Case Instruction Manual

Model: SH29

1. INTRODUCTION

This instruction manual provides detailed information for the proper installation, operation, and maintenance of your SHAD SH29 Top Case. Please read this manual thoroughly before using the product to ensure safe and efficient operation.

Retain this manual for future reference.

The SHAD SH29 Top Case is designed for scooters, maxi-scooters, and motorcycles, offering a secure and convenient storage solution. It features a 29-liter capacity, capable of holding one full-face helmet and gloves.

2. SAFETY INFORMATION

Always prioritize safety when installing and using the top case. Failure to follow these instructions may result in injury or damage to the product or vehicle.

- Ensure the top case is securely mounted to the motorcycle or scooter's rack before each ride.
- Do not exceed the maximum load capacity of the top case (refer to specifications).
- Distribute weight evenly inside the case to maintain vehicle stability.
- Avoid placing heavy or unbalanced items that could shift during travel.
- Regularly check all mounting hardware for tightness and wear.
- Be aware that adding a top case can affect the vehicle's handling, especially at high speeds or in windy conditions. Adjust your riding style accordingly.
- Keep the key in a safe place and ensure the case is locked when unattended.

3. PRODUCT FEATURES

The SHAD SH29 Top Case is designed with user convenience and security in mind. Key features include:

- **SHAD Change Colour System:** Allows for customization of the top case cover (optional accessory).
- **Capacity:** Holds one full-face helmet and gloves, with a total capacity of 29 liters.
- **Press Lock System:** A secure and easy-to-use locking mechanism.

- **Optional Backrest:** Enhances passenger comfort (sold separately).
- **Universal Mounting Kit:** Includes attachment brackets, screws, nuts, and bolts for versatile installation.



Figure 3.1: Front view of the SHAD SH29 Top Case, showcasing its sleek design and SHAD branding.



Figure 3.2: The SHAD SH29 Top Case installed on the rear of a scooter, demonstrating its compact size and integration.



Figure 3.3: Another view of the SHAD SH29 Top Case on a scooter, highlighting its profile and how it complements the vehicle.



Figure 3.4: The SHAD SH29 Top Case on a scooter with a rider, illustrating its practical use for carrying items while riding.



Figure 3.5: Interior view of the SHAD SH29 Top Case, demonstrating its capacity to store a full-face helmet and gloves.



Figure 3.6: Illustration of the SHAD Change Colour System, showing the top case with various optional colored covers.

4. WHAT'S IN THE BOX

Upon opening the packaging, verify that all components are present:

- SHAD SH29 Top Case
- Universal Mounting Kit (includes attachment brackets, screws, nuts, and bolts)
- Keys for the Press Lock System

5. SETUP AND INSTALLATION

The SHAD SH29 Top Case comes with a universal mounting kit designed for easy installation on most motorcycle or scooter racks. Professional installation is recommended if you are unsure about any steps.

5.1. Required Tools

- Wrench set
- Screwdriver set
- Drill (if modifications to the rack are necessary)

5.2. Installation Steps

1. **Prepare the Rack:** Ensure your motorcycle or scooter has a stable rear rack suitable for mounting a top case. Clean the mounting area.
2. **Position the Mounting Plate:** Place the universal mounting plate (standard bottom) on your vehicle's rack. Adjust its position to ensure optimal balance and clearance.
3. **Secure the Mounting Plate:** Use the provided attachment brackets, screws, nuts, and bolts to firmly secure the mounting plate to the rack. Tighten all fasteners evenly. *Do not overtighten.*
4. **Attach the Top Case:** Align the SH29 Top Case with the mounting plate. Press down firmly until you hear a click, indicating it is securely locked onto the plate.
5. **Verify Security:** Gently pull up on the top case to ensure it is firmly attached and does not wobble.
6. **Test the Lock:** Use the key to lock and unlock the top case to familiarize yourself with the mechanism.



Figure 5.1: The universal mounting plate (standard bottom) included with the SHAD SH29 Top Case, ready for installation.

5.3. Video Guide: Product Summary and Features

Your browser does not support the video tag.

Video 5.1: This video provides a comprehensive overview of the SHAD SH29 Top Case, including its dimensions, capacity, and key features such as the standard bottom mounting plate, secure key lock, and integrated handle. It demonstrates the product from various angles and highlights its practical aspects.

6. OPERATING THE TOP CASE

6.1. Opening and Closing

- **To Open:** Insert the key into the lock and turn it to the unlock position. Press the release button located near the lock to open the lid.
- **To Close:** Lower the lid until it clicks into place. Turn the key to the lock position to secure the case. Ensure the lid is fully closed and locked before riding.

6.2. Detaching and Reattaching

- **To Detach:** With the case unlocked, locate the release lever or button on the underside of the top case (or near the mounting point). Activate the release mechanism and lift the case off the mounting plate.
- **To Reattach:** Align the bottom of the top case with the mounting plate. Press down firmly until it clicks securely into place. Verify the attachment before riding.

7. MAINTENANCE

Regular maintenance will prolong the life of your SHAD SH29 Top Case.

- **Cleaning:** Clean the exterior with mild soap and water. Avoid abrasive cleaners or solvents that could damage the finish.
- **Lubrication:** Periodically lubricate the lock mechanism with a small amount of graphite or silicone spray to ensure smooth operation.
- **Hardware Check:** Regularly inspect all mounting hardware (screws, nuts, bolts, brackets) for tightness. Retighten as necessary.
- **Seal Inspection:** Check the lid seal for any signs of wear or damage to ensure water resistance.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Case not locking properly	Lid not fully closed; debris in lock mechanism; worn key.	Ensure lid is fully closed and latched. Clean lock mechanism. Try a spare key if available.
Case feels loose or wobbly	Mounting hardware loose; incorrect installation.	Check and tighten all mounting screws and bolts. Review installation steps in Section 5.
Water inside the case	Damaged or improperly seated lid seal; case not fully closed.	Inspect the lid seal for damage and ensure it is properly seated. Confirm the lid is fully closed and latched.

9. SPECIFICATIONS

Attribute	Detail
Model	SH29
Brand	Shad
Capacity	29 Liters
Dimensions (L x W x H)	19.29" x 16.81" x 13.03" (49cm x 42.7cm x 33.1cm)
Material	Polypropylene (PP)
Color	Black Matt
Mounting Type	Universal Mounting Kit (Rear Rack)
Item Weight	6.38 pounds

10. WARRANTY AND SUPPORT

For warranty information, technical support, or to purchase optional accessories (such as the optional backrest or different color covers), please visit the official SHAD website or contact their customer service directly.
Official SHAD Website: www.shad.es

© 2024 SHAD. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B008MTAO7U>

More documents and user manuals: <https://manuals.plus/>