

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Casio](#) /

> [Casio Replacement Watch Band Manual for Models STR101C-1, STR111C-1](#)

Casio STR101C-1, STR111C-1

Casio Replacement Watch Band Instruction Manual

For Models: STR101C-1, STR111C-1 (Part Number: 10075646 / 5646)

INTRODUCTION

This manual provides instructions for the proper installation, care, and maintenance of your Casio genuine factory replacement watch band. This band is designed for Casio watch models STR101C-1 and STR111C-1.

Please read these instructions carefully before attempting to replace your watch band to ensure correct fitment and longevity of the product.

PACKAGE CONTENTS

- 1 x Casio Genuine Factory Replacement Watch Band (Part Number 10075646 / 5646)

Note: Spring bars for attachment to the watch are typically not included with replacement bands and must be purchased separately or reused from your original watch band if they are in good condition.

SETUP AND INSTALLATION

Replacing a watch band requires careful handling to avoid scratching your watch or damaging the new band. If you are unsure, it is recommended to seek assistance from a professional watch repair service.

Tools Required (Not Included):

- Spring bar tool or a small, flat-head screwdriver
- Soft cloth or protective mat
- New spring bars (if not reusing old ones)

Installation Steps:

1. **Prepare Your Workspace:** Lay your watch face down on a soft cloth or protective mat to prevent scratches.
2. **Remove the Old Band:**

- Locate the spring bars that hold the current band to the watch lugs.
- Using a spring bar tool or small screwdriver, gently compress one end of the spring bar and pull the band away from the watch lug.
- Repeat for the other side of the band and for the second half of the band.
- Carefully remove the old spring bars from the old band. Inspect them for damage; if bent or corroded, replace them with new ones.

3. Install the New Band:

- Insert a spring bar into one end of the new replacement band.
- Place one end of the spring bar into the corresponding hole on the watch lug.
- Using the spring bar tool, compress the other end of the spring bar and guide it into the opposite hole on the watch lug. Ensure both ends of the spring bar are securely seated in the lug holes.
- Gently tug on the band to confirm it is securely attached.
- Repeat this process for the other half of the replacement band.



Image: Top view of the Casio replacement watch band, showing the buckle and strap design. This image illustrates the overall shape and texture of the band.

WEARING AND ADJUSTMENT

Once installed, the watch band can be adjusted to fit your wrist comfortably using the tang buckle. The

resin material is designed for flexibility and durability.

1. **Positioning:** Place the watch on your wrist, ensuring the watch face is centered.
2. **Buckling:** Insert the free end of the band through the buckle and secure the tang (pin) into one of the adjustment holes.
3. **Securing:** Thread the excess strap through the two keepers (loops) to prevent it from flapping.

Ensure the band is snug but not too tight, allowing for comfortable movement and preventing skin irritation. A good fit allows one finger to slide comfortably under the band.



Image: Side profile of the Casio replacement watch band, highlighting the buckle and the textured surface of the strap. This view shows the thickness and contour of the band.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your Casio resin watch band, follow these care guidelines:

- **Cleaning:** Regularly clean the band with mild soap and water. Use a soft brush (like an old toothbrush) to gently scrub away dirt and grime, especially from textured areas. Rinse thoroughly with clean water.
- **Drying:** Pat the band dry with a soft cloth. Allow it to air dry completely before wearing, especially if it has been submerged in water.
- **Avoid Harsh Chemicals:** Do not expose the band to strong chemicals, solvents, or abrasive cleaners, as these can damage the resin material.
- **Sunlight Exposure:** Prolonged exposure to direct sunlight or extreme temperatures can cause the resin to degrade, discolor, or become brittle over time. Store your watch in a cool, dry place when not in use.
- **Sweat and Moisture:** While resin is water-resistant, prolonged exposure to sweat and moisture can lead to odor or material degradation. Clean the band after heavy sweating or water activities.



Image: Angled view of the Casio replacement watch band, showcasing the buckle mechanism and the textured pattern on the strap. This perspective highlights the details of the buckle and the strap's surface.

TROUBLESHOOTING

- **Band Does Not Fit:**

Ensure you have purchased the correct replacement band for your specific Casio watch model (STR101C-1 or STR111C-1). Verify the lug width of your watch and compare it with the band's specifications. This band is designed for a specific lug width; if it does not fit, it may be incompatible with your watch model.

- **Difficulty Installing Spring Bars:**

Ensure the spring bars are correctly aligned with the lug holes. Apply gentle, even pressure with the spring bar tool. If the spring bars are old or bent, replace them with new ones of the correct size.

- **Skin Irritation:**

If you experience skin irritation, ensure the band is clean and dry. Avoid wearing the band too tightly. If irritation persists, discontinue use and consult a medical professional.



Image: Another angled view of the Casio replacement watch band, providing a different perspective of the strap's texture and the buckle. This image helps in visualizing the band's design from various angles.

SPECIFICATIONS

Feature	Detail
Brand	Casio
Model Numbers	STR101C-1, STR111C-1
Part Number	10075646 / 5646
Material	Resin
Clasp Type	Tang Buckle
Metal Type	No Metal Type
Color	Black (as depicted in images)
Package Dimensions	7.4 x 3.9 x 0.79 inches
Item Weight	0.81 ounces

WARRANTY INFORMATION

This replacement watch band is a genuine Casio factory part. For specific warranty details regarding this product, please refer to the warranty documentation that came with your original Casio watch or contact Casio customer support directly. Warranty terms typically cover manufacturing defects.

Please note that wear and tear from normal use, improper installation, or damage caused by misuse are generally not covered under warranty.

CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Casio product, please visit the official Casio website or contact their customer service department.

Casio Official Website: www.casio.com

You may also contact the seller from whom you purchased this replacement band for order-specific support.