

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Morphy Richards](#) /

› [Morphy Richards Super Vapor Steam Mop Instruction Manual](#)

Morphy Richards Super Vapor

Morphy Richards Super Vapor Steam Mop Instruction Manual

Model: Super Vapor

1. INTRODUCTION

The Morphy Richards Super Vapor Steam Mop is designed to provide an efficient and hygienic cleaning solution for various floor types. This appliance utilizes steam to clean and sanitize surfaces, eliminating the need for harsh chemicals. It is suitable for hard floors and, with the included attachment, for carpets.

Please read this instruction manual thoroughly before operating the appliance to ensure safe and effective use.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Ensure the appliance is connected to a properly grounded outlet.
- Do not immerse the appliance in water or other liquids.
- Do not leave the steam mop unattended while it is powered on.
- Keep children and pets away from the appliance during operation.
- Use only clean tap water in the water tank. Do not add cleaning solutions, perfumes, or other chemicals.
- Allow the appliance to cool completely before storing.
- Unplug the appliance before filling the water tank or performing maintenance.
- Do not direct steam at people, animals, or electrical appliances.

3. PACKAGE CONTENTS

Verify that all components are present in the package:

- Steam Mop Unit
- Re-usable Microfiber Cloth Pad
- Carpet Gliding Attachment
- Instructional Manual (this document)
- Customer Care List
- Guarantee Card

4. SETUP AND ASSEMBLY

Follow these steps to assemble your Morphy Richards Super Vapor Steam Mop:

1. **Attach the Handle:** Insert the handle into the main body of the steam mop until it clicks securely into place.
2. **Attach the Microfiber Cloth Pad:** Place the microfiber cloth pad onto the cleaning head. Ensure it is securely attached and covers the entire cleaning surface.
3. **Fill the Water Tank:**
 - Ensure the appliance is unplugged.
 - Open the water tank cap.
 - Fill the water tank with clean tap water up to the maximum fill line (approximately 1 liter). Do not overfill.
 - Close the water tank cap securely.





Image 1: Fully assembled Morphy Richards Super Vapor Steam Mop. The image shows the white steam mop with a blue water tank, a long handle, and a triangular cleaning head with a microfiber pad.

5. OPERATING INSTRUCTIONS

Before first use, or after refilling the tank, allow the mop to heat up for approximately 3 minutes.

- Power On:** Plug the power cord into a suitable electrical outlet (230V). The indicator light will illuminate, signifying that the appliance is heating up.
- Heating Time:** Wait for approximately 3 minutes for the water to heat and steam to be ready.
- Steam Control:** The Super Vapor features manually controlled steam. Adjust the steam output using the control knob located on the main body to suit the cleaning task and floor type.

4. Cleaning Hard Floors:

- Move the steam mop slowly and steadily over the floor surface.
- The steam will clean and sanitize the floor, and the microfiber pad will absorb dirt.
- Floors will dry quickly due to the high temperature of the steam.

5. Cleaning Carpets:

- Attach the carpet gliding attachment over the cleaning head with the microfiber pad.
- Move the steam mop over the carpet surface to refresh and sanitize.
- This attachment is designed for carpet cleaning purposes only, not for deep carpet washing.

6. **Power Off:** When finished cleaning, unplug the appliance from the power outlet.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your steam mop.

- **Cleaning the Microfiber Cloth Pad:**

- After each use, remove the microfiber cloth pad.
- The pad is reusable and can be machine washed with similar colors. Do not use bleach or fabric softener.
- Allow the pad to air dry completely before reattaching or storing.

- **Emptying the Water Tank:** After each use, or before storing, empty any remaining water from the tank.
- **Cleaning the Exterior:** Wipe the exterior of the steam mop with a damp cloth. Do not use abrasive cleaners.
- **Storage:** Store the appliance in a cool, dry place, out of reach of children. Ensure the power cord is neatly wrapped.

7. TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Cause	Solution
No steam produced.	Water tank is empty. Appliance not plugged in. Not enough heating time.	Fill the water tank. Plug the appliance into a power outlet. Allow 3 minutes for heating.
Steam output is low.	Steam control knob set too low. Mineral buildup in the system.	Adjust the steam control knob to a higher setting. Refer to descaling instructions (if applicable, or contact customer care).
Mop not gliding smoothly.	Microfiber pad is dirty or worn.	Clean or replace the microfiber pad.

If the problem persists, please contact Morphy Richards customer care.

8. SPECIFICATIONS

- **Model:** Super Vapor
- **Power:** 1500 Watts
- **Operating Voltage:** 230 Volts
- **Water Tank Capacity:** 1 Litre
- **Heating Time:** Less than 3 minutes
- **Form Factor:** Upright (Stick type)
- **Color:** White
- **Item Weight:** Approximately 4.42 kg
- **Manufacturer Part Number:** 780002

9. WARRANTY AND SUPPORT

The Morphy Richards Super Vapor Steam Mop comes with a **2-year warranty** on the product.

For warranty claims, technical assistance, or to purchase spare parts (such as additional microfiber cloth pads), please refer to the included Customer Care List or visit the official Morphy Richards website.

Please retain your purchase receipt and the Guarantee Card for warranty purposes.

© 2023 Morphy Richards. All rights reserved.
This manual is subject to change without notice.