

Korona 2050171 Mia

Korona 2050171 Mia Electronic Kitchen Scale User Manual

Model: 2050171 / 75877

[Introduction](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#)

1. INTRODUCTION

Thank you for choosing the Korona Mia Electronic Kitchen Scale. This digital scale is designed for precise measurement of both solid and liquid ingredients, making it an essential tool for accurate cooking and baking. Its large LCD display ensures clear and easy-to-read measurements. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your device.



Figure 1: Korona Mia Electronic Kitchen Scale, showing the measuring cup and digital display on the handle.

2. SETUP

2.1 Unpacking

Carefully remove all components from the packaging. Ensure that all parts are present:

- Korona Mia Electronic Kitchen Scale (measuring cup with integrated handle and display)
- CR2032 Lithium Metal Battery (pre-installed or separate)
- User Manual (this document)

2.2 Battery Installation

The scale operates on one CR2032 lithium metal battery. If the battery is not pre-installed or needs replacement:

1. Locate the battery compartment on the underside of the handle.
2. Open the battery compartment cover.

3. Insert the CR2032 battery with the positive (+) side facing upwards.
4. Close the battery compartment cover securely.

Note: Ensure the battery cover is properly secured to prevent accidental dislodgement during use.

3. OPERATION

3.1 Powering On/Off

- To turn on the scale, press the **ON/OFF/TARE** button. The LCD display will illuminate.
- To turn off the scale, press and hold the **ON/OFF/TARE** button for a few seconds until the display turns off. The scale will automatically shut off after a period of inactivity to conserve battery life.

3.2 Selecting Units

The scale can measure in various units. To change the unit of measurement:

- Press the **UNIT** button repeatedly to cycle through available units (e.g., grams, ounces, milliliters, cups). The selected unit will be displayed on the LCD.

3.3 Weighing Ingredients (Tare Function)

The Tare function allows you to weigh multiple ingredients consecutively or to subtract the weight of a container.

1. Place the empty container (e.g., bowl, pitcher) onto the scale.
2. Press the **ON/OFF/TARE** button. The display will reset to zero, effectively subtracting the container's weight.
3. Add your first ingredient to the container. The display will show the weight of the ingredient.
4. To add another ingredient, press the **ON/OFF/TARE** button again to reset the display to zero, then add the next ingredient.
5. Repeat as needed for all ingredients.

3.4 Mode Selection

The **MODE** button allows you to switch between different measurement modes, such as weighing solids or liquids. Refer to the display for the active mode indicator.



Figure 2: Dimensions of the Korona Mia Electronic Kitchen Scale, indicating a width of 14.5 cm and a height of 21.5 cm.

4. MAINTENANCE

4.1 Cleaning

- Wipe the scale with a soft, damp cloth.
- Do not immerse the scale in water or use abrasive cleaning agents.
- The measuring cup component can be detached for easier cleaning. Ensure the electronic handle unit does not get wet.

4.2 Storage

Store the scale in a dry place at room temperature. Avoid extreme temperatures and direct sunlight.



Figure 3: The measuring cup component of the Korona Mia Electronic Kitchen Scale, shown detached from the handle for cleaning or separate use.

5. TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Cause	Solution
Display does not turn on.	Dead or incorrectly installed battery.	Check battery installation. Replace with a new CR2032 battery if necessary.
Inaccurate readings.	Scale not on a flat, stable surface; exceeding maximum weight capacity; interference.	Ensure the scale is on a level surface. Do not exceed 3 kg. Avoid strong electromagnetic fields.
"Lo" or "Err" message on display.	Low battery or overload.	Replace battery if "Lo" appears. Remove items if "Err" appears and ensure weight is within 3 kg limit.

6. SPECIFICATIONS

- **Brand:** Korona
- **Model:** Mia (2050171 / 75877)
- **Type:** Electronic Kitchen Scale
- **Material:** Plastic
- **Color:** Transparent/White
- **Display Type:** LCD
- **Weight Capacity:** Up to 3 Kilograms (3000g)
- **Measurement Precision:** 1 Gram
- **Power Source:** 1 x CR2032 Lithium Metal Battery (included)
- **Product Dimensions (L x W x H):** Approximately 14.61 x 14.5 x 21.49 cm
- **Item Weight:** Approximately 286 Grams
- **Special Feature:** Tare Function, Unit Conversion

7. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact Korona customer service directly. Keep your proof of purchase for warranty claims.

Manufacturer: Korona

Contact information may be available on the official Korona website or through your retailer.
