

[Manuals.plus](#) /

> [Hurom](#) /

> Hurom H101 Easy Clean Slow Juicer Instruction Manual

Hurom H101

Hurom H101 Easy Clean Slow Juicer Instruction Manual

Model: H101 (H-101-BBBA02)

INTRODUCTION

Thank you for choosing the Hurom H101 Easy Clean Slow Juicer. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new juicer. The H101 is designed to extract juice from fruits and vegetables using a slow squeeze technology, preserving nutrients and flavor. Please read this manual thoroughly before first use and keep it for future reference.





Image: The Hurom H101 Easy Clean Slow Juicer in Pearl Black, showcasing its sleek design.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils out of the feed chute during operation to prevent injury.
- Always unplug the juicer from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Ensure all parts are correctly assembled before operating the juicer.

- This appliance is for household use only. Do not use outdoors.
- Children should be supervised to ensure they do not play with the appliance.

PARTS AND COMPONENTS

Familiarize yourself with the various parts of your Hurom H101 juicer for proper assembly and operation.

HUROM H101 Easy Clean Slow Juicer



Image: A detailed diagram labeling the main components of the Hurom H101 juicer: Hopper, Easy Clean Chamber, Pulp Outlet, Juice Spout, and Power Switch.

Inside the Box



Manual and
Recipe Book



Large & Small
Cleaning Brush



Twin Wing
Auger



Juice & Pulp
Container



Hopper &
Chamber



Juicer Body



Pusher



Drying Rack



Fine, Coarse, and
Ice Cream Strainer

Image: An illustration showing all items included in the Hurom H101 packaging: Instruction Manual, Recipe Book, Large & Small Cleaning Brushes, Twin Wing Auger, Juice & Pulp Container, Hopper & Chamber, Juicer Body, Pusher, Drying Rack, and Fine, Coarse, and Ice Cream Strainers.

Included Components:

- Juicer Body (Motor Base)
- Hopper
- Easy Clean Chamber
- Twin Wing Auger
- Fine Strainer
- Coarse Strainer
- Ice Cream Strainer (for sorbets)
- Pulp Container
- Juice Container
- Pusher
- Cleaning Brushes (Large & Small)
- Drying Rack

- Instruction Manual & Recipe Book

SETUP AND ASSEMBLY

Before first use, wash all removable parts with warm, soapy water. Rinse thoroughly and dry. Ensure the motor base is unplugged during assembly.

1. Place the Juicer Body on a stable, flat surface.
2. Align the Easy Clean Chamber with the motor base and rotate clockwise until it locks into place.
3. Insert the desired strainer (Fine for smooth juice, Coarse for more pulp, Ice Cream for frozen desserts) into the chamber.
4. Place the Twin Wing Auger into the center of the strainer, pressing down firmly until it seats properly.
5. Attach the Hopper to the top of the chamber, aligning the red dots, and rotate clockwise until it clicks into place.
6. Position the Pulp Container under the pulp outlet and the Juice Container under the juice spout.

OPERATING INSTRUCTIONS

Food Preparation:

- Wash all fruits and vegetables thoroughly.
- Remove hard seeds, pits, or thick skins (e.g., avocado pits, pineapple skin).
- Cut ingredients into pieces that fit easily into the feed chute. For fibrous vegetables like celery, cut into 1-inch pieces to prevent clogging.

Juicing Process:

1. Ensure the juice cap is closed if you wish to mix juices in the chamber.
2. Plug the juicer into a power outlet.
3. Turn the Power Switch to the 'ON' position.
4. Slowly feed prepared ingredients into the hopper. Use the pusher only if necessary to guide ingredients down. Do not force ingredients.
5. Allow the juicer to process ingredients at its slow speed (43 RPM).
6. Once juicing is complete, open the juice cap to dispense the juice into the juice container.
7. Turn the Power Switch to 'OFF' and unplug the appliance.



Image: The Hurom H101 juicer actively extracting green juice, highlighting its key features: Easy to Clean, High Yield, and 43 RPM slow squeeze technology.



Slow Squeeze Difference

We've minimized the oxidation of juicing through our patented design, leaving you with fresher, more nutrient rich juice.

Image: The Hurom H101 juicer processing red fruits and vegetables, demonstrating the 'Slow Squeeze Difference' which minimizes oxidation for fresher, more nutrient-rich juice.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your juicer. The H101 features an easy-clean design.

Cleaning Steps:

1. Unplug the juicer from the power outlet.
2. Disassemble the juicer by rotating the hopper and chamber counter-clockwise.
3. Remove the auger and strainer.
4. Open the pulp outlet on the chamber for easy removal of residual pulp.
5. Rinse all removable parts under running water. The unique design of the strainers with large grooves allows for easy rinsing without scrubbing.
6. Use the provided cleaning brushes to remove any stubborn pulp or residue.
7. Wash parts with warm, soapy water, then rinse thoroughly.
8. Dry all parts completely before reassembling or storing. Use the drying rack for convenience.



Scrub Free Cleaning

With a strainer featuring grooves instead of holes, you can simply rinse parts under water with no scrubbing required.

Image: A close-up of the Hurom H101 strainer, highlighting its large, elongated grooves designed for easy rinsing and scrub-free cleaning.

Cleaning Video:

Your browser does not support the video tag.

Video: A demonstration of how to clean the Hurom H101 juicer components, showing the ease of rinsing the parts under water.


TROUBLESHOOTING

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; parts not assembled correctly.	Ensure power cord is securely plugged in. Check that the chamber and hopper are correctly locked into place.
Excessive pulp in juice.	Coarse strainer used; soft fruits/vegetables.	Use the fine strainer for less pulp. For very soft ingredients, alternate with harder ingredients.


Problem	Possible Cause	Solution
Juicer stops during operation or jams.	Overloaded with ingredients; fibrous ingredients not cut small enough.	Turn off and unplug. Disassemble and clear any blockages. Cut fibrous ingredients into smaller pieces (1-inch).
Low juice yield.	Ingredients not fresh; pulp outlet clogged.	Use fresh, firm produce. Ensure pulp outlet is clear.

SPECIFICATIONS

- **Model Name:** H101 Easy Clean Slow Juicer
- **Model Number:** H-101-BBBA02
- **Brand:** Hurom
- **Color:** Pearl Black
- **Product Dimensions:** 6"D x 6"W x 18"H (152mm D x 152mm W x 457.2mm H)
- **Chamber Capacity:** 0.5 Liters (16.9 oz / 500ml)
- **Weight:** 18.2 lbs (8.3 kg)
- **Material:** BPA-Free, Impact-Resistant ABS Plastic (Body), Stainless Steel (Blade)
- **Special Feature:** Pulp Control, Slow Squeeze Technology (43 RPM)
- **Wattage:** 150 watts
- **Power Source:** Corded Electric
- **Controller Type:** Button
- **Recommended Uses:** Fruits, Vegetables, Nuts, Seeds



Chamber Capacity
16.9oz/500ml



18.2lb
8.3kg



100%
BPA FREE
SAFE

Image: Visual representation of the Hurom H101 juicer's dimensions (6 inches wide, 18 inches high), chamber capacity (16.9 oz / 500ml), weight (18.2 lbs / 8.3 kg), and confirmation of BPA-free materials.

WARRANTY AND SUPPORT

Your Hurom H101 Easy Clean Slow Juicer comes with a manufacturer's warranty. For detailed warranty information, product support, or to purchase replacement parts, please refer to the warranty card included in your packaging or visit the official Hurom website. For any issues not covered in this manual, please contact Hurom customer service.

You can also visit the [Hurom Store on Amazon](#) for additional information and products.