

[manuals.plus](#) /

› [Toro](#) /

› [Toro Genuine OEM Key and Lanyard Kit 119-1929 Instruction Manual](#)

Toro 119-1929

Toro Genuine OEM Key and Lanyard Kit 119-1929 Instruction Manual

Model: 119-1929

1. INTRODUCTION

This manual provides instructions for the proper use and care of your Toro Genuine OEM Key and Lanyard Kit, part number 119-1929. This kit is designed to provide reliable ignition functionality and secure key management for compatible Toro outdoor power equipment.

2. PACKAGE CONTENTS

The Toro Key and Lanyard Kit 119-1929 includes the following components:

- Two (2) Ignition Keys (Part Number 117-7728)
- One (1) Lanyard with Split Ring Closure



Image 1: Contents of the Toro Key and Lanyard Kit 119-1929, showing two red ignition keys and the black lanyard.

3. COMPATIBILITY

This key and lanyard kit is compatible with various Toro outdoor power equipment models, including:

- Toro Power Clear models
- Toro Power Throw models
- Toro Power Max models

Always refer to your equipment's owner's manual to confirm the correct part number for your specific model.

4. INSTALLATION AND USAGE

4.1. Key Installation

1. Locate the ignition slot on your Toro equipment.
2. Insert one of the provided ignition keys (Part Number 117-7728) into the slot.
3. Ensure the key is fully seated.

4.2. Lanyard Attachment

1. Attach the split ring of the lanyard to the key.
2. The lanyard can be worn around the wrist or attached to clothing to prevent loss of the key during operation.
3. The quick-release buckle allows for easy detachment of the key from the main lanyard strap when needed.

4.3. Operating Equipment with Key

Once the key is inserted, follow the starting procedures outlined in your Toro equipment's owner's manual. The key acts as a safety interlock, preventing the engine from starting or running without it.

- **To Start:** Insert the key and follow your equipment's specific starting instructions.

- **To Stop:** Remove the key from the ignition slot. This will typically shut off the engine and prevent accidental starting.

5. CARE AND STORAGE

- Keep keys clean and free from debris.
- Store spare keys in a dry, safe place to prevent loss or damage.
- Inspect the lanyard periodically for signs of wear or damage. Replace if necessary.

6. TROUBLESHOOTING

If your equipment does not start with the new key:

- **Verify Compatibility:** Double-check that the key and lanyard kit (Part Number 119-1929) is the correct replacement part for your specific Toro model. Refer to your equipment's owner's manual.
- **Key Seating:** Ensure the key is fully inserted into the ignition slot.
- **Other Issues:** If the key is correctly inserted and compatible, and the equipment still does not start, the issue may not be related to the key. Consult your equipment's owner's manual for general troubleshooting steps or contact an authorized Toro service center.

7. SPECIFICATIONS

Feature	Detail
Part Number	119-1929
Key Part Number	117-7728
Number of Keys	2
Lanyard Closure Type	Split Ring
Approximate Item Weight	5 Pounds <i>(Note: This value from product data likely refers to shipping weight or a larger product; actual key/lanyard weight is minimal.)</i>
Approximate Product Dimensions (L x W x H)	48 x 48 x 48 Inches <i>(Note: This value from product data likely refers to packaging or a larger product; actual key/lanyard dimensions are much smaller.)</i>

8. WARRANTY AND SUPPORT

For information regarding warranty coverage for genuine Toro parts, please refer to the warranty documentation provided with your original Toro equipment or visit the official Toro website. For technical support or to locate an authorized service dealer, please contact Toro customer service or visit their official website.

Toro Official Website: www.toro.com