

Manuals.plus /

› MONTANA /

› Montana Cans GOLD Spray Paint User Manual

MONTANA MXG-G6210

Montana Cans GOLD Spray Paint User Manual

Model: MXG-G6210 (Can2 Cool Candy)

PRODUCT OVERVIEW

Montana Cans GOLD provides superb handling, ideal for photorealistic works. This versatile, fast drying spray color provides excellent opaque coverage of pure, brilliant color. The spray cans work with a level cap system, allowing for both low- and high-pressure performance in the same can: go from low-pressure output for working in thin lines and fine detail to high-pressure output for easily filling in larger areas. It is suitable for indoor work, as the atomized spray is reduced to a minimum and is nearly odor-free. A colored ring at the top of the can that identifies the color inside so you can easily identify your color and visualize your palette.





Image: Montana Cans GOLD Spray Paint, Can2 Cool Candy. This image shows the main product, a spray paint can in a light blue-green color with gold branding.

SAFETY INFORMATION

Always read and follow all warnings and instructions on the product label before use. This product is extremely flammable and its contents are under pressure. Vapors are harmful and can irritate eyes, skin, and the respiratory tract. Use in a well-ventilated area. Keep away from heat, sparks, and open flames. Wear appropriate personal protective equipment, including gloves and safety glasses.



Image: Back of the spray paint can displaying important safety warnings and usage instructions.

SETUP

1. **Prepare the Surface:** Ensure the surface is clean, dry, and free of dust or grease. Montana Cans GOLD is suitable for application on various surfaces including canvas, wood, concrete, metal, glass, and flexible surfaces.
2. **Ensure Ventilation:** Work in a well-ventilated area, preferably outdoors. If working indoors, ensure adequate airflow and use appropriate respiratory protection.
3. **Shake the Can:** Shake the can vigorously for at least 2-3 minutes before use. A mixing ball inside the can should be heard rattling. Continue shaking periodically during application.
4. **Remove Safety Seal:** Before spraying, remove the plastic safety washer located between the spray nozzle and the can. This prevents accidental discharge.



Image: A person's gloved hands demonstrating the removal of the safety seal from the spray paint can before use.

OPERATING INSTRUCTIONS

1. **Test Spray:** Always perform a test spray on a scrap piece of material to check color and spray pattern.
2. **Application Technique:** Hold the can approximately 6 inches (15 cm) from the surface. Apply paint in smooth, even strokes. The can's level cap system allows for both low-pressure output for fine details and high-pressure output for filling larger areas.
3. **Multiple Coats:** For best results and opaque coverage, apply multiple thin coats rather than one thick coat. Allow adequate drying time between coats.
4. **Drying Time:** The paint is fast-drying, but full curing may take a few days, especially for chrome effects. Avoid handling or applying clear coats until fully dry to prevent dulling the finish.
5. **360° Nozzle:** The 360° spray nozzle allows you to paint from any angle, including upside down, for versatile application.



Image: A hand demonstrating the proper technique for spraying the Montana Cans GOLD paint onto a metal frame.



Image: Examples of furniture, specifically dining chairs, painted with Montana Cans GOLD spray paint, showcasing the smooth finish.

MAINTENANCE

- **Nozzle Cleaning:** To prevent clogging, especially if not using the entire can, invert the can and spray until only clear propellant comes out. This clears paint from the nozzle.
- **Storage:** Store cans in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the cap is securely placed to prevent accidental discharge.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clogged Nozzle	Paint residue in the nozzle.	Invert the can and spray until clear propellant emerges. If severely clogged, replace the nozzle.
Uneven Spray or Drips	Can not shaken sufficiently, spraying too close, or applying too much paint.	Shake the can well before and during use. Maintain a distance of 6 inches from the surface. Apply multiple thin coats.
Paint Not Adhering / Dusty Finish	Improper surface preparation (dirty, greasy), or paint drying too quickly in the air.	Ensure surface is clean and dry. Avoid spraying in extremely dry or windy conditions.
Color Appears Different	Discrepancy between perceived color and actual spray.	Always refer to the colored ring on the can for the most accurate color representation. Perform a test spray.

SPECIFICATIONS

Brand	MONTANA
Model Name	GOLD
Item Model Number	MXG-G6210
Color	Gld400-6210 - Can2 Cool Candy
Finish Type	Semi-Gloss
Item Volume	1 Gallon (400 Milliliters)
Unit Count	128.0 Fluid Ounces
Paint Type	Spray
Specific Uses	Interior/Exterior
Surface Recommendation	Canvas, Wood, Concrete, Metal, Glass, Flexible Surfaces
Indoor/Outdoor Usage	Indoor, Outdoor
Item Form	Spray
Included Components	1 Can of Montana Spray Paint with replaceable cap
Item Weight	14.6 ounces
Product Dimensions	2.55 x 2.55 x 7.3 inches
Coverage	25 sq ft.
Special Features	Reflective, 100% lead and CFC free

WARRANTY AND SUPPORT

Specific warranty information for the Montana Cans GOLD Spray Paint is not provided in the product details. For support or

warranty inquiries, please contact the manufacturer, Montana Cans, directly.

Manufacturer: Montana Cans

