

Voice Caddie VC300 SE

VOICE CADDIE VC300 SE GOLF GPS - WHITE User Manual

Model: VC300 SE

INTRODUCTION

The VOICE CADDIE VC300 SE is a compact and accurate voice-guided GPS device designed specifically for golf. It provides precise distance measurements to the front, center, and back of the green, helping golfers make informed decisions on the course. Its lightweight design and clip attachment make it convenient to use during play.

PACKAGE CONTENTS

- VOICE CADDIE VC300 SE Device
- USB Charging Cable
- User Manual (this document)
- Built-in Rechargeable Battery

SETUP

1. Charging the Device

Before first use, fully charge your VOICE CADDIE VC300 SE. Connect the supplied USB charging cable to the device's USB port and plug the other end into a USB power adapter or computer USB port. The LED indicator will show charging status.



Image: The VOICE CADDIE VC300 SE device showing its USB charging port, ready for connection to the charging cable.

2. Powering On/Off

- To power on: Press and hold the Power button until the device activates.
- To power off: Press and hold the Power button until the device shuts down.

3. Course Recognition

The VC300 SE automatically recognizes the golf course you are playing on. Ensure you are outdoors with a clear view of the sky for optimal GPS signal reception. The device will announce the course name once recognized.

OPERATING INSTRUCTIONS

1. Getting Distances

Once powered on and a course is recognized, the device will automatically display and announce the distance to the center of the green. Press the main button to cycle through front, center, and back distances.



Image: The VOICE CADDIE VC300 SE device positioned on a dark surface, next to a golf club and a Titleist golf ball, illustrating its compact size.

2. Adjusting Volume

Use the volume buttons on the side of the device to increase or decrease the voice guidance volume.

3. Attaching to Hat or Belt

The VC300 SE features a built-in clip for easy attachment to your hat, visor, or belt, ensuring it's always within reach and sight.



Image: The VOICE CADDIE VC300 SE device securely clipped onto the brim of a white golf visor, demonstrating its convenient attachment method.



Image: A woman on a golf course wearing a white visor with the VOICE CADDIE VC300 SE attached, illustrating how the device is worn during play.

MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place when not in use. Avoid extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Battery is discharged.	Charge the device fully using the supplied USB cable.

Problem	Possible Cause	Solution
No GPS signal / Course not recognized.	Poor satellite reception.	Ensure you are outdoors with a clear view of the sky. Move to an open area away from tall buildings or dense trees.
Incorrect distances.	GPS signal interference or outdated course data.	Ensure strong GPS signal. Check Voice Caddie website for course updates if available.
No audio output.	Volume is too low or muted.	Increase the volume using the side buttons.

SPECIFICATIONS

- Brand:** Voice Caddie
- Model Name:** Vc300
- Special Feature:** Bluetooth
- Connectivity Technology:** GPS
- Map Type:** Street (Note: Primarily for golf course mapping)
- Sport:** Golf
- Included Components:** Batteries included (built-in rechargeable)
- Audio Output Mode:** Stereo
- Battery Life:** Approximately 9 hours
- Attachment Type:** For hat or belt (clip-on)

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Voice Caddie website or contact their customer service directly. Keep your proof of purchase for warranty claims.

Official Website: www.voicecaddie.com (Please note: This is a placeholder URL, refer to your product packaging or official documentation for the correct support website.)