



Manuals.plus /

- › Dritz /
- › Dritz Shirt Button Expanders (Model 25559) Instruction Manual

Dritz 25559

Dritz Shirt Button Expanders (Model 25559) Instruction Manual

For 3/8-Inch, 2 Count Shirt Button Expanders

1. PRODUCT OVERVIEW

The Dritz Shirt Button Expanders (Model 25559) are designed to provide additional comfort for shirts with snug or tight-fitting collars. This package includes two 3/8-inch button expanders, offering a simple solution without the need for sewing.



Image: Two Dritz Shirt Button Expanders, 3/8-inch size, made of metal, shown in their packaging.

Key Features:

- Provides extra comfort for snug-fitting collars.
- Easily fits over existing buttons; no sewing required.
- Package includes two 3/8-inch button expanders.

2. SETUP AND INSTALLATION

Follow these steps to properly attach the Dritz Shirt Button Expander:

1. Identify the shirt button that needs expansion.
2. Take one Dritz Shirt Button Expander.
3. **Standard Installation:** Slip the loop spring end of the expander over the existing shirt button. Ensure the button is securely seated within the loop.
4. **For Small Buttonholes:** If the shirt's buttonhole is too small for the entire button expander to pass through, first place the spring end through the buttonhole. Then, attach the spring loop to the existing shirt button.
5. Once attached, button your shirt as usual, using the expander as the new button.

3. OPERATING INSTRUCTIONS

The Dritz Shirt Button Expanders are designed for immediate use after installation. They provide a small but effective extension to your shirt collar, enhancing comfort.

- The expander acts as an extension, allowing the shirt collar to fasten at a slightly larger circumference.
- When wearing a tie, the expander is typically concealed, maintaining a neat appearance.
- These expanders are intended for temporary use to alleviate tightness.

4. MAINTENANCE AND CARE

To ensure the longevity of your Dritz Shirt Button Expanders and prevent damage to your garments, please observe the following care instructions:

- **Always remove the button expanders before laundering or dry cleaning any garment.** Heat and harsh chemicals can damage the expanders or the fabric of your shirt.
- Store the expanders in a dry place when not in use.
- Clean with a soft, dry cloth if necessary. Avoid abrasive cleaners.

5. TROUBLESHOOTING

If you encounter any issues while using your Dritz Shirt Button Expanders, consider the following:

- **Expander does not fit through the buttonhole:** As mentioned in the setup instructions, if the buttonhole is too small, first thread the spring end of the expander through the buttonhole, then attach it to the existing shirt button.
- **Expander feels loose or insecure:** Ensure the existing shirt button is fully seated within the spring loop of the expander. The expander should feel snug.
- **Discomfort when wearing:** Re-adjust the expander to ensure it is positioned correctly and not pinching the fabric or skin. If discomfort persists, the expander may not be suitable for that particular shirt or fit preference.

6. SPECIFICATIONS

Attribute	Detail
Brand	Dritz
Model Number	25559
Size	3/8-inch
Material	Metal
Color	Gray
Number of Pieces	2
Item Weight	4.99 g
UPC	072879250305

7. WARRANTY AND SUPPORT

For information regarding warranty, returns, or product support, please refer to the retailer's policy where the Dritz Shirt Button Expanders were purchased. You may also visit the official Dritz website for general product information and contact details.

Official Dritz Website: www.dritz.com