Bajaj ICX 7

Bajaj Majesty ICX 7 1900-Watt Induction Cooktop User Manual

Model: ICX 7 | Brand: Bajaj

1. Introduction

This manual provides essential information for the safe and efficient operation of your Bajaj Majesty ICX 7 1900-Watt Induction Cooktop. Please read it thoroughly before using the appliance and keep it for future reference. The Bajaj Majesty ICX 7 is designed to offer faster and more efficient cooking compared to traditional gas stoves, featuring a unique tact switch for convenience and 8 pre-set menus for various cooking needs.

2. Important Safety Instructions

To reduce the risk of fire, electric shock, injury to persons, or damage to the appliance, basic safety precautions should always be followed, including the following:

- Read all instructions carefully before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the power input is within the specified range of 220 - 240 V.
- Keep warm mode is available for convenience.

- The working voltage range is 130V to 260V AC.

3. Product Overview

The Bajaj Majesty ICX 7 Induction Cooktop features a sleek black glass surface with intuitive controls. It incorporates Pan Sensor Technology for efficient cooking.



Figure 1: Front view of the Bajaj Majesty ICX 7 Induction Cooktop, showing the cooking zone and control panel with various function buttons.

Key Features:

- **Pan Sensor Technology:** Detects suitable cookware for induction heating.
- **8 Preset Modes:** Dedicated settings for common cooking tasks like Soup, Braise, Boil, Deep Fry, Fry, and Hot Pot.
- **1900W Power Capacity:** Provides rapid heating and efficient cooking.
- **Voltage Pro:** Designed to operate within a wide voltage range (130V to 260V AC).

- **Variable Temperature and Power Selection:** Allows precise control over cooking settings.
- **Tact Switch Controls:** User-friendly interface for easy operation.
- **Keep Warm Mode:** Maintains food at a serving temperature.



Figure 2: Visual representation of the cooktop's key features including Pan Sensor Technology, 8 Preset Modes, 1900W Power Capacity, Voltage Pro, and Variable Temperature and Power Selection.

4. Setup

Unpacking and Initial Inspection:

1. Carefully remove the induction cooktop from its packaging.
2. Check for any signs of damage during transit. If damaged, do not use the appliance and contact customer service.
3. Ensure all included components are present: Induction cooktop, User manual, Guarantee card, and List of service centres.

Placement:

- Place the cooktop on a flat, stable, and heat-resistant surface.
- Ensure there is adequate ventilation around the appliance. Do not block the ventilation openings.
- Keep the cooktop away from water sources, open flames, and other heat-generating appliances.
- Maintain a safe distance from walls and other objects to allow for proper airflow.

Power Connection:

- Plug the power cord into a grounded electrical outlet.
- Verify that the power supply matches the appliance's requirements (220 - 240 V).

5. Operating Instructions

Compatible Cookware:

The Bajaj Majesty ICX 7 Induction Cooktop requires cookware made of ferromagnetic material. This includes cast iron, enameled iron, and stainless steel with a magnetic base. Cookware with a flat bottom and a diameter between 12 cm and 26 cm is recommended. Non-magnetic materials like glass, ceramic, aluminum, or copper will not work.

Basic Operation:

1. Place suitable cookware with food on the center of the cooking zone.
2. Plug the cooktop into a power outlet. The display will show "OFF".
3. Press the **ON/OFF** button to turn on the appliance. The display will light up.
4. Select a cooking mode or adjust power/temperature.
5. To turn off, press the **ON/OFF** button again.

Using Preset Modes:

The cooktop features 8 preset modes for common cooking tasks. Simply press the corresponding button for the desired function (e.g., Soup, Boil, Fry). The cooktop will automatically adjust power and temperature settings for optimal results.



Figure 3: The Bajaj Majesty ICX 7 Induction Cooktop in a home setting, emphasizing its 8 preset cooking modes for versatile meal preparation.

Adjusting Power and Temperature:

- After turning on, you can manually adjust the power level or temperature using the **+** and **-** buttons.
- The display will show the current power level or temperature setting.

Timer Function:

- Press the **Timer** button to set a cooking duration.
- Use the **+** and **-** buttons to adjust the time.
- Once the timer expires, the cooktop will automatically switch off or alert you.

Keep Warm Mode:

Activate the **Keep Warm** mode to maintain food at a suitable serving temperature after cooking. Refer to the control panel for the specific button or sequence to activate this function.

6. Maintenance

Cleaning the Cooktop:

1. Always unplug the cooktop and allow it to cool completely before cleaning.
2. Wipe the glass surface with a soft, damp cloth and a mild detergent.
3. For stubborn stains, use a non-abrasive cleaner specifically designed for ceramic or induction cooktops.
4. Do not use abrasive pads, harsh chemicals, or steam cleaners.
5. Ensure no water enters the internal components.
6. Dry the surface thoroughly with a clean, soft cloth.

Care and Storage:

- Avoid dropping heavy objects on the glass surface, as this can cause damage.
- Do not drag cookware across the surface to prevent scratches.
- Store the cooktop in a dry, cool place when not in use for extended periods.

7. Troubleshooting

If you encounter issues with your Bajaj Majesty ICX 7 Induction Cooktop, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cooktop does not turn on.	No power supply; Power cord not properly plugged in; Main fuse tripped.	Check if the power cord is securely plugged into a working outlet. Check your household fuse box.
Cooktop beeps and displays an error code (e.g., "E0").	Incompatible cookware; No cookware on the cooking zone; Cookware too small or too large.	Ensure you are using induction-compatible cookware. Place cookware centrally on the cooking zone. Use cookware within the recommended size range.
Cooking process is slow or inefficient.	Incorrect power setting; Cookware not fully flat or suitable for induction.	Increase the power setting. Ensure cookware has a flat, magnetic base.
Fan continues to run after turning off.	Normal operation to cool down internal components.	This is normal. The fan will stop automatically once the internal temperature has cooled sufficiently.

If the problem persists after attempting these solutions, please contact Bajaj customer service for assistance.

8. Specifications

Feature	Detail
Brand	Bajaj
Model Number	ICX 7
Power Input	220 - 240 V
Power Consumption	1900 Watts

Feature	Detail
Working Voltage Range	130V to 260V AC
Material	Glass
Colour	Black
Item Weight	3.72 kg (3720 Grams)
Item Dimensions (LxWxH)	43.4 x 36 x 20.8 Centimeters
Mounting Type	Freestanding
Fuel Type	Electric
Ventilation Type	Vent Free
Included Components	Induction cooktop, User manual, Guarantee card, List of service centre



Figure 4: Diagram showing the approximate dimensions of the Bajaj Majesty ICX 7 Induction Cooktop.

9. Warranty and Support

Your Bajaj Majesty ICX 7 Induction Cooktop comes with a **1 Year Warranty** from the date of purchase. Please refer to the Guarantee Card included in the box for detailed terms and conditions.

Customer Service:

For any service, repair, or warranty claims, please contact Bajaj customer support. A list of authorized service centers is provided with your product in the "List of service centre" document.

Bajaj Electricals Ltd
45/47, Veer Nariman Road,
Mumbai, 400001

© 2023 Bajaj Electricals Ltd. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question