

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Microsoft](#) /

› [Microsoft LifeChat LX-3000 Headset \(JUG-00013\) Instruction Manual](#)

Microsoft JUG-00013

Microsoft LifeChat LX-3000 Headset (JUG-00013) Instruction Manual

Model: JUG-00013

[Introduction](#)

[Setup](#)

[Operating Instructions](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

The Microsoft LifeChat LX-3000 Headset (JUG-00013) is designed to provide clear stereo sound and comfortable use for various audio applications, including internet voice calls, music, movies, and gaming. Featuring a noise-cancelling microphone and convenient in-line controls, this wired USB headset offers a reliable audio solution for your PC.



Figure 1: Microsoft LifeChat LX-3000 Headset with microphone and in-line controls.

2. SETUP

The Microsoft LifeChat LX-3000 Headset features a simple Plug and Play USB connection, making setup straightforward. Follow these steps to begin using your headset:

1. **System Requirements:** Ensure your PC meets the minimum operating system requirements: Microsoft Windows 10, Windows 8.1, Windows 8, or Windows 7.
2. **Connect the Headset:** Locate an available USB port on your computer. Insert the USB connector of the headset firmly into the USB port.
3. **Driver Installation:** Your operating system should automatically detect the headset and install the necessary drivers. This process may take a few moments.
4. **Verify Connection:** Once installed, the headset should appear as an audio device in your computer's sound settings. You may need to select it as the default playback and recording device.



Figure 2: Close-up of the USB connector for the headset.

3. OPERATING INSTRUCTIONS

The LifeChat LX-3000 Headset is designed for ease of use with integrated controls and a flexible microphone.

3.1. Adjusting the Headset

- **Headband Adjustment:** The headband is adjustable to fit various head sizes. Gently extend or retract the earcups until the headset sits comfortably over your ears.
- **Microphone Positioning:** The pivoting boom microphone offers 180-degree movement. Position the microphone approximately one inch from your mouth for optimal voice clarity.

3.2. Using In-Line Controls

The headset features an in-line control module for quick access to essential functions:

- **Volume Control:** Use the volume up (+) and volume down (-) buttons to adjust the listening volume.
- **Microphone Mute:** Press the mute button (often indicated by a microphone icon) to temporarily disable or enable the microphone. An indicator light on the control module may show the mute status.



Figure 3: In-line control module for volume and microphone mute.

3.3. Noise-Cancelling Microphone

The integrated noise-cancelling microphone helps reduce background noise, ensuring your voice is heard clearly during calls and recordings.

4. MAINTENANCE

Proper care and maintenance will extend the life of your Microsoft LifeChat LX-3000 Headset.

- **Cleaning Ear Pads:** The leatherette ear pads can be gently wiped with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Cable Care:** Avoid sharp bends or excessive pulling on the flexible 6-foot cable to prevent damage. Store the cable neatly when not in use.
- **Storage:** Store the headset in a clean, dry place away from extreme temperatures and direct sunlight.

5. TROUBLESHOOTING

If you encounter issues with your headset, try the following solutions:

Problem	Solution
No sound from headset	<ul style="list-style-type: none">• Ensure the USB connector is fully inserted into the port.• Check your computer's sound settings to confirm the LifeChat LX-3000 is selected as the default playback device.• Increase the volume using the in-line controls and your computer's system volume.• Try connecting to a different USB port.
Microphone not working	<ul style="list-style-type: none">• Ensure the microphone is not muted via the in-line control.• Check your computer's sound settings to confirm the LifeChat LX-3000 is selected as the default recording device.• Verify microphone privacy settings in your operating system.• Reposition the microphone boom closer to your mouth.
Poor audio quality	<ul style="list-style-type: none">• Ensure the USB connection is secure.• Close other applications that might be using audio resources.• Update your computer's audio drivers.

6. SPECIFICATIONS

Key technical specifications for the Microsoft LifeChat LX-3000 Headset:

Feature	Detail
Brand	Microsoft
Model Number	JUG-00013
Connectivity Technology	Wired (USB)
Ear Placement	Over Ear

Feature	Detail
Microphone	Noise-cancelling, Pivoting Boom (180-degree movement)
Controls	In-line Volume Control, Microphone Mute
Cable Length	Flexible 6-foot cable
Ear Pad Material	Faux Leather
Frequency Range	20 Hz - 20,000 Hz
Compatible Operating Systems	Microsoft Windows 10, Windows 8.1, Windows 8, Windows 7
Item Weight	8.32 ounces

7. WARRANTY & SUPPORT

7.1. Warranty Information

The Microsoft LifeChat LX-3000 Headset (JUG-00013) comes with a **3-year limited hardware warranty**. This warranty covers defects in materials and workmanship under normal use. For specific terms and conditions, please refer to the warranty documentation included with your product or visit the official Microsoft support website.

7.2. Customer Support

For further assistance, technical support, or warranty claims, please contact Microsoft Customer Support through their official website or the contact information provided in your product packaging. You can find additional resources and FAQs on the [Microsoft Support website](#).