Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Edushape 705191

Edushape See-Me Trendy 7-inch Sensory Ball Instruction Manual

Model: 705191

Introduction

This manual provides instructions for the safe and effective use of your Edushape See-Me Trendy 7-inch Sensory Ball. Designed to support early childhood development, this ball offers tactile stimulation and encourages motor skill development. Please read this manual thoroughly before use and retain it for future reference.
Product Contents: 1 Edushape See-Me Trendy 7-inch Sensory Ball.

Safety Information

- Always supervise children during play.
- Inspect the ball for damage before each use. Discontinue use if any damage is observed.
- Keep away from sharp objects and extreme temperatures.
- This product is intended for children aged 6 months and up.
- Made from BPA and phthalate-free plastic.

Setup

The Edushape See-Me Trendy Sensory Ball is typically shipped pre-inflated. No assembly is required. If the ball requires inflation or re-inflation:

1. Locate the inflation valve on the ball.
2. Insert a standard ball pump needle (not included) into the valve.
3. Inflate the ball until it is firm but still slightly pliable. Do not over-inflate.
4. Remove the pump needle and ensure the valve is sealed.



Image: The Edushape See-Me Trendy Sensory Ball, showing its transparent, textured surface and vibrant color, alongside its product packaging. This image illustrates the product as it appears upon unboxing.

Operating Instructions

The Edushape Sensory Ball is designed for open-ended play to encourage various developmental skills.

- **Tactile Exploration:** Encourage your child to touch, hold, and feel the nubbly surface of the ball. This stimulates sensory development.
- **Gross Motor Skills:** Facilitate activities such as rolling, tossing, and bouncing the ball. This helps develop hand-eye coordination and strengthens muscles.
- **Fine Motor Skills:** For older infants, encourage gripping and manipulating the ball with their hands.
- **Visual Tracking:** Roll the ball slowly across a surface to encourage your child to follow its movement with their eyes.



Image: A detailed close-up view of the Edushape See-Me Trendy Sensory Ball, highlighting its transparent material and the distinct nubbly texture designed for sensory stimulation.



Image: A young child, approximately 1-2 years old, sitting on the floor and happily holding a blue Edushape Sensory Ball. This demonstrates typical interaction with the product.

Maintenance and Care

- **Cleaning:** Wipe the ball with a damp cloth and mild soap. Rinse thoroughly with water. Do not use harsh chemicals or abrasive cleaners.
- **Drying:** Air dry completely before storing.
- **Storage:** Store in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Ball is deflated or soft.	Loss of air through valve or minor puncture.	Re-inflate using a standard ball pump. If deflation persists, inspect for damage.
Ball appears dirty.	Accumulation of dirt from play.	Clean with mild soap and water as per maintenance instructions.

Specifications

- **Brand:** Edushape
- **Model:** See-Me Trendy (Model Number: 705191)
- **Material:** Plastic (BPA and Phthalate-Free)
- **Color:** Transparent Trendy (Specific color may vary per individual product)
- **Item Diameter:** 7 inches
- **Item Weight:** Approximately 5.6 ounces (0.35 pounds)
- **Recommended Age:** 6 months and up
- **UPC:** 433599254767

Warranty Information

Edushape products are manufactured to high-quality standards. For specific warranty details, please refer to the packaging or contact Edushape customer support directly. General warranty terms typically cover manufacturing defects.

Support and Contact

For further assistance, questions, or to report any issues, please contact Edushape customer support:

- **Website:** Visit the official Edushape website for contact information and FAQs.
- **Brand Store:** Edushape Amazon Store

© 2025 Edushape. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0090RXNZS

More documents and user manuals: **https://manuals.plus/**