Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Paul Neuhaus B0093I37DW

Paul Neuhaus Axena Exterior Wall Lamp Instruction Manual

Model: B0093I37DW

1. Introduction

Thank you for choosing the Paul Neuhaus Axena Exterior Wall Lamp. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions carefully before installation and retain them for future reference.
The Axena wall lamp features a classic design crafted from durable aluminum, offering comprehensive illumination for outdoor areas such as terraces and gardens. It is designed for outdoor use with an IP44 protection rating.

2. Safety Instructions

WARNING: Electrical installation should only be performed by a qualified electrician. Always disconnect the main power supply before installation, maintenance, or bulb replacement to prevent electric shock.

- Ensure the power supply is switched off at the fuse box or circuit breaker before commencing work.
- Verify that the voltage indicated on the product label matches your local power supply.
- This product is rated IP44, meaning it is protected against solid objects larger than 1mm and against splashing water from any direction. It is suitable for outdoor use but should not be submerged in water.
- Do not modify the product in any way. Unauthorized modifications may void the warranty and pose safety risks.
- Keep packaging materials out of reach of children.
- Allow bulbs to cool completely before handling or replacing.

3. Package Contents

Please check that all components are present and undamaged before installation.

- 1x Paul Neuhaus Axena Exterior Wall Lamp (Aluminum body)
- 2x GU10 Bulbs (35W each)
- Mounting hardware (screws, wall plugs)
- Instruction Manual

4. Installation Guide

Important: Installation must be carried out by a qualified electrician in accordance with local wiring regulations.

1. **Preparation:**
    - Switch off the main power supply at the circuit breaker.
    - Choose a suitable mounting location on an exterior wall, ensuring it is structurally sound and has access to electrical wiring.
2. **Mounting the Fixture:**
    - Carefully remove the mounting bracket from the lamp body (if applicable).
    - Hold the mounting bracket against the wall at the desired position and mark the drilling points.
    - Drill holes using an appropriate drill bit for your wall type. Insert wall plugs if necessary.
    - Secure the mounting bracket to the wall using the provided screws.
3. **Wiring Connection:**
    - Connect the household electrical wires to the lamp's terminal block. Ensure correct polarity: Live (L) to Live, Neutral (N) to Neutral, and Earth (⚡) to Earth.
    - Ensure all connections are secure and properly insulated.
4. **Attaching the Lamp Body:**
    - Carefully attach the lamp body to the mounting bracket, securing it with the screws or fasteners provided.
5. **Bulb Installation:**
    - Insert the two GU10 bulbs into their respective sockets. Gently push and twist until they are securely seated.
6. **Final Check:**
    - Ensure all parts are securely fastened and no wires are exposed.
    - Restore power at the circuit breaker.



Figure 1: Paul Neuhaus Axena exterior wall lamp, showcasing its classic aluminum design.

5. Operating Instructions

Once installed and powered, the Paul Neuhaus Axena wall lamp operates via your standard wall switch connected to the fixture.

- **Turning On/Off:** Use the connected wall switch to turn the lamp on or off.
- **Dimming Function:** This lamp is dimmable. If connected to a compatible dimmer switch (not included), you can adjust the light intensity. Ensure that the GU10 bulbs used are also dimmable.

6. Maintenance

Regular maintenance will ensure the longevity and optimal performance of your wall lamp.

- **Cleaning:** Disconnect power before cleaning. Wipe the lamp body with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Bulb Replacement:**
    a. Switch off the power supply to the lamp.
    b. Allow the old bulb to cool completely.
    c. Gently push the GU10 bulb into its socket and twist counter-clockwise to remove.
    d. Insert a new GU10 bulb (max 35W) by pushing it into the socket and twisting clockwise until secure. Ensure the new bulb is compatible with the lamp's specifications and any dimming functionality.
    e. Restore power.
- **Inspection:** Periodically check the lamp for any signs of damage, loose connections, or wear. If any issues are found, disconnect power and consult a qualified electrician.

7. Troubleshooting

If you encounter problems with your lamp, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Lamp does not light up.	No power supply. Faulty bulb. Loose wiring connection.	Check circuit breaker/fuse. Replace bulb. Check wiring (consult electrician).
Light flickers.	Loose bulb. Incompatible dimmer switch. Faulty bulb.	Ensure bulb is securely seated. Use a compatible dimmer or remove dimmer. Replace bulb.
Dimming not working.	Non-dimmable bulbs. Incompatible dimmer switch.	Ensure dimmable GU10 bulbs are used. Ensure dimmer switch is compatible with LED/halogen GU10 bulbs.

If the problem persists after attempting these solutions, please contact a qualified electrician or customer support.

8. Specifications

Brand:	Paul Neuhaus
Model:	B0093I37DW
Material:	Aluminum, Metal

Color:	Aluminum
Protection Class:	IP44
Bulb Socket:	GU10
Number of Bulbs:	2 (included)
Max Wattage per Bulb:	35W
Power Source:	Cable electric
Special Feature:	Dimmable
Style:	Classic
Mounting Type:	Monopoint
Specific Use:	Wall, Garden

9. Warranty and Support

For information regarding warranty terms and conditions, please refer to the documentation provided at the time of purchase or contact your retailer. For technical support or inquiries, please reach out to Paul Neuhaus customer service or your authorized dealer.

© 2023 Paul Neuhaus. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0093I37DW

More documents and user manuals: **https://manuals.plus/**