

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Winsome](#) /

› [Winsome Terrace 3-Tier Wide Storage Shelf \(Model 92338\) Instruction Manual](#)

Winsome 92338

Winsome Terrace 3-Tier Wide Storage Shelf (Model 92338) Instruction Manual

Your guide to assembly, operation, and maintenance.

1. INTRODUCTION

This manual provides comprehensive instructions for the Winsome Terrace 3-Tier Wide Storage Shelf. This shelf is designed for displaying items and storing books, offering a functional and elegant addition to various rooms.

The overall dimensions of the 3-tier shelf are 37 inches (W) x 11.8 inches (D) x 30 inches (H). The top shelf surface measures 37 inches (W) x 11.8 inches (D). The two lower shelves are 34.5 inches (W) x 10.6 inches (D), with a shelf clearance ranging from 12.3 inches to 12.8 inches. The unit is constructed from a combination of solid and composite wood with an Espresso finish.



Figure 1: Assembled Winsome Terrace 3-Tier Wide Storage Shelf.

2. SAFETY INFORMATION

Please read and understand all safety warnings and assembly instructions before beginning assembly or using this product. Failure to follow these instructions may result in injury or damage to the product.

- Keep all small parts and packaging materials away from children.
- Assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all connections are securely fastened before use.
- Do not exceed the recommended weight capacity for each shelf.
- If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

3. PACKAGE CONTENTS

Verify that all components are present before starting assembly. While a detailed list is not provided, typical components for this type of shelf include:

- Top Panel
- Side Panels (2)
- Fixed Shelves (2)
- Back Panels (typically 2-3 sections)
- Hardware Pack (screws, dowels, cam locks, etc.)

Refer to the included assembly diagram for a precise list of parts and hardware.

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Follow these general steps, referring to the specific diagrams and instructions provided in your product packaging for detailed guidance.

1. **Prepare the Area:** Clear a spacious, flat, and clean area for assembly. Lay down a blanket or cardboard to protect the furniture pieces and your floor.
2. **Identify Parts:** Unpack all components and hardware. Match them against the parts list in your product's assembly guide.
3. **Assemble Side Frames:** Attach the top and bottom rails to the side panels using the provided hardware (e.g., dowels and screws). Ensure they are aligned correctly.
4. **Install Shelves:** Secure the fixed shelves between the side panels. Use cam locks and screws as indicated in the instructions. Ensure all connections are tight.
5. **Attach Back Panels:** Carefully slide or nail the back panels into the designated grooves or attach them to the rear of the unit. Ensure they are flush and secure to enhance stability.
6. **Final Tightening:** Once fully assembled, gently tighten all screws and cam locks. Avoid overtightening to prevent damage to the wood.
7. **Positioning:** Carefully move the assembled shelf to its desired location.



Figure 2: Product dimensions and recommended weight capacities.



Figure 3: Front view of the shelf, illustrating shelf layout.





Figure 4: Side view of the shelf, showing depth and leg structure.



Figure 5: Back view of the shelf, showing back panel attachment points.

5. OPERATING INSTRUCTIONS

The Winsome Terrace Storage Shelf is designed for static storage and display. To operate effectively:

- Place items evenly across the shelves to distribute weight.
- Do not overload shelves. Refer to Figure 2 for weight capacity guidelines (Top shelf: 50 lbs, Lower shelves: 25 lbs each).
- Avoid placing heavy items on the very edge of shelves to prevent tipping.
- This unit is intended for indoor use only.

6. MAINTENANCE

To maintain the appearance and longevity of your Winsome Terrace Storage Shelf:

- Wipe surfaces with a damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- Periodically check all hardware connections and tighten if necessary.
- Keep the shelf away from direct sunlight and extreme temperature changes to prevent warping or fading.

7. TROUBLESHOOTING

If you encounter issues with your storage shelf, consider the following:

- **Wobbling/Instability:** Ensure all screws and cam locks are fully tightened. Verify that the unit is placed on a level surface. If the floor is uneven, use furniture glides or shims to stabilize.
- **Parts Not Fitting:** Double-check the assembly instructions to ensure you are using the correct parts for each step and that they are oriented correctly. Do not force parts together.
- **Missing Hardware/Damaged Parts:** If you find any parts missing or damaged upon opening the package, do not proceed with assembly. Contact Winsome customer support for replacement parts.

8. SPECIFICATIONS



Brand	Winsome
Model Name	Terrace
Item Model Number	92338
Product Dimensions	11.81"D x 37"W x 30"H
Number of Shelves	3
Color	Espresso
Finish Type	Espresso
Material	Solid and Composite Wood
Item Weight	30.9 Pounds
Assembly Required	Yes
Product Care Instructions	Wipe with Damp Cloth
Recommended Uses	Indoor storage and display

9. WARRANTY AND SUPPORT

For information regarding product warranty, replacement parts, or customer support, please refer to the contact details provided in your product packaging or visit the official Winsome website. Keep your purchase receipt for warranty claims.

© 2023 Winsome Trading, Inc. All rights reserved.

Related Documents - 92338

	<p><u>Winsome 92514 R1 Storage Shelf Assembly Instructions</u></p> <p>Assembly instructions for the Winsome 92514 R1 Storage Shelf, including parts list and care instructions.</p>
	<p><u>Winsome 94138 Entertainment Cart Assembly Instructions</u></p> <p>Official assembly instructions for the Winsome 94138 Entertainment Cart, including a parts list, step-by-step assembly diagrams, and care instructions. This guide is provided by Winsome Trading, Inc. and is available in English, French, and Spanish.</p>
	<p><u>Winsome 94339 R2 Secretary Desk Assembly Instructions</u></p> <p>Detailed assembly instructions for the Winsome 94339 R2 Secretary Desk, including parts list, hardware list, and step-by-step guidance for assembly.</p>
	<p><u>Winsome 10792 R3 Cabinet Assembly Instructions</u></p> <p>Comprehensive assembly guide for the Winsome 10792 R3 7-Drawer Cabinet, detailing parts, tools, and step-by-step instructions for building the furniture.</p>
	<p><u>Winsome 40420 R2 End Table Assembly Instructions</u></p> <p>Official assembly instructions for the Winsome 40420 R2 End Table, including parts list, step-by-step guidance, and care instructions.</p>
	<p><u>Winsome Corner TV Stand 92634 - Assembly Instructions and Parts List</u></p> <p>Comprehensive guide for assembling the Winsome Corner TV Stand (model 92634), including a detailed parts list, step-by-step instructions, and care recommendations. Ensure all parts are accounted for before assembly.</p>