

[manuals.plus](#) /

› [LEGO](#) /

› [LEGO City Fire Emergency 60004 Instruction Manual](#)

**LEGO 60004**

# LEGO City Fire Emergency 60004 Instruction Manual

Model: 60004

Brand: LEGO

## INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of the LEGO City Fire Emergency 60004 building set. This set allows you to construct a fire truck, an abandoned house with retractable flames, and includes three firefighter minifigures with various accessories.

Key features of this set include:

- Three firefighter minifigures with assorted accessories.
- A fire truck with an extendable, rotating ladder and a retractable hose with a water element.
- An abandoned house featuring retractable flames, a trash can, and a streetlight.
- Accessories such as smoke diver gear, an axe, and a saw.



*The complete LEGO City Fire Emergency 60004 set, featuring the fire truck, abandoned house, and three firefighter minifigures.*

## **SETUP AND ASSEMBLY**

The LEGO City Fire Emergency 60004 set requires assembly. Please follow the detailed step-by-step building instructions provided in the box. Sort all LEGO elements by color and shape before beginning assembly to ensure a smooth building process.

### **Assembly Steps Overview:**

1. Unpack all components and verify that all parts are present using the included parts list.
2. Begin by assembling the minifigures as per the instructions.
3. Proceed with the construction of the fire truck, paying close attention to the ladder mechanism.
4. Assemble the abandoned house, ensuring the retractable flame mechanism functions correctly.
5. Integrate all accessories as indicated in the building guide.



*Various views of the LEGO City Fire Emergency 60004 set, illustrating the fire truck, house, and minifigures from different angles, and showing the house being 'on fire' and 'extinguished'.*



*Close-up view of the three firefighter minifigures and their accessories, including an axe, a fire extinguisher, and a water element.*

## OPERATING INSTRUCTIONS

Once assembled, the LEGO City Fire Emergency 60004 set offers interactive play features:

### Fire Truck Operation:

- **Extendable Ladder:** Manually extend the ladder on the fire truck to reach higher areas of the burning house. The ladder can also rotate 360 degrees for optimal positioning.
- **Retractable Hose:** Unroll the hose from the side of the fire truck and attach the water element to simulate firefighting.

### Abandoned House Features:

- **Retractable Flames:** The flame elements on the roof of the abandoned house can be manually retracted or extended to simulate the house being on fire or extinguished.
- **Door Access:** The house features a door that can be opened and closed, allowing minifigures to enter.

### Minifigure Interaction:

- Position the firefighter minifigures with their accessories (axe, saw, fire extinguisher) to engage in rescue and firefighting scenarios.



*A firefighter minifigure using an axe to 'cut through' the boarded-up door of the abandoned house, demonstrating an action scenario.*



*A firefighter minifigure inside the abandoned house, holding a fire extinguisher and aiming it at a small fire element, showing the interior play feature.*

## MAINTENANCE

To ensure the longevity and cleanliness of your LEGO City Fire Emergency 60004 set, follow these simple maintenance guidelines:

- **Cleaning:** Clean LEGO bricks using a mild soap solution and lukewarm water (not exceeding 40°C or 104°F). Rinse thoroughly with clear water and air dry at room temperature. Avoid hot water, direct sunlight, or high heat, as this can damage the plastic.
- **Storage:** Store your LEGO set in a clean, dry place away from direct sunlight to prevent discoloration and material degradation.
- **Handling:** Handle the set with care to prevent pieces from detaching or breaking.

## TROUBLESHOOTING

If you encounter any issues with your LEGO City Fire Emergency 60004 set, refer to the following common solutions:

### Missing Pieces:

- Carefully check all packaging materials, including bags and corners of the box, as small pieces can

sometimes be overlooked.

- If a piece is genuinely missing, contact LEGO Customer Service for assistance. Refer to the "Support" section for contact information.

## Assembly Difficulties:

- Double-check the building instructions for the specific step you are on. Ensure all pieces are oriented correctly.
- Sometimes, a small error in an earlier step can affect later assembly. Revisit previous steps if necessary.

## Functionality Issues:

- If the fire truck ladder or house flames are not moving smoothly, inspect the connecting pieces for any obstructions or incorrect assembly.

## SPECIFICATIONS

Feature	Detail
Model Number	60004 (Item Model Number: 6021712)
Product Dimensions	11.1 x 2.52 x 10.31 inches
Item Weight	1.3 pounds
Recommended Age	5 - 12 years
Manufacturer	LEGO City

## WARRANTY INFORMATION

LEGO products are manufactured to high-quality standards. While specific warranty details for individual sets are not typically provided, LEGO offers comprehensive customer service for issues such as missing or defective parts.

If you believe a part is missing or defective, please contact LEGO Customer Service directly. They are committed to ensuring customer satisfaction and will assist you with replacement parts if necessary.

## SUPPORT

For further assistance, including detailed building instructions, replacement parts, or general inquiries, please visit the official LEGO website:

[LEGO Customer Service](#)

You can also find additional information and community support at the [LEGO Store on Amazon](#).