

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Hello Kitty](#) /

› [Hello Kitty Water Mouse 81409A User Manual](#)

Hello Kitty 81409A

Hello Kitty Water Mouse User Manual

Model: 81409A

1. INTRODUCTION

This manual provides instructions for the Hello Kitty Water Mouse, Model 81409A. This optical mouse features a unique water globe effect with a floating charm and is designed for ease of use and durability. Please read this manual thoroughly before using your new mouse.





Figure 1: Hello Kitty Water Mouse (Model 81409A) in retail packaging.

2. PRODUCT FEATURES

- Features the iconic Hello Kitty character design.
- Unique water globe effect with a floating charm for visual appeal.
- Equipped with a new optical sensor, eliminating the need for a mouse ball.
- Compact size, suitable for various users.
- Durable construction designed for longevity.

3. SETUP INSTRUCTIONS

Follow these steps to connect and begin using your Hello Kitty Water Mouse:

1. **Unpack the Mouse:** Carefully remove the mouse from its packaging.
2. **Connect to Computer:** Locate an available USB port on your computer. Insert the USB connector of the Hello Kitty Water Mouse into the USB port.
3. **Driver Installation:** For most modern operating systems (Windows XP, Vista, 7, Mac OS X 10.1 or

better), the mouse is plug-and-play and will automatically install the necessary drivers. Wait a few moments for your computer to recognize the device.

4. **Test Functionality:** Move the mouse and click the left and right buttons to ensure it is working correctly.

No batteries are required for this wired mouse.

4. OPERATING THE MOUSE

The Hello Kitty Water Mouse functions like a standard 3-button optical mouse:

- **Left Button:** Used for selecting items, opening files, and executing commands.
- **Right Button:** Used to open context-sensitive menus.
- **Scroll Wheel:** Roll the wheel up or down to scroll through documents and web pages. The scroll wheel may also function as a middle button when pressed.

Ensure the mouse is used on a clean, flat surface for optimal optical sensor performance.

5. MAINTENANCE

To ensure the longevity and proper functioning of your Hello Kitty Water Mouse, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the mouse. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- **Optical Sensor:** Keep the optical sensor on the underside of the mouse clean and free from dust or debris. Do not attempt to open the mouse.
- **Storage:** When not in use, store the mouse in a clean, dry environment away from extreme temperatures.

6. TROUBLESHOOTING

If you encounter issues with your Hello Kitty Water Mouse, refer to the following common problems and solutions:

- **Mouse is not responding:**
 - Ensure the USB connector is securely plugged into a working USB port on your computer.
 - Try plugging the mouse into a different USB port.
 - Restart your computer.
- **Cursor movement is erratic or jumpy:**
 - Clean the optical sensor on the underside of the mouse with a soft cloth.
 - Ensure you are using the mouse on a clean, non-reflective, and uniform surface. Avoid glass or highly reflective surfaces.
- **Buttons or scroll wheel are not working:**
 - Verify the mouse is properly connected to the computer.
 - Check your computer's mouse settings to ensure buttons are configured correctly.

7. SPECIFICATIONS

Model Number	81409A
Brand	Hello Kitty
Color	Pink
Sensor Type	Optical
Connectivity	Wired USB
Operating System Compatibility	Windows XP, Vista, 7; Mac OS X 10.1 or better
Dimensions (L x W x H)	19.99 x 10.08 x 5.08 cm (approx. 7.87 x 3.97 x 2 inches)
Weight	213.19 g (approx. 0.47 lbs)
Batteries Required	No

8. WARRANTY AND SUPPORT

For information regarding warranty coverage and customer support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your proof of purchase for warranty claims.

© 2023 Hello Kitty. All rights reserved. This manual is for informational purposes only.

Related Documents - 81409A

 <p>USER MANUAL KT2052P THIS PRODUCT IS NOT A TOY! Caution: Electrical Hazard Product - Please use only when plugged into AC outlet.</p>	<p>Hello Kitty Sleeping Kitty Alarm Clock with Digital Tuning Radio - User Manual KT2052P User manual for the Hello Kitty Sleeping Kitty Alarm Clock with Digital Tuning Radio (Model KT2052P). Learn about setup, operation, safety instructions, and warranty information.</p>
 <p>OUTSIDE INSIDE</p>	<p>Hello Kitty Dancing LED Water Tower Speaker Instruction Manual Instruction manual for the Hello Kitty Dancing LED Water Tower Speaker, covering setup, controls, Bluetooth pairing, and compliance information.</p>




[Hello Kitty Kitchen & Fridge Set Assembly Instructions](#)

Detailed, step-by-step assembly guide for the Hello Kitty Kitchen & Fridge Set (Model 43621484). Includes parts list, hardware, and safety warnings for safe assembly and use.



[Hello Kitty RD WM WM1-KIT-HK1 Instruction Manual](#)

Comprehensive instruction manual for the Hello Kitty RD WM WM1-KIT-HK1, detailing setup, operation, safety, and maintenance for optimal use.



[Hello Kitty CD Boombox KT2025 User Manual](#)

User manual for the Hello Kitty CD Boombox with AM/FM Stereo Radio and Light Show Effect, model KT2025. Includes safety instructions, operation guides for CD, radio, and AUX input, care and maintenance tips, and troubleshooting.



[Hello Kitty Cake Pop Maker Instructions and Safety Information](#)

Comprehensive guide for the Hello Kitty Cake Pop Maker (CPM-KIT-HK1), including operating instructions, safety precautions, tips, and a vanilla cake pop recipe.