

Preethi Easy Grind Aura WG-901

Preethi Easy Grind Aura WG-901 Wet Grinder Instruction Manual

Model: Easy Grind Aura WG-901

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, maintenance, and care of your Preethi Easy Grind Aura WG-901 Wet Grinder. Please read all instructions carefully before using the appliance for the first time and retain this manual for future reference.



Image 1.1: The Preethi Easy Grind Aura Wet Grinder. This image displays the main unit of the wet grinder, including the motor base, the stainless steel drum, and the transparent lid. The overall design is compact and suitable for kitchen countertops.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before operating the appliance.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not immerse the motor base, cord, or plug in water or other liquids.
- Always unplug the appliance from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Keep hands and utensils away from moving parts during operation to prevent injury.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact authorized service personnel for examination, repair, or adjustment.
- The appliance is equipped with a heat-sensitive cut-off feature that activates during overload or voltage fluctuation to prevent damage. If this occurs, unplug the unit, allow it to cool, and then restart.
- This appliance is for household use only. Do not use outdoors.
- Close supervision is necessary when any appliance is used by or near children.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Always ensure the lid is properly secured before starting the grinder.

3. PRODUCT OVERVIEW AND COMPONENTS

The Preethi Easy Grind Aura WG-901 Wet Grinder comes with several components designed for various kitchen tasks:

- **Main Unit:** Houses the motor and control panel. Features a shock-resistant ABS body.
- **Stainless Steel Drum:** The primary container for grinding. It features a tilt and pour handle for convenience.
- **Grinding Stones:** Cylindrical grooved stones for efficient grinding.
- **Transparent Polycarbonate Lid:** Allows viewing of contents during operation.
- **Atta Kneader Attachment:** Designed with chamfered blades for kneading dough.
- **Coconut Scraper Attachment:** Used for scraping coconut. Includes a plate and cap.
- **Batter Remover:** Tool for easily removing ground batter from the drum and stones.
- **Spatula:** General purpose tool for handling ingredients.
- **Polymer Wheels:** Sturdy wheels for easy movement of the unit.

4. SETUP AND FIRST USE

Before using your wet grinder for the first time, follow these steps:

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.

2. **Clean:** Wash the stainless steel drum, grinding stones, lid, atta kneader, coconut scraper, batter remover, and spatula with mild soap and water. Rinse thoroughly and dry completely.
3. **Placement:** Place the main unit on a stable, flat, and dry surface, away from heat sources and direct sunlight. Ensure adequate ventilation around the unit.
4. **Assemble Drum:** Place the clean stainless steel drum securely onto the motor base. Ensure it is properly seated.
5. **Insert Grinding Stones:** Carefully place the grinding stones into the drum, ensuring they are centered on the rotating shaft.
6. **Power Connection:** Ensure the power switch is in the "OFF" position before plugging the grinder into a 230V AC power outlet.

5. OPERATING INSTRUCTIONS

5.1. Grinding Pulses and Grains

1. Ensure the drum and grinding stones are clean and properly assembled on the motor base.
2. Add pre-soaked and drained pulses or grains into the drum. Do not overload the drum beyond its recommended capacity.
3. Pour a small amount of water into the drum. The amount of water will vary depending on the consistency desired.
4. Place the transparent lid securely on the drum.
5. Switch on the grinder. The stones will begin to rotate, grinding the ingredients.
6. Periodically check the consistency. Add more water gradually through the lid opening if needed.
7. Grind until the desired smooth consistency is achieved. The AEM lock pressure and cylindrical grooved stones ensure efficient grinding.
8. Once grinding is complete, switch off the grinder and unplug it from the power outlet.
9. Use the batter remover and spatula to carefully remove the ground batter from the drum and stones.

5.2. Using the Atta Kneader

1. Remove the grinding stones from the drum.
2. Attach the atta kneader attachment onto the central shaft inside the drum. Ensure it is securely fitted.
3. Add flour and water (and oil, if desired) into the drum according to your recipe.
4. Place the transparent lid securely on the drum.
5. Switch on the grinder. The chamfered blades of the atta kneader will begin to mix and knead the dough.
6. Allow the machine to knead until the dough reaches the desired consistency. This typically takes a few minutes.
7. Switch off the grinder and unplug it.
8. Carefully remove the kneaded dough.

5.3. Using the Coconut Scraper

1. Remove the grinding stones from the drum.
2. Attach the coconut scraper attachment onto the central shaft inside the drum. Ensure it is securely fitted.

3. Place the coconut half (cut side facing the scraper) firmly against the rotating scraper blade.
4. Switch on the grinder. The scraper will remove the coconut flesh.
5. Continue scraping until all desired coconut flesh is removed.
6. Switch off the grinder and unplug it.
7. Collect the scraped coconut from the drum.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your wet grinder.

1. **Always Unplug:** Before cleaning, always ensure the grinder is switched off and unplugged from the power outlet.
2. **Drum and Stones:** Immediately after use, remove the drum and grinding stones. Rinse them thoroughly under running water to remove all food residue. Use a soft brush or sponge with mild dish soap if necessary.
3. **Attachments:** Wash the atta kneader, coconut scraper, batter remover, and spatula in warm soapy water, rinse, and dry.
4. **Main Unit:** Wipe the exterior of the motor base with a damp cloth. Do not use abrasive cleaners or scourers. **Never immerse the motor base in water or any other liquid.**
5. **Drying:** Ensure all parts are completely dry before reassembling or storing.
6. **Storage:** Store the grinder and its accessories in a clean, dry place, away from direct sunlight and moisture.

7. TROUBLESHOOTING

Refer to the table below for common issues and their potential solutions:

Problem	Possible Cause	Solution
Grinder does not start.	Not plugged in.	Ensure plug is firmly in the outlet.
	Power switch is off.	Turn the power switch to "ON".
	Power outage.	Check household circuit breaker.
	Overload protection activated.	Unplug, wait 15-20 minutes for motor to cool, then restart. Reduce load if overloaded.
Grinding is slow or inefficient.	Insufficient water.	Add small amounts of water gradually.
	Overloaded drum.	Reduce the quantity of ingredients.
	Ingredients not pre-soaked.	Ensure ingredients are properly pre-soaked as required.
	Stones not properly seated.	Check and reseal grinding stones.

Problem	Possible Cause	Solution
Excessive noise during operation.	Stones not properly seated. Foreign object in drum. Unit not on a stable surface.	Switch off, unplug, and check stone placement. Switch off, unplug, and inspect drum for foreign objects. Ensure the grinder is on a flat, stable surface.

If the problem persists after attempting these solutions, please contact Preethi customer support.

8. SPECIFICATIONS

- **Model:** Easy Grind Aura WG-901
- **Power:** 150 Watts
- **Operating Voltage:** 230 Volts
- **Body Material:** Shock-resistant ABS
- **Drum Material:** 100% Stainless Steel
- **Item Weight:** Approximately 4.89 kg
- **Included Accessories:** Wet grinder unit, Atta kneader, Batter remover, Spatula, Coconut scraper with plate and cap.

9. WARRANTY AND CUSTOMER SUPPORT

Your Preethi Easy Grind Aura WG-901 Wet Grinder comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use.

For warranty claims, service, or any technical assistance, please contact Preethi customer support. Keep your purchase receipt as proof of purchase for warranty validation.

Please note: The warranty does not cover damage caused by misuse, negligence, unauthorized repairs, or normal wear and tear.