

[Manuals.plus](#) /

› [Preethi](#) /

› Preethi Blue Leaf Silver 600-Watt Mixer Grinder Instruction Manual

Preethi Blue Leaf Silver

Preethi Blue Leaf Silver 600-Watt Mixer Grinder Instruction Manual

Model: Blue Leaf Silver (MG-149)

1. INTRODUCTION

Thank you for choosing the Preethi Blue Leaf Silver 600-Watt Mixer Grinder. This appliance is designed for efficient and convenient grinding tasks in your kitchen. Please read this instruction manual carefully before using the appliance for the first time to ensure safe and optimal performance. Keep this manual for future reference.



Image 1.1: The Preethi Blue Leaf Silver Mixer Grinder, showcasing its compact design and silver finish.




Image 1.2: Top-down view highlighting the unique leaf-shaped design of the mixer grinder base.

2. IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before use.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Always unplug the appliance from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Keep hands and utensils away from moving blades during operation to prevent injury. Use a spatula only when the motor is off.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact authorized service personnel for examination, repair, or adjustment.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Always ensure the jar is properly locked onto the motor unit before starting. The safety lock feature prevents operation if not correctly assembled.
- Do not overload the mixer grinder. Refer to the capacity guidelines for each jar.
- Avoid grinding hot ingredients immediately after grinding cold ingredients, and vice-versa, to prevent thermal shock to the jars.

3. PRODUCT COMPONENTS

The Preethi Blue Leaf Silver Mixer Grinder comes with the following components:

- Motor Unit (Main Body)
- 1.5 Litre Stainless Steel Jar with Dome Lid
- 1.0 Litre Stainless Steel Jar with Flat Lid
- 0.4 Litre Stainless Steel Chutney Jar with Flat Lid
- Spatula (for mixing and scraping)



Image 3.1: Overview of the Preethi Blue Leaf Silver Mixer Grinder and its main components. The image highlights the Dual Fan Powerful 600W Motor, High Quality SS Tapered Jar, Strong & durable virgin ABS Body, Flexi Lid, 18000 RPM with 3 speed control & pulse, and



Image 3.2: The three stainless steel jars included: a 0.4 L chutney jar with flat lid, a 1.0 L middle jar with flat lid, and a 1.5 L big jar with dome lid.

4. SETUP AND FIRST USE

1. **Unpacking:** Carefully remove all components from the packaging. Retain the packaging for future storage or transport.
2. **Cleaning:** Before first use, wash the jars, lids, and blades with warm soapy water. Rinse thoroughly and dry completely. Wipe the motor unit with a damp cloth. Do not immerse the motor unit in water.
3. **Placement:** Place the mixer grinder on a stable, flat, and dry surface, away from heat sources and water. Ensure there is adequate ventilation around the motor unit.
4. **Power Connection:** Ensure the power switch is in the 'OFF' position (0) before plugging the appliance into a 230V AC power outlet.

5. OPERATING INSTRUCTIONS

The Preethi Blue Leaf Silver Mixer Grinder features a powerful 600-watt motor with 3-speed control and a pulse function for versatile grinding.

General Operation:

1. **Prepare Ingredients:** Cut ingredients into small pieces suitable for grinding. Do not overfill the jar beyond its maximum capacity.
2. **Assemble Jar:** Place the ingredients into the desired jar. Secure the lid firmly onto the jar.
3. **Mount Jar:** Place the assembled jar onto the motor unit. Twist gently until it locks securely into place. The safety lock feature ensures the appliance will not operate unless the jar is correctly mounted.
4. **Select Speed:** Turn the knob to the desired speed setting (1, 2, or 3). For short bursts of power, use the 'Pulse' (P) setting by holding the knob in that position and releasing it.
5. **Grinding:** Allow the mixer grinder to operate until the desired consistency is achieved. Avoid continuous operation for more than 5 minutes. Allow a 2-minute rest period between cycles to prevent motor overheating.
6. **Switch Off:** After grinding, turn the knob back to the 'OFF' position (0) and unplug the appliance from the power outlet.
7. **Remove Jar:** Carefully remove the jar from the motor unit. Open the lid and empty the contents.

Specific Grinding Tips:

- **Wet Grinding (e.g., batters, purees):** Use the 1.5 Litre or 1.0 Litre jar. Add liquids gradually if needed. Ensure the dome lid is securely in place.

- **Dry Grinding (e.g., spices, grains):** Use the 1.0 Litre or 0.4 Litre jar. Ensure ingredients are completely dry for best results. Grind in short bursts to prevent overheating and retain flavor.
- **Chutney Grinding:** Use the 0.4 Litre chutney jar. Add minimal liquid for thick chutneys.



Image 5.1: The Preethi Blue Leaf Silver Mixer Grinder with a jar attached, positioned on a kitchen counter, ready for use.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your mixer grinder.

1. **Always unplug** the appliance before cleaning.
2. **Motor Unit:** Wipe the motor unit with a soft, damp cloth. Do not use abrasive cleaners or immerse it in water.
3. **Jars and Lids:** Wash the stainless steel jars, blades, and lids with warm soapy water immediately after use. Use a brush to clean around the blades carefully. Rinse thoroughly and dry completely to prevent rust. The jars are dishwasher safe.
4. **Blades:** Handle blades with extreme care as they are sharp.
5. **Storage:** Store the mixer grinder and its accessories in a clean, dry place.

7. TROUBLESHOOTING

If you encounter any issues, refer to the following troubleshooting guide before contacting customer service.

Problem	Possible Cause	Solution
Appliance does not start.	Not plugged in. Jar not locked correctly. Overload protector tripped.	Ensure the plug is firmly inserted into the power outlet. Ensure the jar is securely locked onto the motor unit. Switch off, unplug, remove some ingredients, wait 2-3 minutes, then press the reset button (usually at the bottom of the motor unit) and restart.
Burning smell during operation.	New motor smell (normal for first few uses). Overloading. Continuous operation for too long.	This is normal and will dissipate after a few uses. Reduce the quantity of ingredients. Allow the motor to cool down. Do not operate continuously for more than 5 minutes.
Loud noise during operation.	Normal operating noise. Jar not seated properly. Loose blades or worn bushes.	Mixer grinders produce noise during operation. Ensure the jar is correctly locked onto the motor unit. If noise is excessive or unusual, contact customer service.
Leakage from jar.	Lid not properly closed. Gasket not in place or damaged. Overfilling the jar.	Ensure the lid is firmly pressed down and locked. Check if the gasket is correctly fitted and undamaged. Replace if necessary. Do not fill the jar beyond the maximum fill line.

8. SPECIFICATIONS

Brand	Preethi
Model Name	Blue Leaf Silver
Part Number	MG-149
Power	600 Watts
Operating Voltage	230 Volts
Motor Speed (at load)	10,500 RPM
Overall Speed	18,000 RPM (with 3 speed control & pulse)
Number of Speeds	3 + Pulse
Jars Included	1.5 Litre (Big Jar), 1.0 Litre (Middle Jar), 0.4 Litre (Chutney Jar)
Jar Material	100% Stainless Steel
Body Material	Shock-proof ABS Plastic
Blade Material	Stainless Steel
Controls Type	Knob Control

Special Features	Safety Lock, Flow Breakers in Jars, Oil-filled Sintered Bronze Bushes, Vacuum Grip
Product Dimensions (D x W x H)	26D x 40W x 45H Centimeters
Item Weight	2.24 kg
Country of Origin	India

9. WARRANTY AND SUPPORT

Your Preethi Blue Leaf Silver Mixer Grinder comes with a comprehensive warranty and dedicated customer support.

- **Warranty:** This product is covered by a **2-year warranty** on the product from the date of purchase. Please retain your purchase receipt for warranty claims.
- **Life-long Free Service:** Preethi offers life-long free service for this product. Terms and conditions may apply.
- **Customer Service:** For any service, repair, or warranty-related queries, please contact Preethi customer support. Refer to the contact information provided in your warranty card or visit the official Preethi website.
- **Manufacturer:** Philips Domestic Appliances India Limited, Present R Survey No 1526/1, 2, 3, Thaiyur B Village, Chengalpet Taluk, Kanchipuram District, Chennai-603103.INDIA.

For more information and support, you can visit the [Preethi Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question