Preethi Trio MG-158

Preethi Trio Mixer Grinder (MG-158)

Instruction Manual

1. Introduction

Thank you for choosing the Preethi Trio Mixer Grinder. This appliance is designed for efficient mixing and grinding of various ingredients. Please read this manual carefully before operating the unit to ensure safe and optimal performance. Keep this manual for future reference.

Image 1: Important information regarding mixer grinder operation. It highlights that operating noise levels are typically 80-90 dB, an initial burning smell may occur due to motor varnish, and 750 Watt mixer grinders are recommended for heavy-duty grinding.

Note on Noise and Smell: It is normal to experience some burning smell when operating your mixer grinder for the first time. This is due to the motor varnish heating up. This should not recur in subsequent uses. Mixer grinders operate with a powerful motor, resulting in a typical operating noise level of 80-90 dB. If noise levels seem excessively high or the burning smell persists, please contact customer service.

2. Important Safety Instructions

- Always ensure the mixer grinder is placed on a stable, flat, and dry surface.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Ensure the jar is securely locked onto the motor unit before operating.
- Never operate the appliance with an empty jar.
- Do not touch moving parts, especially the blades, when the appliance is in operation or plugged in.
- Always unplug the appliance from the power outlet before assembling, disassembling, cleaning, or when not in use.
- Keep hands and utensils out of the jar while grinding to prevent injury and damage to the appliance.
- Do not overload the mixer grinder. Refer to the capacity guidelines for each jar.
- If the motor trips due to overload, reset the overload protector located at the bottom of the product.
- This appliance is for household use only. Do not use outdoors.
- Do not use attachments not recommended by the manufacturer.
- Children should be supervised to ensure they do not play with the appliance.

3. Product Components

The Preethi Trio Mixer Grinder comes with the following components:

- **Main Motor Unit:** The base unit housing the 500W motor, control knob, and overload protector. Features a totally shock-proof ABS body.
- **1.5 Litre Big Jar:** Made of 100% stainless steel with flow breakers, suitable for wet grinding.
- **1.0 Litre Middle Jar:** Made of 100% stainless steel with flow breakers, suitable for dry grinding.
- **0.4 Litre Chutney Jar:** Made of 100% stainless steel, ideal for small quantities and chutneys.
- **Transparent Polycarbonate Domes and Lids:** For all jars, allowing visibility during operation.
- **Instructional Manual:** This document.



Image 2: The Preethi Trio Mixer Grinder main unit shown with its three accompanying stainless steel jars of varying sizes, each with a transparent lid.

4. Setup and First Use

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Cleaning:** Before first use, wash the jars, lids, and blades with warm soapy water. Rinse thoroughly and dry completely. Wipe the motor unit with a damp cloth.
3. **Placement:** Place the motor unit on a clean, dry, and stable surface, away from heat sources and water.
4. **Jar Assembly:** Ensure the blade assembly is securely fitted inside the jar. Place the ingredients into the chosen jar, ensuring not to exceed the maximum fill line.
5. **Lid Placement:** Securely place the transparent dome/lid onto the jar.
6. **Mounting Jar:** Place the assembled jar onto the motor unit, aligning the locking tabs. Twist the jar clockwise until it locks securely into place. The mixer grinder features a safety lock mechanism, preventing operation if the jar is not correctly seated.
7. **Power Connection:** Plug the PVC insulated 3-core flexicord into a 230V AC power outlet.

5. Operating Instructions

The Preethi Trio Mixer Grinder features a rotary switch with 2 speeds and an incher function.

1. **Preparation:** Follow steps 1-6 from the "Setup and First Use" section.
2. **Speed Selection:** Turn the rotary switch to the desired speed setting (1 or 2). Speed 1 is for lighter tasks, and Speed 2 is for more intensive grinding.
3. **Incher Function:** For short bursts of grinding or to dislodge ingredients, turn the switch to the 'Pulse' or 'Incher' position and release. This provides momentary operation at maximum speed.
4. **Grinding:** Allow the mixer grinder to operate until the desired consistency is achieved. Do not run continuously for more than 3-5 minutes. Allow a cooling period between cycles.
5. **Stopping Operation:** Turn the rotary switch to the 'OFF' position (0).
6. **Unplugging:** Always unplug the appliance from the power outlet after use.
7. **Removing Jar:** Twist the jar counter-clockwise to unlock and lift it from the motor unit. Carefully remove the lid and pour out the contents.



Image 3: The Preethi Trio Mixer Grinder main unit in teal and white, with one stainless steel jar and its transparent dome lid securely attached, demonstrating its operational configuration.

6. Care and Maintenance

1. **Cleaning Jars and Lids:** After each use, immediately wash the jars, lids, and blades with warm soapy water. Use a brush to clean the blades carefully. Rinse thoroughly and dry completely to prevent rust.
2. **Cleaning Motor Unit:** Wipe the motor unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
3. **Storage:** Store the mixer grinder and its accessories in a clean, dry place when not in use.
4. **Dishwasher Safety:** The jars and lids are **NOT** dishwasher safe. Hand wash only.

7. Troubleshooting

Problem	Possible Cause	Solution
Mixer grinder does not start.	Power cord not plugged in; Jar not locked correctly; Overload protector tripped.	Ensure power cord is securely plugged in. Lock the jar onto the motor unit. Press the overload protector button located at the bottom of the unit.
Burning smell during first use.	Motor varnish heating up for the first time.	This is normal for initial uses and should subside. If it persists, contact customer service.
Excessive noise during operation.	Normal operating noise (80-90 dB); Jar not seated properly; Contents too hard or overloaded.	Ensure the jar is securely locked. Reduce the quantity of ingredients. If noise is abnormal, contact customer service.
Motor stops during operation.	Overload protector tripped due to overloading or continuous use.	Turn off the unit, unplug it, and wait a few minutes. Press the overload protector button at the bottom. Reduce ingredients if overloaded, then restart.
Leakage from jar.	Lid not properly secured; Gasket not in place or damaged; Jar overloaded.	Ensure the lid is tightly closed. Check if the gasket is correctly fitted and undamaged. Do not overfill the jar.

8. Specifications

Feature	Detail
Model Number	Trio MG-158
Brand	Preethi
Wattage	500 Watts
Operating Voltage	230 Volts
Number of Jars	3 (1.5L, 1.0L, 0.4L)
Jar Material	100% Stainless Steel
Body Material	Acrylonitrile Butadiene Styrene (ABS)
Control Type	Rotary Knob Control
Number of Speeds	2 Speed + Incher
Special Features	Safety Lock, Overload Protector
Product Dimensions (D x W x H)	31D x 44W x 22H Centimeters
Item Weight	4500 Grams
Country of Origin	India

9. Warranty Information

The Preethi Trio Mixer Grinder (Model MG-158) comes with a**2-year warranty** on the product from the date of purchase. This warranty covers manufacturing defects under normal household use. Please retain your purchase receipt for

warranty claims.
For warranty service, please contact the authorized service center. The warranty does not cover damage caused by misuse, neglect, unauthorized repairs, or normal wear and tear.

10. Customer Support

For any queries, service requests, or assistance with your Preethi Trio Mixer Grinder, please contact:

Manufacturer: Philips Domestic Appliances India Limited

Address: Present Survey No 1526 / 1,2,3, Thaiyur Village, Chengalpet Taluk, Kanchipuram District, Chennai - 603104 India

Please visit the official Preethi website or refer to your purchase documentation for the most current contact information and service center locations.

© 2023 Preethi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question