

System Sensor RTS151KEY

System Sensor RTS151KEY Remote Test Station User Manual

Model: RTS151KEY

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of the System Sensor RTS151KEY Remote Test Station. The RTS151KEY is designed as an accessory for duct smoke detectors, enabling remote testing and resetting capabilities.

Key Features:

- Remote Test Station functionality.
- Designed as a Duct Smoke Detector Accessory.
- Replaces the RTS451KEY model.

2. SAFETY INFORMATION

Always adhere to local and national electrical codes and regulations during installation and operation. Only qualified personnel should perform installation and maintenance. Disconnect power before servicing the device.

Important Notice: DO NOT PAINT FIRE ALARM DEVICE. Painting may impair the device's functionality and compromise fire safety.

3. SETUP AND INSTALLATION

The RTS151KEY is designed for easy installation. Ensure the mounting location is accessible and visible for testing and resetting. Refer to the specific duct smoke detector's manual for detailed wiring diagrams and compatibility.



Figure 3.1: Rear view of the RTS151KEY showing wiring terminals and product information label. The label indicates "DC ONLY" and lists power requirements for the server (green LED) and alarm (red LED).

Wiring Instructions:

Connect the RTS151KEY to the compatible duct smoke detector using appropriate wiring. The terminals on the back of the unit are clearly labeled for connection. Ensure all connections are secure and comply with electrical standards.

- **Power (Green LED):** 4-36 VDC, 12 mA MAX.
- **Alarm (Red LED):** 2.8-32 VDC, 12 mA MAX.

Consult the duct smoke detector's installation manual for specific terminal assignments and wiring configurations.

4. OPERATING INSTRUCTIONS

The RTS151KEY provides remote control and status indication for the connected duct smoke detector. The front panel features a key switch and an alarm indicator LED.



Figure 4.1: Front view of the RTS151KEY Remote Test Station. It features a key switch with OFF, RESET, and TEST positions, and an ALARM indicator LED.

Key Switch Functions:

- **OFF:** Standard operating position. The detector monitors for smoke.
- **RESET:** Used to reset the connected duct smoke detector after an alarm or test. Turn the key to this position momentarily and then release.
- **TEST:** Initiates a functional test of the connected duct smoke detector. Turn the key to this position and hold until the alarm activates, then release.

Alarm Indicator LED:

- The LED illuminates when the connected duct smoke detector is in an alarm state.

5. MAINTENANCE

The RTS151KEY requires minimal maintenance. Regular visual inspections are recommended to ensure the unit is free from damage and obstructions. Keep the surface clean using a soft, dry cloth. Do not use abrasive cleaners or solvents. Periodic functional testing of the connected duct smoke detector via the RTS151KEY should be performed according to the manufacturer's recommendations and local fire codes.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Alarm LED does not illuminate during alarm.	No power to the unit, faulty wiring, or faulty detector.	Check power supply to the duct smoke detector. Verify wiring connections between RTS151KEY and detector. Test the detector directly if possible.
Key switch does not activate test/reset.	Incorrect key operation, wiring issue, or detector malfunction.	Ensure key is fully turned to TEST/RESET position. Check wiring. Consult duct smoke detector manual for troubleshooting.
Unit appears damaged.	Physical impact or environmental factors.	Do not attempt to repair. Contact System Sensor support or a qualified technician for replacement.

7. SPECIFICATIONS

Attribute	Detail
Manufacturer	System Sensor
Part Number	RTS151KEY
Item Model Number	CECOMINOD057176
Item Weight	6.4 ounces
Product Dimensions	2.76 x 1.8 x 4.61 inches
Color	White
Finish	White
Power Source	Battery-powered (Note: This might refer to the detector it connects to, as the RTS151KEY itself is typically powered by the detector's circuit)
Item Package Quantity	1
Batteries Included?	No
Batteries Required?	No
Date First Available	April 4, 2012

Note: "Battery-powered" specification likely refers to the overall system the RTS151KEY integrates with, as the RTS151KEY itself is typically powered by the connected duct smoke detector.

8. WARRANTY AND SUPPORT

For warranty information and technical support, please contact System Sensor directly or refer to their official website. Keep your purchase receipt as proof of purchase.


System Sensor Contact Information:

- Website: www.systemsensor.com
- Customer Service: Refer to the website for regional contact details.




© 2024 System Sensor. All rights reserved.

Documents - System Sensor – RTS151KEY




[pdf] User Manual Installation Guide Instructions Specifications Dimension Guide Guide Accessories
RTS151KEY A Remote Test Station Installation Guide I56 3475 false prod edam honeywell content dam hbt en us documents manuals and guides installation |||
I56-3475-001 INSTALLATION AND MAINTENANCE INSTRUCTIONS **RTS151KEY**-A Remote Test Station 3333 Unity Drive, Missis
www.systemsensor.ca SPECIFICATIONS Dimensions: Weight: Power Requirements Power LED Green : Alarm LED Red : Alarm R
lang:en score:46 filesize: 526.44 K page_count: 2 document date: 2019-07-10



[System Sensor RTS151KEY\(A\) Remote Test Station Installation and Maintenance Instructions](#)

Installation and maintenance instructions for the System Sensor RTS151KEY(A) Remote Test Station. This document provides specification information for the product.


lang:en score:39 filesize: 935.2 K page_count: 2 document date: 2016-06-10



[\[pdf\] User Manual Instructions Specifications Dimension Guide Accessories](#)

RTS151 Remote Test Station 5 giorni fa — NOTE RTS151KEY A replaces RTS451KEY NOTICE This manual shall be left with the owner user of this equipment to dam hbt en us documents manuals and guides installation moved ss |||

I56-0758-016 INSTALLATION AND MAINTENANCE INSTRUCTIONS **RTS151KEY** A Remote Test Station SPECIFICATIONS Dimensions LED Red : Alarm Response Time: Temperature: Humidity: Listing: 4.6 H 2.75 W 1.8 D 0.24 Lbs. 14 35 VDC, 12 mA maximum 2.8 32 VDC, 12 mA ... lang:en score:39 filesize: 934.98 K page_count: 2 document date: 2016-06-10



[\[pdf\] User Manual Instructions Specifications Dimension Guide Accessories](#)


RTS151KEY A Remote Test Station 2 i56 0758 017 ©2019 system sensor 05 29 2019 figure 4 connecting a rts151key to d2 wire duct smoke detector h0612 12cdr manuals and guides installation |||

I56-0758-017 INSTALLATION AND MAINTENANCE INSTRUCTIONS **RTS151KEY** -A Remote Test Station SPECIFICATIONS Dimensions LED Red : Alarm Response Time: Temperature: Humidity: Listing: 4.6 H 2.75 W 1.8 D 11.69 cm x 4.57 cm 0.24 Lbs. 0... lang:en score:39 filesize: 586.99 K page_count: 2 document date: 2019-05-29



[\[pdf\] User Manual Instructions Specifications Dimension Guide Accessories](#)

SK Duct Addressable Photoelectric Detector Manual SKDuct isheet false prod edam honeywell content dam hbt en us documents manuals and guides installation | I56-3432-006 INSTALLATION AND MAINTENANCE INSTRUCTIONS SK-Duct Air Duct Smoke Detector 12 Clinton ... D 19.7 cm L2 RTS451/RTS151 RTS451KEY/ **RTS151KEY** STANDBY 0 mA 0 mA 12 mA ALARM 12 mA Max. 12 mA Max. 12 mA Max. 15 to 32 V lang:en score:36 filesize: 1.05 M page_count: 6 document date: 2017-06-15



[\[pdf\] User Manual Instructions Specifications Dimension Guide Accessories Catalog](#)

I56 0758 011 RTS151KEY Remote Test Station Kele D440 03 00 1 INSTALLATION AND MAINTENANCE INSTRUCTIONS 3825 Ohio Avenue St Charles Illinois 6 NOTE A test coil is required only for use D2 DNR DH400 DH500 mod els For models order part DCOIL 500 Coil GENERAL INFORMATION The System Sensor an productspecs kele Catalog 08 Gas Specialty Sensors

I56-0758-011 INSTALLATION AND MAINTENANCE INSTRUCTIONS **RTS151KEY** Remote Test Station Specifications Dimensions Alarm Response Time: Temperature: Humidity: Listing: 4.6 H 2.75 W 1.8 D 0.24 Lbs. 14 35 VDC, 12 mA maximum 2.8 32 VDC, 12 mA ... lang:en score:36 filesize: 651.65 K page_count: 2 document date: 2009-05-07



[\[pdf\] User Manual Instructions Specifications Dimension Guide](#)

I56 3104 false prod edam honeywell content dam hbt en us documents manuals and guides installation |||

I56-3104-004 INSTALLATION AND MAINTENANCE INSTRUCTIONS DNRA Duct Smoke Detector 3333 Unity Drive, ... Y CURRENT 12mA Max. RTS151 0mA 12mA Max. **RTS151KEY**-A 12mA 12mA Max. Only A models are ULC listed. 2 GENERAL DESCRIPTION lang:en score:36 filesize: 962.4 K page_count: 6 document date: 2019-04-18



[\[pdf\]](#) User Manual Instructions Specifications Dimension Guide

D4120W Duct Smoke Detector Manual I56 3046 prod edam honeywell content dam hbt en us documents manuals and guides installation moved ss |||
I56-3046-007R INSTALLATION AND MAINTENANCE INSTRUCTIONS D4120W Duct Smoke Detector 3825 Ohio Aven ... n/a 29m/
n/a 12mA Max. RTS451KEY/**RTS151KEY** 12mA n/a 12mA Max. RTS2 3mA Max. 16mA Max. 30mA Max. RTS2-AOS 3mA 16mA M:
lang:en score:35 filesize: 1.84 M page_count: 8 document date: 2016-06-12



[\[pdf\]](#) User Manual Instructions Specifications Dimension Guide Accessories

RTS2 AOS Multi Signaling Accessory Manual RTS I56 3381 prod edam honeywell content dam hbt en us documents manuals and guides user |||
I56-3381-003 INSTALLATION AND MAINTENANCE INSTRUCTIONS RTS2, RTS2-AOS, AOS Multi-Signaling Accesso ... D4S D4S
RTS151 Not Listed **RTS151KEY RTS151KEY** A APA151 RA100Z SENS-RDR Not Listed RA100Z A Not Listed Description Remote.
lang:en score:35 filesize: 1003.99 K page_count: 4 document date: 2010-01-22




[\[pdf\]](#) User Manual Instructions Specifications Dimension Guide Accessories

RTS2 AOS Multi Signaling Accessory Manual I56 3381 prod edam honeywell content dam hbt en us documents manuals and guides installation moved ss |||
I56-3381-003 INSTALLATION AND MAINTENANCE INSTRUCTIONS RTS2, RTS2-AOS, AOS Multi-Signaling Accesso ... D4S D4S
RTS151 Not Listed **RTS151KEY RTS151KEY** A APA151 RA100Z SENS-RDR Not Listed RA100Z A Not Listed Description Remote.
lang:en score:35 filesize: 1003.77 K page_count: 4 document date: 2010-01-22




[\[pdf\]](#) Instructions Specifications Dimension Guide

I56 5841 001R false prod edam honeywell content dam hbt en us documents manuals and guides installation |||
I56-5841-001R INSTALLATION AND MAINTENANCE INSTRUCTIONS D4120 Duct Smoke Detectors D4S Sensor Comp ... n/a 29r
0mA n/a 12mA Max. RTS451KEY/**RTS151KEY** 12mA n/a 12mA Max. RTS2 3mA Max. 16mA Max. 30mA Max. RTS2-AOS 3mA 16n
lang:en score:35 filesize: 1.85 M page_count: 8 document date: 2016-06-10




[\[pdf\]](#) User Manual Instructions Specifications Dimension Guide Accessories

RTS151KEY Manual I56 0758 systemsensor 80 en us Documents
I56-0758-015 INSTALLATION AND MAINTENANCE INSTRUCTIONS **RTS151KEY** A Remote Test Station 3825 Ohio Avenue, St. C
www.systemsensor.com Specifications Dimensions: Weight: Power Requirements Power LED Green : Alarm LED Red : Alarm Resp
lang:en score:34 filesize: 720.31 K page_count: 2 document date: 2011-04-11



[\[pdf\]](#) Quick Start Guide Installation Guide Specifications Guide

OSI RI SS QuickStartGuide I56 6583 prod edam honeywell content dam hbt en us documents manuals and guides reference |||
I56-6583-001 Quick Start Guide OSI-RI-SS Smoke Detection System This guide provides information o ... by using the OSP-004 tes
the **RTS151KEY** for testing the detector, the remote fault LED will blink the set sensitivity of the detec...
lang:en score:33 filesize: 1.4 M page_count: 2 document date: 2018-11-01



[\[pdf\]](#) User Manual Instructions Specifications Dimension Guide Accessories

RTS151KEY A Remote Test Station System Sensor remote alarm out aux test input trouble output reset t2 3 t3 4 2 1 optional yellow led note rts151key a can be used with instructions red For wire detectors the LED will show Consult installation information The National Fire Protection Association NOTICE This shall be left owner user of this equipment part DCOIL 500 Coil GENERAL INFORMATION an automatic fire accessory de Manual I56 0758 systemsensor en us Documents I56-0758-016 INSTALLATION AND MAINTENANCE INSTRUCTIONS **RTS151KEY** A Remote Test Station SPECIFICATIONS Dimensions LED Red : Alarm Response Time: Temperature: Humidity: Listing: 4.6 H 2.75 W 1.8 D 0.24 Lbs. 14 35 VDC, 12 mA maximum 2.8 32 lang:en score:33 filesize: 930.96 K page_count: 2 document date: 2016-06-10




[\[pdf\]](#) User Manual Instructions Specifications Dimension Guide

DNRECL Eclipse Duct Smoke Detector System Sensor INSTALLATION AND MAINTENANCE INSTRUCTIONS 3825 Ohio Avenue St Charles Illinois 60174 1 800 I56-3496-006R INSTALLATION AND MAINTENANCE INSTRUCTIONS DNRECL Eclipse Duct Smoke Detector 3825 O ... ACCESS RTS451/RTS151 0mA 12mA Max. RTS451KEY/RTS151KEY 12mA 12mA Max. 2 GENERAL DESCRIPTION Smoke introduced into lang:en score:32 filesize: 894.47 K page_count: 6 document date: 2017-05-26



[Fire-Lite BEAM1224\(A\) and BEAM1224S\(A\) Conventional Beam Smoke Detectors](#)

Technical data sheet for Fire-Lite BEAM1224(A) and BEAM1224S(A) conventional beam smoke detectors. Details features, specifications lang:en score:32 filesize: 725.95 K page_count: 2 document date: 2022-02-20



[\[pdf\]](#) User Manual Installation Guide Specifications Guide Warranty Label

OSI RI SS Installation Guide mmu Single endedReflected TypeProjectedImaging BeamSmokeDetector Intelligent InstallationGuide October2018 DocumentNo E56 OSI-RI-SS Single-ended Reflected Type Projected Imaging Beam Smoke Detector Intelligent Installation ... n 9 4 Special Applications 5.3 **RTS151KEY** Test Function 13 6 Package Contents 15 7 Detector Placement 17 7.1 Example for spa... lang:en score:31 filesize: 1.38 M page_count: 48 document date: 2018-11-30



[\[pdf\]](#) Instructions Specifications Label

Click here to Mircom CAT 5176 D2 Innovairflex 2 Wire Photoelectric Duct Detector English Fire Alarm Resources Free fire alarm manuals documents installation in ||| INNOVAIRFLEX 2-WIRE PHOTOELECTRIC DUCT DETECTOR D2 Description The InnovairFlex D2 2-wire photoelectric ... rly installed testing using the **RTS151KEY** A remote test station. Terminal connections shall be of the strip and clamp method suitable... lang:en score:31 filesize: 1.52 M page_count: 2 document date: 2022-04-20



[\[pdf\]](#) Installation Guide Instructions Specifications

untitled Click here to Notifier BEAM1224 A and BEAM1224S Conventional Beam Smoke Detectors Fire Alarm Resources Free fire alarm manuals documents installation 23733 ||| BEAM1224 A and BEAM1224S A Conventional Beam Smoke Detectors General The System Sensor BEAM1224 an ... eature of a filter the RTS151 or **RTS151KEY** remote test station moves the filter into the pathway of the light beam, testing the detector... lang:en score:31 filesize: 709.12 K page_count: 2 document date: 2022-02-15



[\[pdf\]](#) Installation Guide Instructions Specifications Guide

OSI RE SS Installation Guide Eman Ali E56 6654 000 System Sensor systemsensoreurope 2020 12 |||

E56-6654-000 INSTALLATION AND MAINTENANCE INSTRUCTIONS OSI-RE-SS Smoke Detection System Pittway T ... 5mA max
resistor Remote annunciator **RTS151KEY/RTS151KIT** VOLTAGE 10.2 to 32 VDC CURRENT - min 9 mA - max 11 mA Environment:
lang:en score:31 filesize: 2.12 M page_count: 16 document date: 2020-12-03



[\[pdf\]](#) User Manual Instructions Specifications Dimension Guide Accessories Label

thealarmtech manuals System Sensor DUCT D2 Duct Condition Evaluation 92708 Manual |||

I56-3050-004R INSTALLATION AND MAINTENANCE INSTRUCTIONS D2 Duct Smoke Detector 3825 Ohio Avenue, ... I Current Re
RTS451/RTS151 RTS451KEY/**RTS151KEY** 0mA 0mA 12mA Max. 12mA Max. Average standby current 60A Max. alarm current 13
lang:en score:30 filesize: 1.22 M page_count: 6 document date: 2012-03-02



[\[pdf\]](#) User Manual Instructions Specifications Dimension Guide

D4120 Duct Smoke Detector D4P120 Power Board Component and D4S Sensor 2022 08 25 — TABLE OF CONTENTS PAGE 1 Limitations of Detectors 2 Explod
us documents manuals guides installation moved ss |||

I56-2967-008R INSTALLATION AND MAINTENANCE INSTRUCTIONS D4120 Duct Smoke Detector D4S Sensor Compo ... n/a 29r
0mA n/a 12mA Max. RTS451KEY/**RTS151KEY** 12mA n/a 12mA Max. RTS2 3mA Max. 16mA Max. 30mA Max. RTS2-AOS 3mA 16n
lang:en score:30 filesize: 1.84 M page_count: 8 document date: 2016-06-10



[\[pdf\]](#) User Manual Instructions Specifications Dimension Guide

D4120W Duct Smoke Detector Manual 10 mars 2022 — Disable the zone or system undergoing maintenance to prevent unwanted alarms and possible dispatch of
honeywell content dam hbt en us documents manuals guides user |||

I56-3046-007R INSTALLATION AND MAINTENANCE INSTRUCTIONS D4120W Duct Smoke Detector 3825 Ohio Aven ... n/a 29m
n/a 12mA Max. RTS451KEY/**RTS151KEY** 12mA n/a 12mA Max. RTS2 3mA Max. 16mA Max. 30mA Max. RTS2-AOS 3mA 16mA M
lang:en score:30 filesize: 1.84 M page_count: 8 document date: 2016-06-12



[\[pdf\]](#) Instructions Specifications Dimension Guide Accessories


SILENT KNIGHT SK DUCT Instructions jmacfiles s3 amazonaws |||

I56-3432-001R INSTALLATION AND MAINTENANCE INSTRUCTIONS SK-Duct Air Duct Smoke Detector 12 Clinto ... W2.5 in D 19
RTS451/RTS151 RTS451KEY/ **RTS151KEY** 0mA 0mA 12mA 12mA Max. 12mA Max. 12mA Max. 15 to 32 VDC 300A 24 VDC one
lang:en score:28 filesize: 1.01 M page_count: 6 document date: 2009-10-13



[\[pdf\]](#) Instructions Specifications

Click here to Mircom CAT 5178 D4120 Innovairflex 4 Wire Photoelectric Duct Detector English Fire Alarm Resources Free fire alarm manuals documents installatio 22543 |||
INNOVAIRFLEX 4-WIRE PHOTOELECTRIC DUCT DETECTOR D4120 Features Photoelectric, integrated low-flow ... urrent Loads
RTS151 0 mA 12 mA Max. **RTS151KEY** 12 mA 12 mA Max. Electrical Ratings Power supply voltage: Input capacitance: Reset volta
lang:en score:28 filesize: 1.12 M page_count: 2 document date: 2022-04-20




[\[pdf\]](#) User Manual Instructions Specifications Dimension Guide Accessories

RTS151KEY A Remote Test Station Instructions I56 0758 017 05 29 2019 SPECIFICATIONS Dimensions 4 6" H x 2 75" W 1 8" D Red indicates alarm For wire de
HN1XAPG QBeeEnofhpPZneYYWohDvPJ4ZYNhdt7oe7bqLISAdLGXhA2pIOOIZafxO1wXpFMQMJIIMn3oH9moYpNpSI8y7BC1hXY
AVo1n68MEYUBwPPDXEmIRK4aOSy14NxpYXoArYkNn6TTnnahPM0uq7jbZDvGK6zTVuCAJvlzlgz7HE0K0WR2Okq70snoMGTP0k9pdTNWUrtPuOToeQOdZ0
gQB |||
I56-0758-017 INSTALLATION AND MAINTENANCE INSTRUCTIONS **RTS151KEY** -A Remote Test Station SPECIFICATIONS Dim
LED Red : Alarm Response Time: Temperature: Humidity: Listing: 4.6 H 2.75 W 1.8 D 11.69 cm x 6.99 cm x 4.57 cm 0.24 Lbs. 0...
lang:en score:28 filesize: 591.27 K page_count: 2 document date: 2019-05-29



[\[pdf\]](#) User Manual Instructions Specifications Dimension Guide Accessories Label

SystemSensor D2 Manual s3 absupply net amazonaws System Sensor |||
I56-3050-004R INSTALLATION AND MAINTENANCE INSTRUCTIONS D2 Duct Smoke Detector 3825 Ohio Avenue, ... I Current R
RTS451/RTS151 RTS451KEY/**RTS151KEY** 0mA 0mA 12mA Max. 12mA Max. Average standby current 60A Max. alarm current 13
lang:en score:28 filesize: 1.23 M page_count: 6 document date: 2012-03-02



[\[pdf\]](#) Installation Guide Instructions Specifications Datasheet

IDP Beam T Data Sheet 350282 Rev E Silent Knight by Honeywell Click here to Farenhyt Reflected Smoke Detector without Test Feature Fire Alarm Resources Fr
specifications tmstvtv 1676769597 firealarmresources 21693 |||
Addressable Beam Smoke Detector IDP-Beam IDP-Beam-T The IDP-Beam and IDP-Beam-T are addressable be ... r ; local test swi
RTS151 and **RTS151KEY** test station Physical Detector: 10 H 25.4 cm x 7.5 W 19.1 cm x 3.3 D 8.4 cm Refl...
lang:en score:28 filesize: 758.21 K page_count: 2 document date: 2022-04-15



[\[pdf\]](#) Instructions Specifications Dimension Guide Label

System Sensor DUCT DS Low FLOW HVAC Literature Greenheck lowflowsmokedetectorductsd sfvrns c9bbc7b7 7 webcontent greenheck atg cms prod docs defau
INSTRUCTIONS DUCTSD Duct Smoke Detector 3825 Ohio Avenue, St. Charles, Illinois 60174 1-800-SENSOR2, FAX: 630-377-6495 www.systemsensor.com SP
I56-3974-002R INSTALLATION AND MAINTENANCE INSTRUCTIONS DUCTSD Duct Smoke Detector 3825 Ohio Aven ... Y CURF
MHR/MHW 0mA RA100Z 0mA RTS151 0mA **RTS151KEY** 12mA TROUBLE n/a n/a n/a n/a ALARM 30mA Max. 29mA Max. 12m
lang:en score:27 filesize: 1.37 M page_count: 8 document date: 2024-08-05



[pdf] Guide Flyer

Duct Detector Testing and Maintenance Flyer HVFL184 InnovairFlex™ Smoke Guide maintenance is important to any duct smoke detector application This document lists system sensor product flyers |||

InnovairFlex™ Testing and Maintenance Duct Smoke Detector Testing and Maintenance Guide Testing and ... he MAGNET TEST I including RTS151, **RTS151KEY**, RTS2 and RTS2-AOS. During testing the red alarm LED on the sensor and the power board sh... lang:en score:23 filesize: 190.57 K page_count: 2 document date: 2012-12-20



[pdf] User Manual Instructions Specifications Dimension Guide

DNR Manual I56 3051 systemsensor 80 en us Documents

I56-3051-012 INSTALLATION AND MAINTENANCE INSTRUCTIONS DNR Duct Smoke Detector 3825 Ohio Avenue, ... y prevent t DEVICE RA100Z RTS151 **RTS151KEY** ACCESSORY CURRENT LOADS AT 24 VDC STANDBY ALARM 0mA 12mA Max. 0mA 12 lang:en score:23 filesize: 1018 K page_count: 6 document date: 2019-02-26



[pdf]

System Sensor RTS151KEY Zdalny tester obwodów kanalowych i czujek liniowych z kluczykiem ADI Global Distribution Karta katalogowa karta pl rts151key 4963 a System Sensor **RTS151KEY** Zdalny tester obwodów kanalowych i czujek liniowych z kluczykiem q Zakres zmian napicia zasilania 14 .. Prd alarmowania 12 mA q Czas reakcji na alarm 40 s maksymalnie Zdalny tester RTS151 został zaprojektowany... lang:pl score:23 filesize: 127.48 K page_count: 1 document date: 2018-05-27



[pdf] User Manual Instructions Specifications Dimension Guide Accessories Label

D2 Manual I56 3050 systemsensor 80 en us Documents

I56-3050-008R INSTALLATION AND MAINTENANCE INSTRUCTIONS D2 Duct Smoke Detector 3825 Ohio Avenue, ... I Current Re RTS451/RTS151 RTS451KEY/**RTS151KEY** 0mA 0mA 12mA Max. 12mA Max. Average standby current 60A Max. alarm current 13 lang:en score:23 filesize: 1.32 M page_count: 6 document date: 2016-06-12



[pdf] User Manual Instructions Specifications Dimension Guide

DNRW Duct Smoke Detector System Sensor Feb 26 2019 — 2 GENERAL DESCRIPTION introduced into this air duct system will be distributed throughout the en Documents |||

I56-3371-011 INSTALLATION AND MAINTENANCE INSTRUCTIONS DNRW Duct Smoke Detector 3825 Ohio Avenue, ... y preven DEVICE RA100Z RTS151 **RTS151KEY** ACCESSORY CURRENT LOADS AT 24 VDC STANDBY ALARM 0mA 12mA Max. 0mA 12 lang:en score:23 filesize: 1018.56 K page_count: 6 document date: 2019-02-26



[pdf] Installation Guide Accessories Catalog

Fire Life Safety Products System Sensor Jun 18 2018 — Installation ease intelligence and instant inspection are the guiding principles of i3 Series photoelectric sm III
Fire Life Safety Products C ATA L O G Audible/Visible Notification Beam Smoke Detection Carbon Mo ... A100Z Remote annunciato accessory **RTS151KEY** Remote test station accessory with key 6500-MMK Heavy-duty multi-mount bracket for BEAM...
lang:en score:23 filesize: 3.73 M page_count: 20 document date: 2021-03-31




[pdf] Specifications Datasheet Accessories

Duct Detector Remote Test Accessory RTS151KEY A Data Sheet hbt fire rts151key datasheet false prod edam honeywell content dam en us documents literature
Duct Smoke Detector Accessories Expand the versatility of the InnovairFlex™ line of duct smoke detectors with System Sensor not MHW RA100Z/RA100ZA RTS151 **RTS151KEY** RTS2 AOS RTS2-AOS Piezo Annunciator Mini-Horn, Red Mini-Horn, White ...
lang:en score:23 filesize: 412.98 K page_count: 2 document date: 2013-09-30



[pdf] User Manual Instructions Specifications Dimension Guide

D4120W Manual I56 3046 systemsensor 80 en us Documents
I56-3046-007R INSTALLATION AND MAINTENANCE INSTRUCTIONS D4120W Duct Smoke Detector 3825 Ohio Aven ... n/a 29mV n/a 12mA Max. RTS451KEY/**RTS151KEY** 12mA n/a 12mA Max. RTS2 3mA Max. 16mA Max. 30mA Max. RTS2-AOS 3mA 16mA M:
lang:en score:22 filesize: 1.84 M page_count: 8 document date: 2016-06-12



[pdf] User Manual Instructions Specifications Dimension Guide Accessories

Download Anleitung RTS151KEY Honeywell Fernanzeige und Bedieneinheit Windowdrives windowdrives b cdn net media ef 72 60 III
I56-0758-015 INSTALLATION AND MAINTENANCE INSTRUCTIONS **RTS151KEY** A Remote Test Station 3825 Ohio Avenue, St. C
www.systemsensor.com Specifications Dimensions: Weight: Power Requirements Power LED Green : Alarm LED Red : Alarm Resp
lang:en score:22 filesize: 696.38 K page_count: 2 document date: 2019-05-22



[pdf] Accessories Borchure

untitled Brochure System Sensor RTS151KEY Key Remote Test and Reset Station for Duct Smoke Detector SystemSensor 00013 7 BROC images tradeservice A
Accessories Conventional and Intelligent Duct smoke detector accessories add functionality to the d ... cap for metal sampling tubes
station **RTS151KEY*** Remote test station with key lock RTS2 Multi-signaling accessory, without strobe RTS2 ...
lang:en score:22 filesize: 69.56 K page_count: 1 document date: 2019-06-12




[\[pdf\]](#) User Manual Installation Guide

Fire Lite Alarms OSI RI FL INTELLIGENT BEAM Product Manual alldataresource assets images firelite |||

OSI-RI-SS Intelligent Reflective Imaging Beam Smoke Detector This intelligent, single-ended beam sm ... arm test switch, local alarm RTS151 and **RTS151KEY** -A test stations , OSID-R test filter. On smooth ceilings, 30-60 feet between projected b...


lang:en score:22 filesize: 258.28 K page_count: 4 document date: 2020-03-29



[\[pdf\]](#) User Manual Instructions Specifications Accessories Diagram

MRI 2351RAP Advanced Protocol Intelligent Photoelectric Smoke Remote Test can be remotely tested using the RTS151 or RTS151KEY test accessories Refer tc I56-6726-000 INSTALLATION AND MAINTENANCE INSTRUCTIONS MRI-2351RAP Advanced Protocol Intelligent ... ings or cautio tested using the RTS151 or **RTS151KEY** test accessories. Refer to the DNR W manual for wiring diagrams. Maximum test response

lang:en score:22 filesize: 376.39 K page_count: 2 document date: 2020-12-16



[\[pdf\]](#) User Manual

datas ibdglobal en slides slide dnre manual instalacion 8494 |||

I56-3538-002R INSTRUCCIONES DE INSTALACION Y MANTENIMIENTO Detector de humo en conductos DNRE ESPE ... 4Vcc EQ RTS451/RTS151 0mA 12mA Mx. RTS451KEY/**RTS151KEY** 12mA 12mA Mx. 6500RTS-KEY 12mA 12mA Mx. 2 DESCRIPCIN GEN


lang:es score:22 filesize: 1.2 M page_count: 6 document date: 2012-07-12



[\[pdf\]](#) User Manual Installation Guide Instructions Specifications Dimension Guide Accessories Label

D2 Duct Smoke Detector Install Manual Apr 9 2025 — NOTICE This manual shall be left with the owner user of this equipment Alarm Solid Red The unit is in alarm edam getfileservlet id V1QvN1UIVj nuOT2H9uZdX6jorTykqAOZ6Vuckdvc61pWlQg5V0g2TQ1tZ1ya3f1eg1WZs9OyY0MVsdEzBi0rlgq0DDxJKJRC0THoaulDqkbeV 0JzUQnbGtTeoYpq6ywn1DUYwZqqq 1m SHh4RQ8eOV2s9Rqp9GzUs0gskbRmUFvs872S7 FL1EySwvU412ByYiRzVFL5E3lsmRhKM7JbPgE4kk HoYdST51rPr I56-3050-008R INSTALLATION AND MAINTENANCE INSTRUCTIONS D2 Duct Smoke Detector 3825 Ohio Avenue, ... I Current R RTS451/RTS151 RTS451KEY/**RTS151KEY** 0mA 0mA 12mA Max. 12mA Max. Average standby current 60A Max. alarm current 13

lang:en score:21 filesize: 1.32 M page_count: 6 document date: 2016-06-12



[\[pdf\]](#) Quick Start Guide Installation Guide Specifications Guide

Quick Start Guide OSI R SS and RA Smoke Detection Mounting the detector Remove detachable front rim cover To detach Imager part from backbox loosen 3 hol bottom or top QuickStartGuide I56 6572 systemsensor en us Documents |||

I56-6572-001 Quick Start Guide OSI-R-SS and OSI-RA-SS Smoke Detection System This guide provides ... by using the OSP-004 t the **RTS151KEY** for testing the detector, the remote fault LED will blink the set sensitivity of the detec...

lang:en score:21 filesize: 1.22 M page_count: 2 document date: 2018-11-01