

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Motorola](#) /

> [Motorola Defy XT535 User Manual](#)

Motorola XT535

Motorola Defy XT535 User Manual

Model: XT535

INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your Motorola Defy XT535 smartphone. Please read this manual thoroughly before operating your device to ensure proper functionality and to prevent damage.

SETUP

Package Contents

Verify that your package contains the following items:

- Motorola Defy XT535 Phone
- Charger
- User Manual (this document)

Identifying Phone Components

Familiarize yourself with the key components of your Motorola Defy XT535.



Image: Motorola Defy XT535 showing front, side, and back views. This image helps identify the location of the display, buttons, ports, and camera.

- **Front:** 3.7-inch touchscreen display, front camera, earpiece.
- **Right Side:** Volume buttons, power/lock button.
- **Left Side:** Micro USB port.
- **Top:** 3.5mm headphone jack.
- **Back:** 5MP camera, LED flash, speaker, battery cover.

Installing the SIM Card and Battery

1. Ensure the phone is powered off.
2. Remove the back cover by gently prying it from the notch located at the bottom or side of the phone.
3. If the battery is already installed, remove it by lifting it from the bottom edge.
4. Insert the SIM card into the SIM card slot with the gold contacts facing down and the cut corner aligned correctly. Push until it clicks into place.
5. Insert the microSD card (optional) into its designated slot, ensuring proper orientation.
6. Insert the battery, aligning the gold contacts on the battery with the contacts in the phone. Press down gently until it is secure.
7. Replace the back cover, pressing firmly around the edges until it snaps into place.

Charging the Battery

Before first use, fully charge the phone's battery.

1. Connect the charger to the micro USB port on the phone.
2. Plug the charger into a power outlet.
3. The charging indicator will appear on the screen.
4. Once fully charged, disconnect the charger.

Powering On and Off

- **To Power On:** Press and hold the Power button until the Motorola logo appears.
- **To Power Off:** Press and hold the Power button until the phone options menu appears. Select "Power off" and confirm.

OPERATING INSTRUCTIONS

Basic Navigation

Your Motorola Defy XT535 features a capacitive touchscreen for interaction.

- **Tap:** Touch the screen once to open applications, select items, or press buttons.
- **Touch & Hold:** Touch and hold an item to access context-sensitive menus or move items.
- **Swipe:** Drag your finger across the screen to scroll through lists or switch between home screen panels.
- **Pinch:** Use two fingers to zoom in or out on web pages, photos, and maps.





MOTOROLA

3G 08:30

北京

26°C

08:30



智件园



浏览器



摩方园



日历





Image: Front view of the Motorola Defy XT535 displaying the home screen with various icons and widgets. This illustrates the primary user interface.

Making and Receiving Calls

- **To Make a Call:** Tap the Phone icon, enter the number using the dial pad, and tap the Call button.
- **To Answer a Call:** When the phone rings, swipe the green phone icon to the right.
- **To Decline a Call:** Swipe the red phone icon to the left.

Sending and Receiving Messages

- **To Send a Message:** Tap the Messaging icon, then tap "New message". Enter the recipient's number or select from contacts, type your message, and tap Send.
- **To Read a Message:** Tap the Messaging icon. Unread messages will be highlighted.

Connecting to Wi-Fi

1. Go to **Settings > Wireless & networks > Wi-Fi settings**.
2. Turn Wi-Fi on. The phone will scan for available networks.
3. Tap on the desired network. If it is secured, enter the password and tap Connect.

Using the Camera

1. Tap the Camera icon to open the camera application.
2. Frame your shot using the screen as a viewfinder.
3. Tap the Shutter button to take a photo.
4. To switch to video mode, tap the video icon. Tap the Record button to start/stop recording.

MAINTENANCE

Cleaning Your Device

- Use a soft, lint-free cloth to clean the screen and body of the phone.
- Avoid using abrasive cleaners, solvents, or aerosol sprays.
- Do not expose the phone to excessive moisture while cleaning.

Battery Care

- Avoid extreme temperatures, as they can affect battery life.
- Do not leave the phone connected to the charger for extended periods after it is fully charged.
- If the battery is removable, ensure it is properly seated.

Software Updates

Periodically check for software updates to ensure optimal performance and security.

1. Go to **Settings > About phone > System updates**.
2. Follow the on-screen instructions to check for and install any available updates.

TROUBLESHOOTING

Common Issues and Solutions

- **Phone not turning on:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on.
- **Phone freezing or unresponsive:** Perform a soft reset by pressing and holding the Power button for about 10-15 seconds until the phone restarts. If this does not work, remove and reinsert the battery (if applicable), then power on.
- **Poor signal or no network:** Check if the SIM card is correctly inserted. Move to an area with better network coverage. Restart the phone.
- **Wi-Fi connection issues:** Ensure Wi-Fi is enabled on the phone and the router is working. Try forgetting the network and reconnecting.
- **Battery drains quickly:** Reduce screen brightness, close unused applications, turn off Wi-Fi/Bluetooth/GPS when not in use.

Factory Reset

A factory reset will erase all data from your phone's internal storage, including app data, photos, and settings. Back up important data before proceeding.

1. Go to **Settings > Privacy > Factory data reset**.
2. Tap **Reset phone**.
3. Confirm by tapping **Erase everything**.

SPECIFICATIONS

Model	Motorola Defy XT535
Operating System	Android 2.3 (Gingerbread)
Display	3.7-inch Capacitive Touchscreen
Resolution	480 x 854 pixels
Rear Camera	5 MP with LED Flash
Front Camera	Yes
Internal Storage	2 GB
Connectivity	Wi-Fi, Bluetooth, GPS, 2G Cellular (GSM)
Dimensions	Approximately 6.7 x 5.1 x 1.8 inches (Package Dimensions)
Weight	Approximately 12 ounces

WARRANTY AND SUPPORT

For detailed warranty information, please refer to the separate warranty booklet included with your product or visit the official Motorola support website. For technical assistance or further inquiries, please contact Motorola customer support.

Motorola Support: www.motorola.com/us/support

