

manuals.plus /

> **VIZIO** /

> **VIZIO XRT300 QWERTY Keyboard Remote Control User Manual**

VIZIO XRT300

VIZIO XRT300 QWERTY Keyboard Remote Control User Manual

Model: XRT300

1. INTRODUCTION

This manual provides comprehensive instructions for the VIZIO XRT300 QWERTY Keyboard Remote Control. This remote is designed to operate compatible VIZIO Smart TVs, offering both standard television control functions and a full QWERTY keyboard for efficient text input and navigation within Smart TV applications.



Image showing the front side of the VIZIO XRT300 remote control, featuring standard television control buttons.

2. COMPATIBILITY

The VIZIO XRT300 remote control is compatible with the following VIZIO Smart TV models. For optimal performance and full functionality, especially for Smart TV features and the QWERTY keyboard, ensure your television's firmware is updated to the latest version (typically versions that include YouTube and Skype applications).

- E472VL, E472VLE, E552VLE
- M420SV, M470SV, M550SV
- M420SL, M470SL, M550SL
- M370SR, M420SR, M420KD
- E551VA, E460ME
- E3D320VX, E3D420VX, E3DB420VX, E3D470VX
- M320SR, M3D421SR, M3D550SR, M3D460SR, M3D420SR
- XVT3D474SV, XVT3D650SV
- XVT323SV, XVT373SV, XVT423SV, XVT473SV, XVT553SV (*Requires latest firmware with YouTube and Skype apps*)

3. PACKAGE CONTENTS

- 1 x VIZIO XRT300 QWERTY Keyboard Remote Control

Note: AAA batteries are not included and must be purchased separately.

4. SETUP

4.1 Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open the compartment.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

4.2 Initial Use

The VIZIO XRT300 remote control does not require any programming. Once the batteries are correctly installed, it is ready for immediate use with compatible VIZIO Smart TVs.

5. OPERATING THE REMOTE

5.1 Front Side (Standard TV Controls)

The front side of the remote features standard buttons for controlling your VIZIO Smart TV:

- **Power Button:** Turns the TV on or off.
- **Volume Up/Down:** Adjusts the television's volume.
- **Channel Up/Down:** Changes television channels.
- **Input Button:** Cycles through available input sources (HDMI, AV, etc.).
- **Menu/Settings:** Accesses the TV's main menu or settings.
- **Navigation Pad (Arrow Buttons & OK):** Used to navigate menus and select options.
- **Smart TV/App Buttons:** Dedicated buttons for quick access to popular streaming services or the Smart TV home screen.

5.2 Rear Side (QWERTY Keyboard)

Flip the remote over to access the full QWERTY keyboard. This keyboard is ideal for:

- Entering text in search bars within Smart TV applications (e.g., YouTube, Netflix).
- Typing usernames and passwords for app logins.
- Navigating web browsers on your Smart TV.

The remote automatically detects which side is facing up and activates the corresponding controls.

6. IMPORTANT NOTES

- **Firmware Update:** For full functionality of Smart TV features and the QWERTY keyboard, especially with XVT models, ensure your VIZIO Smart TV has the latest firmware installed. This typically includes versions that support applications like YouTube and Skype.
- **Line of Sight:** The remote operates using infrared (IR) technology. Ensure there is a clear line of sight between the remote's IR emitter and the TV's IR receiver for reliable operation.
- **Logo Protection:** Some remotes may ship with a protective sticker (e.g., RC-015 or RC-017) over the VIZIO logo. This sticker can be removed after receipt to reveal the brand logo.

7. TROUBLESHOOTING

- **Remote not responding:**
 - Check if the batteries are inserted correctly and are not depleted. Replace with fresh AAA batteries if necessary.
 - Ensure there are no obstructions between the remote and the TV's IR sensor.
 - Verify that the remote is pointed directly at the TV.
- **QWERTY keyboard not working:**
 - Confirm your VIZIO TV is a compatible Smart TV model.
 - Ensure your TV's firmware is updated to the latest version, as mentioned in the Compatibility and Important Notes sections.
 - Some older Smart TV applications may not fully support external keyboard input.
- **Buttons feel worn or text is fading:**

Over extended periods of use, cosmetic wear on button labels may occur. This does not typically affect the remote's functionality.

8. SPECIFICATIONS

Model Number	XRT300
Power Source	2 x AAA Batteries (not included)
Dimensions (L x W x H)	Approximately 7 x 5 x 2 inches
Weight	Approximately 3.04 ounces (without batteries)
Connectivity Technology	Infrared (IR)
Color	Black

9. WARRANTY INFORMATION

This VIZIO XRT300 remote control comes with a 30-day warranty from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims.

10. SUPPORT

For any questions, concerns, or assistance with your VIZIO XRT300 remote control, please contact the seller directly. They are committed

to providing support and resolving any issues you may encounter.

