

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BAZZ](#) /

› [BAZZ Series 400 Recessed Trim Light User Manual](#)

BAZZ 401-R30

BAZZ Series 400 Recessed Trim Light User Manual

Model: 401-R30

1. INTRODUCTION

Thank you for choosing the BAZZ Series 400 Recessed Trim Light. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions thoroughly before beginning installation and retain them for future reference.



Image 1.1: BAZZ Series 400 Recessed Trim Light packaging. The packaging displays the product, model numbers (401-R30, 400-R30, 400-CFL), and highlights a 3-year warranty.

2. SAFETY INFORMATION

WARNING: To avoid electric shock, always shut off the power to the service leads at the circuit breaker or fuse box before proceeding with any connections or installation. This product must be installed in accordance with the applicable installation

code by a person familiar with the construction and operation of the product and the hazards involved.

- Ensure all electrical connections are secure and comply with local electrical codes.
- Do not exceed the maximum wattage specified for the bulb type.
- This product is designed for interior and exterior soffit applications.
- Keep children and pets away from the installation area.

3. PACKAGE CONTENTS

Please verify that all components are present before installation:

- 1 x Series 400 Recessed Trim Light (Model 401-R30)
- Mounting hardware (pre-attached housing clips)

Note: Bulb is not included.

4. SETUP AND INSTALLATION

Follow these steps carefully for proper installation:

1. **Prepare the Installation Area:** Ensure the power is OFF at the circuit breaker. The required installation hole diameter is 4 1/2 inches (11.43 cm).
2. **Electrical Connections:**
 - Connect the black (live) wire from your household wiring to the colored wire from the fixture.
 - Connect the white (neutral) wire from your household wiring to the white wire from the fixture.
 - Connect the bare copper (ground) wire from your household wiring to the bare copper wire from the fixture.
 - The use of a wire clip (not included) is recommended for securing connections.
 - Ensure all connections conform to the electrical code of your region.
3. **Install the Trim Light:**
 - Remove the decorative baffle from the fixture if present.
 - While holding the fixture with one hand, insert the three housing clips into the T-side slots of the installation hole.
 - Using the tip of a finger, push down each clip one by one along the slots until they sit firmly on the opposite surface of the ceiling.
4. **Insert Bulb:** Install a 75W BR30 max bulb or a 15W CFL bulb (not included) into the socket.




Image 4.1: Back of product packaging detailing electrical connections and installation steps with diagrams. It also specifies the 4 1/2 inch installation hole and compatible bulb types (R30 75W, CFL 15W).

5. OPERATING INSTRUCTIONS

Once installed and the bulb is inserted, the BAZZ Series 400 Recessed Trim Light operates via a standard wall switch connected to the circuit. Simply toggle the wall switch to turn the light ON or OFF.

6. MAINTENANCE

To ensure the longevity and optimal performance of your recessed trim light, follow these maintenance guidelines:

- Cleaning:** Disconnect power before cleaning. Wipe the trim with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- Bulb Replacement:** Ensure power is OFF before replacing the bulb. Allow the bulb to cool completely before touching. Replace with a bulb of the same type and wattage (75W BR30 max or 15W CFL).
- Inspection:** Periodically inspect the wiring and connections for any signs of wear or damage. If any issues are found, consult a qualified electrician.

7. TROUBLESHOOTING

If your recessed trim light is not functioning correctly, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check the circuit breaker or fuse. Ensure the wall switch is ON.
	Loose or incorrect wiring.	Turn off power at the breaker. Recheck all electrical connections.

Problem	Possible Cause	Solution
	Faulty bulb.	Replace the bulb with a new one of the correct type and wattage.
Light flickers.	Loose bulb or connection.	Ensure the bulb is screwed in tightly. Check wiring connections.
	Incorrect dimmer switch (if applicable).	Ensure the dimmer switch is compatible with the bulb type.

If the problem persists after trying these solutions, please contact customer support or a qualified electrician.

8. SPECIFICATIONS

Brand	BAZZ
Model Number	401-R30
Product Type	Recessed Trim Light
Finish	White Baffle
Number of Lights	1
Bulb Type (Max)	75W BR30 or 15W CFL (not included)
Opening Dimensions	4.50" W x 4.50" D (11.43 cm diameter)
Trim Dimensions	5.62" W x 5.62" D
Overall Dimensions	5.25" H x 5.63" W
Weight	0.52 lbs
Application	Interior and exterior soffit
ASIN	B009EU63JO
First Available	Jan. 30 2017

9. WARRANTY AND SUPPORT

The BAZZ Series 400 Recessed Trim Light comes with a **3-year warranty** from the date of purchase, covering defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

For technical support, warranty inquiries, or replacement parts, please contact BAZZ customer service. You can find contact information on the BAZZ official website or through your retailer.

Manufacturer: BAZZ INC.

797, St-Rene, Montreal, QC Canada H4C 3G9

	<p>BAZZ FLDWFW1 WiFi Water Leak Sensor - Installation and User Guide</p> <p>This document provides comprehensive instructions for the BAZZ FLDWFW1 WiFi Water Leak Sensor, including setup requirements, product configuration, technical specifications, LED indicator guide, app download and registration procedures, pairing instructions, warranty details, and FCC compliance information.</p>
	<p>BAZZ LED SLIM SLMSQ4W Recessed Light Fixture Energy Star Certified</p> <p>Discover the BAZZ LED SLIM SLMSQ4W, an energy-efficient recessed light fixture. Features include integrated LED, 750 lumens, dimmable, suitable for damp locations, and insulated ceiling rated. Available in Matte White and Brushed Chrome finishes.</p>
	<p>Hunter X-Core Residential Irrigation Controller Owner's Manual</p> <p>Comprehensive guide to the Hunter X-Core Residential Irrigation Controller, covering installation, programming, advanced features, and troubleshooting.</p>
	<p>Inogen One G4 User Manual: Portable Oxygen Concentrator Guide</p> <p>Comprehensive user manual for the Inogen One G4 portable oxygen concentrator. Learn about intended use, operation, maintenance, troubleshooting, and system specifications for safe and effective use.</p>
	<p>GARDENBEAUT R30 (R0) Holzhacker Bedienungsanleitung</p> <p>Umfassende Bedienungsanleitung für den GARDENBEAUT R30 (R0) Holzhacker. Enthält Anleitungen zur Montage, sicheren Bedienung, Wartung, Fehlerbehebung und Garantieinformationen.</p>
	<p>Robotic Vacuum Cleaner R30 User Manual and Safety Guide</p> <p>Comprehensive guide for the R30 Robotic Vacuum Cleaner, covering safety instructions, product components, installation, usage, charging, app integration, maintenance, troubleshooting, and technical specifications.</p>