Saved from manuals.plus.
Open the live page for links to other documents and user manuals.


Warner Home Video 1000379479

42 The Jackie Robinson Story Blu-ray Disc User Manual

Introduction **Setup** **Operating** **Maintenance** **Troubleshooting** **Specifications**

1. Introduction

This manual provides essential information for the proper use and care of your *42 The Jackie Robinson Story* Blu-ray Disc. This disc contains the film depicting the life story of Jackie Robinson, the first African American Major League Baseball player of the modern era, and his signing with the Brooklyn Dodgers under Branch Rickey.
The Blu-ray Disc format offers high-definition video and audio quality for an enhanced viewing experience. This package also includes an UltraViolet digital copy, subject to an expiration date.



This image displays the front cover of the Blu-ray disc. It features actor Chadwick Boseman portraying Jackie Robinson in his Brooklyn Dodgers uniform, captured in a dynamic pose during a baseball slide. The movie title '42 The Jackie Robinson Story' is clearly visible, along with the names of lead actors Chadwick Boseman and Harrison Ford.

2. Setup

2.1 Disc Handling

- Always hold the Blu-ray disc by its edges to avoid touching the playing surface.
- Keep the disc clean and free from dust, fingerprints, and scratches.
- Store the disc in its protective case when not in use.

2.2 Player Compatibility

This Blu-ray Disc requires a Blu-ray Disc player for playback. It is not compatible with standard DVD players. Ensure your player is connected to a high-definition television or display for optimal viewing quality.

2.3 TV/Display Connection

Connect your Blu-ray player to your television or display using an HDMI cable for the best video and audio performance. Refer to your Blu-ray player and television manuals for specific connection instructions.

3. Operating Instructions

3.1 Inserting the Disc

Gently insert the Blu-ray disc into your Blu-ray player with the label side facing up. The player should automatically detect the disc and begin loading the main menu.

3.2 Menu Navigation

Use your Blu-ray player's remote control to navigate the disc's main menu. Typically, arrow keys are used to highlight options, and the 'Enter' or 'OK' button is used to select.

3.3 Playback Controls

Standard playback controls (Play, Pause, Stop, Fast Forward, Rewind, Skip Chapter) are available via your remote control during movie playback.

3.4 Language and Subtitle Selection

From the main menu or during playback (using your remote's audio/subtitle button), you can select your preferred audio language (English DTS 5.1, Spanish Dolby Digital 5.1) and subtitle options (French, Spanish).

3.5 Bonus Features

This Blu-ray Disc includes bonus content. Access these features from the main menu. Bonus content includes:

- **Stepping into History:** A look at the historical context and making of the film.
- **Full-Contact Baseball:** Details on the baseball sequences and authenticity.
- **The Legacy of the Number 42:** Exploring Jackie Robinson's lasting impact.

3.6 UltraViolet Digital Copy

Your purchase includes an UltraViolet digital copy. Please note that the digital copy had an expiration date of **July 16, 2015**. Refer to the packaging for instructions on how to redeem digital copies, if applicable and within the redemption period.

4. Maintenance


4.1 Cleaning the Disc

If the disc becomes dirty, gently wipe the playing surface with a soft, lint-free cloth. Wipe from the center of the disc

outwards in a straight line. Do not use abrasive cleaners or solvents.

4.2 Storage

Store the Blu-ray disc in its original case, away from direct sunlight, extreme temperatures, and high humidity. Proper storage helps prevent damage and prolongs disc life.



This image shows the spine of the Blu-ray disc case. The spine prominently features the movie title '42 The Jackie Robinson Story' and the Blu-ray Disc logo, indicating the format of the media.

5. Troubleshooting

5.1 Disc Not Playing

- Ensure the disc is inserted correctly with the label side facing up.
- Verify that your player is a Blu-ray Disc player and not a standard DVD player.
- Check the disc for visible dirt or scratches and clean if necessary.
- Try playing another Blu-ray disc to confirm your player is functioning correctly.

5.2 Skipping or Freezing

- Clean the disc thoroughly as described in Section 4.1.
- Ensure your Blu-ray player's firmware is up to date. Consult your player's manual or manufacturer's website for update instructions.

5.3 No Audio or Video

- Check all cable connections between your Blu-ray player and your TV/audio system.
- Ensure your TV input is set to the correct HDMI port.
- Verify that the audio settings on your Blu-ray player and TV are correctly configured.

6. Specifications

Feature	Detail
Title	42 (Blu-ray+UltraViolet)
Studio	Warner Home Video
Item Model Number	1000379479
ASIN	B009NNM9TU
MPAA Rating	PG-13 (Parents Strongly Cautioned)
Run Time	2 hours and 8 minutes
Release Date	July 16, 2013
Media Format	AC-3, Blu-ray, Dolby, Dubbed, NTSC, Subtitled, Ultraviolet, Widescreen
Audio Languages	English (DTS 5.1), Spanish (Dolby Digital 5.1)
Subtitles	French, Spanish
Number of Discs	1
Product Dimensions	0.6 x 5.4 x 6.7 inches; 2.56 ounces
Digital Copy Expiration	July 16, 2015

7. Warranty and Support

For physical media such as Blu-ray discs, warranty and support are typically handled by the retailer from which the product was purchased. Please refer to the retailer's return and exchange policies for any issues related to manufacturing defects or damage upon receipt.
For content-related inquiries or technical support regarding your Blu-ray player, please consult the manufacturer of your playback device.

© 2024 Warner Home Video. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B009NNM9TU

More documents and user manuals: **https://manuals.plus/**