

Manuals.plus /

› Hama /

› Hama LED Safety Lights (2-pack) Instruction Manual

Hama 00106998

Hama LED Safety Lights (2-pack) Instruction Manual

INTRODUCTION

Thank you for choosing the Hama LED Safety Lights. This manual provides essential information for the proper setup, operation, and maintenance of your safety lights. These lights are designed to enhance your visibility in low-light conditions, making them ideal for activities such as running, cycling, or walking, and for increasing the safety of children and pets.

Please read these instructions carefully before using the product and keep them for future reference.

SETUP

1. Unpacking and Contents

Carefully remove all components from the packaging. Verify that all items are present:

- 2 x Hama LED Safety Lights
- 4 x CR2032 Button Cell Batteries (pre-installed or separate)
- 1 x Small Screwdriver

2. Battery Installation / Replacement

The safety lights operate on CR2032 button cell batteries. If the lights are dim or do not turn on, the batteries may need to be installed or replaced.

1. Locate the small screw on the back of the light unit.
2. Use the provided screwdriver to carefully loosen the screw and open the battery compartment.
3. Insert two CR2032 batteries into each light unit, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment and tighten the screw securely. Do not overtighten.



Image: Hama LED Safety Light with its clip open, revealing the internal battery compartment where two CR2032 batteries are inserted.

3. Attaching the Safety Light

The Hama LED Safety Lights feature a robust clip for easy attachment to various items.

- Identify a suitable attachment point such as clothing (shirt, jacket), a belt, a backpack strap, or a pet collar.
- Open the clip by pressing the top and bottom parts together.
- Securely attach the light to your chosen item, ensuring it is firmly gripped by the clip and faces the desired direction for maximum visibility.



Image: A backpack with two Hama LED Safety Lights clipped onto its straps, demonstrating a typical attachment method for enhanced visibility.

OPERATING THE SAFETY LIGHT

Each Hama LED Safety Light has a single button for controlling its functions.

1. **Power On:** Press the button once to turn the light on. It will typically start in the constant light mode.
2. **Change Modes:** Press the button repeatedly to cycle through the available light modes:
 - **Constant Light:** Provides a steady illumination.
 - **Fast Flashing:** Rapid blinking for increased attention.
 - **Slow Flashing:** Slower blinking pattern.
3. **Power Off:** After cycling through all modes, pressing the button one more time will turn the light off.



Image: Two Hama LED Safety Lights shown illuminated with a red glow, demonstrating their operational state. For optimal visibility, position the lights where they are clearly visible to others, especially from the rear or front depending on your activity.



Image: A person running outdoors during sunset, wearing a Hama LED Safety Light clipped to their shorts, illustrating practical use for visibility.

MAINTENANCE

Battery Replacement

When the light becomes dim or stops working, it is time to replace the batteries. Refer to the "Battery Installation / Replacement" section under Setup for detailed instructions. Always use two fresh CR2032 button cell batteries for each light.

Cleaning

To clean the safety lights, wipe them with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the plastic housing or electronic components. Ensure the lights are completely dry before storage or next use.

Storage

Store the safety lights in a cool, dry place when not in use. If storing for an extended period, it is recommended to remove the batteries to prevent leakage and potential damage to the device.

TROUBLESHOOTING

- **Light does not turn on:**

- Check if the batteries are correctly installed with the proper polarity (+/-).
- Replace the batteries with new CR2032 button cells.

- **Light is dim:**

- The batteries are likely low. Replace them with new CR2032 button cells.

SPECIFICATIONS

Model Number	00106998
Brand	Hama
Color	Red
Material	Plastic
Power Source	Battery Powered (2 x CR2032 per light)
Water Resistance Level	Not Waterproof (IP20)
Product Weight	18 Grams (per light)
Mounting Type	Clip-on
Product Dimensions (L x W x H)	5.5 x 2.8 x 1.8 cm
Number of Light Settings	3 (Constant, Fast Flashing, Slow Flashing)
Included Components	2 clip lights, 4 CR2032 button cells, 1 screwdriver

WARRANTY

Specific warranty terms and conditions for the Hama LED Safety Lights may vary by region and retailer. Please refer to the warranty information provided with your purchase documentation or visit the official Hama website for details regarding your product's warranty coverage.

SUPPORT

For further assistance, technical support, or to inquire about replacement parts, please visit the official Hama website or contact Hama customer service directly. You can find more information at Hama's Amazon Store or their global website.