Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bajaj RCX 3

Bajaj Majesty New RCX 3 Multifunction Rice Cooker

MODEL: RCX 3 (680012)

1. Introduction

Thank you for choosing the Bajaj Majesty New RCX 3 Multifunction Rice Cooker. This appliance is designed to simplify your cooking experience, providing perfectly cooked rice with minimal effort. Please read this manual carefully before using the appliance to ensure safe and efficient operation.



Image: Bajaj Majesty New RCX 3 Rice Cooker, showcasing its design and a bowl of cooked rice.

2. Product Components

Your Bajaj Majesty New RCX 3 Rice Cooker comes with the following components:

- Rice Cooker Main Unit
- Stainless Steel Lid
- Aluminium Cooking Bowl
- Measuring Cup
- Aluminium Trivet
- Spatula



Image: The rice cooker displayed with its various accessories: an aluminum cooking bowl, a measuring cup, an aluminum trivet, a spatula, and a stainless steel lid.

3. Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the inner cooking bowl, stainless steel lid, measuring cup, and spatula with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the rice cooker on a stable, flat, heat-resistant surface, away from direct sunlight and heat sources. Ensure there is adequate ventilation around the unit.
4. **Power Connection:** Ensure the power cord is securely plugged into a grounded electrical outlet (230 volts).

4. Operating Instructions

Follow these steps for cooking rice:

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of rice. (Maximum raw rice capacity: 0.9 liters).
2. **Wash Rice:** Rinse the rice thoroughly under cold water until the water runs clear.
3. **Add Water:** Place the washed rice into the aluminum cooking bowl. Add the appropriate amount of water. A common ratio is 1 cup of rice to 1.5-2 cups of water, but this may vary based on rice type and desired consistency.
4. **Place Bowl:** Ensure the exterior of the cooking bowl is dry, then place it into the main unit of the rice cooker. Rotate it slightly to ensure proper contact with the heating element.
5. **Close Lid:** Place the stainless steel lid securely on the rice cooker.
6. **Start Cooking:** Plug in the rice cooker. Press the 'COOK' switch down. The 'COOK' indicator light will illuminate.
7. **Automatic Cooking:** The rice cooker will automatically switch to 'KEEP WARM' mode once the rice is cooked. The 'WARM' indicator light will illuminate, and the 'COOK' light will turn off.
8. **Serve:** Allow the rice to rest in 'KEEP WARM' mode for 10-15 minutes after cooking for best results. Use the provided spatula to fluff and serve the rice.

Your browser does not support the video tag.

Video: A detailed demonstration of the Bajaj Majesty New RCX 3 Rice Cooker in operation, including adding ingredients and cooking process.

5. Cleaning and Maintenance

Regular cleaning ensures the longevity and optimal performance of your rice cooker.

1. **Unplug:** Always unplug the rice cooker from the power outlet and allow it to cool completely before cleaning.
2. **Inner Pot and Accessories:** Wash the aluminum cooking bowl, stainless steel lid, measuring cup, and spatula with warm, soapy water. These parts are not dishwasher safe; hand wash only. Rinse thoroughly and dry completely.
3. **Exterior:** Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners or scouring pads. Never immerse the main unit in water or any other liquid.
4. **Storage:** Store the rice cooker in a dry place when not in use.

6. Troubleshooting

If you encounter any issues, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Rice is undercooked or hard.	Insufficient water; cooking cycle interrupted.	Add a small amount of hot water and restart the cooking cycle. Ensure the lid is properly closed.
Rice is mushy or sticky.	Too much water; rice not rinsed properly.	Reduce water quantity for future cooking. Rinse rice thoroughly before cooking.
Cooker does not turn on.	Power cord not plugged in; power outage; thermal fuse tripped.	Check power connection. Verify power supply. If the thermal fuse has tripped due to overheating, allow the unit to cool completely before attempting to use it again. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Rice burns at the bottom.	Insufficient water; cooking for too long.	Ensure correct water-to-rice ratio. The automatic shut-off should prevent burning; if it fails, contact customer support.

If the problem persists after trying these solutions, please contact customer support.

7. Specifications

Feature	Detail
Brand	Bajaj
Model Name	RCX 3 (680012)
Total Volume Capacity	1.5 Litres
Raw Rice Capacity	0.9 Litres
Power	350 Watts
Operating Voltage	230 Volts
Product Dimensions	26D x 26W x 18H Centimeters
Material	Stainless Steel (Lid), Aluminium (Cooking Bowl)
Special Feature	Automatic Cooking, Keep Warm Function, Thermal Fuse

8. Warranty and Support

Your Bajaj Majesty New RCX 3 Multifunction Rice Cooker comes with a**2-year warranty on the product** from the date of purchase. Please retain your purchase receipt for warranty claims.

For any service-related queries or support, please contact Bajaj customer care:

- **Customer Care Number:** 022 - 4138 0000
- **WhatsApp Number:** +91 70399 20000
- **Email:** customercare@bajajelectricals.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B009P2KWG6

More documents and user manuals: **https://manuals.plus/**