Bajaj Twister 410025

Bajaj Twister 750-Watt Mixer Grinder Instruction Manual

Model: Twister 410025 | Brand: Bajaj

1. Introduction

Thank you for choosing the Bajaj Twister 750-Watt Mixer Grinder. This appliance is designed for efficient and convenient food preparation, featuring a powerful 750-watt motor and a versatile multi-functional blade system. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new mixer grinder. Please read it thoroughly before first use and retain it for future reference.

2. Important Safety Instructions

- Always ensure the mixer grinder is placed on a stable, flat, and dry surface before operation.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Ensure all jars are securely locked onto the motor unit and lids are properly fastened before switching on the appliance. The safety lock feature prevents operation if not assembled correctly.
- Keep hands and utensils away from moving blades during operation to prevent injury. Always switch off and unplug the appliance before cleaning or attempting to remove contents from the jar.
- Unplug the mixer grinder from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate the appliance with a damaged cord or plug, or if it has been dropped or damaged in any manner. Contact the Brand Service Centre for repair.
- A slight burning smell may occur during the first few uses due to the motor varnish heating. This is normal and should dissipate with subsequent uses. If the smell persists or is accompanied by smoke, discontinue use and contact the service center.
- The powerful motor may produce some noise during operation. If the noise level seems abnormal or excessive, please contact the Brand Service Centre.
- This appliance is not dishwasher safe. Refer to the cleaning instructions for proper care.

3. Product Components

Your Bajaj Twister Mixer Grinder comes with the main motor unit and three stainless steel jars, each designed for specific tasks.



Image: Bajaj Twister Mixer Grinder main unit with 1.5 Litre liquidizing jar, 1 Litre dry/wet grinding jar, and 0.3 Litre chutney jar.

3.1. 1.5 Litre Liquidizing Jar



Image: The 1.5 Litre stainless steel liquidizing jar with a transparent dome lid, suitable for blending and liquidizing tasks.

This large jar is ideal for preparing juices, smoothies, batters, and other liquid-based preparations. It features a durable stainless steel body and a transparent dome lid for easy viewing of contents.

3.2. 1 Litre Dry/Wet Grinding Jar



Image: The 1 Litre stainless steel dry/wet grinding jar with a white lid, designed for grinding spices, lentils, and other ingredients.

Use this medium-sized jar for both dry grinding tasks like spices, coffee beans, and grains, as well as wet grinding for pastes and purees.

3.3. 0.3 Litre Chutney Jar



Image: The compact 0.3 Litre stainless steel chutney jar with a white lid, perfect for small quantities.

This small jar is specifically designed for grinding small quantities of ingredients, such as chutneys, dips, and spice pastes.

4. Setup

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for storage or future transport.
2. **Initial Cleaning:** Before first use, wash the jars, lids, and blades with warm soapy water. Rinse thoroughly and dry completely. Wipe the motor unit with a damp cloth.
3. **Placement:** Place the motor unit on a clean, dry, stable, and level surface, away from heat sources and water. Ensure adequate ventilation around the unit.
4. **Power Connection:** Ensure the power switch is in the 'OFF' position before plugging the appliance into a 230 Volt AC power outlet.

5. Operating Instructions

1. **Prepare Ingredients:** Cut ingredients into small pieces suitable for the jar size. Do not overload the jars beyond their maximum capacity markings.
2. **Attach Jar:** Place the desired jar onto the motor unit. Twist it clockwise until it locks securely into place. The safety lock ensures the appliance will not start if the jar is not correctly seated.
3. **Secure Lid:** Place the lid firmly on the jar and ensure it is properly fastened. For the liquidizing jar, ensure the dome is fixed.
4. **Select Speed:** Turn the knob control to the desired speed setting (1, 2, or 3). Use the 'Pulse' function for short bursts of power.
5. **Operation:** Allow the mixer grinder to run for short intervals, especially for tough ingredients, to prevent overheating. Do not run continuously for more than 30 minutes. Allow a cooling period between cycles.
6. **Switch Off:** After processing, turn the knob control to the 'OFF' position and unplug the appliance from the power outlet.
7. **Remove Jar:** Twist the jar counter-clockwise to unlock and lift it from the motor unit. Carefully remove the lid and pour out the contents.

6. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your mixer grinder.

- **Always Unplug:** Ensure the appliance is unplugged from the power supply before cleaning.
- **Motor Unit:** Wipe the motor unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Jars and Lids:** Wash the stainless steel jars, lids, and blades with warm soapy water immediately after use. Use a brush for thorough cleaning of blades. Rinse well and dry completely to prevent water spots and odors.
- **Blades:** Handle blades with extreme care as they are sharp.
- **Dishwasher Safety:** The jars and lids are **not** dishwasher safe. Hand wash only.
- **Storage:** Store the mixer grinder and its accessories in a clean, dry place when not in use.

7. Troubleshooting

Problem	Possible Cause	Solution
Mixer grinder does not start.	Power cord not plugged in; Jar not locked properly; Overload protector tripped.	Ensure plug is firmly in outlet; Securely lock the jar onto the motor unit; Press the reset button located at the bottom of the motor unit (if applicable) after allowing it to cool.
Burning smell during first use.	Motor varnish heating for the first time.	This is normal and should subside after a few uses. If it persists or is accompanied by smoke, contact service.
Excessive noise during operation.	Normal operation of a powerful motor; Jar not seated correctly; Damaged blades.	Some noise is expected. Ensure jar is properly locked. If noise is abnormal or very loud, contact the Brand Service Centre.
Contents leaking from jar.	Lid not properly secured; Jar overloaded; Worn gasket.	Ensure lid is firmly fastened and gasket is correctly placed. Do not overfill jars. If problem persists, contact service for gasket replacement.

8. Specifications

Feature	Detail
Model Name	Twister
Model Number	410025
Wattage	750 Watts
Voltage	230 Volts
Motor RPM	18000
Number of Jars	3
Jar Capacities	1.5 Litre (Liquidizing), 1 Litre (Dry/Wet Grinding), 0.3 Litre (Chutney)
Body Material	Acrylonitrile Butadiene Styrene (ABS)
Jar Material	Stainless Steel
Blade Material	Stainless Steel
Controls Type	Knob Control
Number of Speeds	3
Special Feature	Safety Lock
Product Dimensions (D x W x H)	18D x 13W x 20H Centimeters
Item Weight	4.83 Kilograms

9. Warranty and Support

Your Bajaj Twister Mixer Grinder is covered by a comprehensive warranty to ensure your peace of mind.

- **Product Warranty:** 2 years on the product from the date of purchase.
- **Motor Warranty:** 5 years on the motor from the date of purchase.

For any service, repair, or warranty claims, please contact the Bajaj Brand Service Centre. Ensure you have your purchase receipt and product details available when contacting support.