Bajaj ICX 6 WOV

Bajaj Majesty ICX 6 WOV 1600-Watt Induction Cooktop

User Manual

Introduction

This manual provides essential information for the safe and efficient operation of your Bajaj Majesty ICX 6 WOV 1600-Watt Induction Cooktop. Please read it thoroughly before using the appliance and keep it for future reference. This induction cooktop is designed to provide a convenient and efficient cooking experience with its advanced features and user-friendly interface.

Important Safety Instructions

To reduce the risk of fire, electric shock, injury to persons, or damage when using your appliance, follow basic safety precautions, including the following:

- Ensure the operating voltage is 230V as specified.
- Do not immerse the cooktop in water or any other liquid.
- Always place the cooktop on a stable, flat, heat-resistant surface.
- Do not touch the ceramic plate immediately after cooking, as it may still be hot.
- Use only induction-compatible cookware. The cooktop will automatically shut off if an unsuitable vessel is placed on it for more than a minute.
- Keep children away from the appliance during operation.
- Do not operate the appliance if the power cord or plug is damaged.
- Avoid blocking the ventilation openings of the cooktop.
- In case of abnormal supply voltage, wait for the power supply to normalize before switching on the unit.
- If the temperature under the pot or of the induction itself becomes too high, the unit may shut down. Allow it to cool before resuming operation.

Product Overview

Familiarize yourself with the components of your Bajaj Majesty ICX 6 WOV Induction Cooktop.



Figure 1: Overall view of the Bajaj Majesty ICX 6 WOV Induction Cooktop, showcasing its sleek black design with gold accents and the central induction coil area.



Figure 2: Detailed view of the control panel, highlighting the feather touch buttons for various functions like Pressure Cooker, Noodles, Milk/Tea, Roti/Dosa, Curry/Sabji, and the ON/OFF switch, along with the digital display.



Figure 3: The power plug for the induction cooktop, a standard three-pin plug for electrical connection.

Setup

1. **Unpacking:** Carefully remove the induction cooktop from its packaging. Retain packaging materials for future storage or transport if needed.
2. **Placement:** Place the cooktop on a flat, stable, and heat-resistant surface. Ensure there is adequate ventilation around the unit. Do not place it near heat sources or flammable materials.
3. **Power Connection:** Plug the power cord into a grounded 230V AC electrical outlet. Ensure the outlet is capable of handling 1600W power consumption.
4. **Initial Cleaning:** Before first use, wipe the ceramic surface with a soft, damp cloth. Ensure it is completely dry before plugging in.

Operating Instructions

The Bajaj Majesty ICX 6 WOV Induction Cooktop is designed for ease of use with its feather touch controls and preset menus.

1. **Power On:** Place an induction-compatible vessel containing food or liquid on the ceramic plate. Press the**ON/OFF** button to turn on the cooktop. The digital display will illuminate.
2. **Selecting a Preset Menu:** The cooktop features five preset menus for common cooking tasks:
   - Pressure Cooker
   - Noodles
   - Milk/Tea
   - Roti/Dosa
   - Curry/Sabji

   Press the corresponding feather touch button for your desired cooking mode. The cooktop will automatically adjust temperature and wattage.
3. **Manual Control:** Use the **+/-** buttons (represented by up/down arrows on the control panel) to manually adjust the heating temperature or wattage if not using a preset.
4. **Keep Warm Mode:** To keep food warm after cooking, select the **Warm Mode**. This maintains a low temperature to prevent food from cooling.
5. **Auto Shut-Off:** The cooktop is equipped with an auto shut-off feature. If no vessel is placed on the ceramic plate for more

than one minute after being turned on, or if an unsuitable vessel is detected, the cooktop will automatically power off for safety and energy saving.

6. **Power Off:** After cooking, press the **ON/OFF** button to turn off the cooktop. Unplug the appliance from the power outlet when not in use.

Care and Maintenance

Proper care and maintenance will ensure the longevity and optimal performance of your induction cooktop.

- **Cleaning the Ceramic Surface:** After the cooktop has cooled down completely, wipe the ceramic surface with a soft, damp cloth and mild detergent. For stubborn stains, use a non-abrasive ceramic cooktop cleaner. Do not use abrasive pads, scourers, or harsh chemicals.
- **Cleaning the Body:** Wipe the exterior body of the cooktop with a soft, damp cloth. Ensure no water enters the internal components.
- **Ventilation Openings:** Periodically check and clean the ventilation openings to ensure proper airflow and prevent overheating. Use a soft brush or vacuum cleaner to remove dust.
- **Storage:** When not in use for extended periods, unplug the cooktop and store it in a dry, cool place, away from direct sunlight and moisture.
- **Do Not Immerse:** Never immerse the cooktop in water or any other liquid for cleaning.

Troubleshooting

Refer to the table below for common issues and their solutions. If the problem persists, please contact customer care.

Error Code	Reason	Actionable Solution
E1	Unsuitable pot on the plate	Replace with induction suitable cookware.
E2	IGBT temperature sensor open	Please contact Bajaj customer care.
E3	Abnormal supply voltage more than 280V	Please switch on the unit after power supply is back to normal.
E4	Temperature sensor underplate open	Please switch on the unit after power supply is back to normal.
E5	Temperature under the pot is too high	Please contact Bajaj customer care.
E6	Temperature of Induction too high	Please wait for a few minutes before temperature cools down.
E0	Circuit of PCB is abnormal	Please contact Bajaj customer care.

Specifications

Feature	Detail
Brand	Bajaj
Model Number	ICX 6 WOV
Wattage	1600 Watts
Operating Voltage	230 Volts

Feature	Detail
Controls Type	Touch
Special Feature	Automatic Shut-Off
Heating Elements	6 (referring to preset functions)
Item Weight	2 kg 200 g (approx. 4.85 Pounds)
Included Components	1 (Induction Cooktop Unit)

Warranty and Support

Your Bajaj Majesty ICX 6 WOV Induction Cooktop comes with a warranty and dedicated customer support.

- **Warranty:** 1 year on product.
- **Customer Service:** For any queries, assistance, or to report issues, please contact Bajaj customer care at:**18001025963**.

© 2025 Bajaj. All rights reserved.