



[Manuals.plus](#) /

> [Vivitar](#) /

> Vivitar 35-Inch Deluxe Tripod Carrying Case Bag VIV-TC-35 Instruction Manual

Vivitar VIV-TC-35

Vivitar 35-Inch Deluxe Tripod Carrying Case Bag VIV-TC-35 Instruction Manual

INTRODUCTION

This instruction manual provides essential information for the proper use, care, and maintenance of your Vivitar 35-Inch Deluxe Tripod Carrying Case Bag, model VIV-TC-35. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

SAFETY INFORMATION

- Do not overload the carrying case beyond its intended capacity.
- Ensure all zippers are fully closed before lifting or transporting the case.
- Inspect the case and straps regularly for any signs of wear or damage. Discontinue use if significant damage is observed.
- Keep the case away from open flames or extreme heat sources.
- Store the case in a cool, dry place when not in use.

PACKAGE CONTENTS

- Vivitar 35-Inch Deluxe Tripod Carrying Case Bag (VIV-TC-35)

SETUP

The Vivitar Tripod Carrying Case is designed for immediate use. No assembly is required. You may adjust the shoulder strap for comfortable carrying.

1. **Adjusting the Shoulder Strap:** Locate the adjustable buckles on the shoulder strap. Slide the buckles to lengthen or shorten the strap to your desired carrying length. Ensure the strap is securely fastened before use.

OPERATION

Follow these steps to properly store and transport your tripod.

1. **Opening the Case:** Unzip the main zipper along the length of the bag. The top flap is designed for easy access.
2. **Inserting the Tripod:** Carefully place your folded tripod into the case. Ensure it fits within the cylindrical design for optimal protection. The case is designed to fit most tripods up to 35 inches when folded.
3. **Closing the Case:** Once the tripod is inside, securely close the main zipper. Ensure no fabric is caught in the zipper teeth.
4. **Carrying the Case:** Use the adjustable shoulder strap for hands-free transport or the web handle for quick carrying.





Figure 1: External view of the Vivitar 35-Inch Deluxe Tripod Carrying Case Bag, showing the main zipper, shoulder strap, and web handle.



Figure 2: Internal view of the Vivitar 35-Inch Deluxe Tripod Carrying Case Bag, illustrating the spacious cylindrical compartment for a tripod.

MAINTENANCE

- **Cleaning:** Wipe the exterior of the case with a damp cloth and mild soap if necessary. Do not machine wash or tumble dry. Allow to air dry completely.
- **Storage:** When not in use, store the case in a clean, dry environment away from direct sunlight to prevent material degradation.
- **Zipper Care:** Periodically check the zipper for smooth operation. If it becomes stiff, a small amount of zipper lubricant can be applied.

TROUBLESHOOTING

- **Zipper is Stiff or Stuck:** Ensure no fabric is caught in the zipper. Apply a small amount of zipper lubricant or a graphite pencil lead to the teeth to improve movement.
- **Tripod Does Not Fit:** Verify that your tripod is folded to a length of 35 inches or less. The case is designed for cylindrical tripods.

- **Strap Discomfort:** Adjust the shoulder strap length to distribute weight evenly. Ensure the padded section of the strap rests comfortably on your shoulder.

SPECIFICATIONS

Feature	Detail
Model Number	VIV-TC-35
Material	Cordura-webbed nylon
Color	Black
Product Dimensions (L x W x H)	88.9L x 11.4W x 88.9H Centimetres (35" L x 4.5" W x 4.5" H)
Item Weight	1 Pound (approximately 453.59 g)
Closure Type	Zipper
Strap Type	Shoulder
Handle Type	Web Handle
Pocket Description	Zipper Pocket

WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support, please refer to the documentation provided with your purchase or visit the official Vivitar website. Contact details for customer service can typically be found on the manufacturer's website.

