

[manuals.plus](#) /› [Pfister](#) /› **Pfister Hanover F5314HNY Kitchen Faucet Instruction Manual**

Pfister F5314HNY

Pfister Hanover F5314HNY Kitchen Faucet Instruction Manual

Model: F5314HNY | Brand: Pfister

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, maintenance, and troubleshooting of your Pfister Hanover F5314HNY Kitchen Faucet. Please read all instructions carefully before beginning installation or use to ensure proper function and to prevent damage. Keep this manual for future reference.

Safety Information: Always turn off the water supply to the faucet before attempting any installation, repair, or maintenance. Wear appropriate personal protective equipment, such as safety glasses, during installation.

2. PRODUCT OVERVIEW

The Pfister Hanover F5314HNY is a 2-handle, 4-hole kitchen faucet with a high arc spout, pull-down sprayer, and a coordinating soap dispenser, finished in Tuscan Bronze. It incorporates several key technologies for enhanced performance and ease of use.

- **AccuDock™:** Ensures a secure and tight connection for the pull-down sprayer to the faucet spout.
- **Pforever Seal™:** Advanced ceramic disc valve technology designed to prevent leaks.
- **Pfast Connect™:** Simplifies the connection to water supply lines, reducing installation time.
- **TiteSeal™:** Mounting technology that eliminates the need for plumber's putty or silicone during installation.



Figure 2.1: Overview of the Pfister Hanover F5314HNY Kitchen Faucet, highlighting AccuDock, 2 Spray Functions, Pforever Seal, and Pfast Connect features.



Figure 2.2: Cross-section diagram illustrating the Pforever Seal advanced ceramic disc valve technology, designed for leak-free performance.

3. SETUP & INSTALLATION

Before installation, ensure you have all necessary tools and components as listed in the product packaging. This faucet is designed for 3 or 4-hole countertop installations.

3.1 Tools Required (Not Included)

- Adjustable wrench
- Phillips screwdriver
- Flashlight
- Safety glasses

3.2 Installation Steps

- 1. Prepare the Sink:** Ensure the mounting surface is clean and free of debris. If replacing an old faucet, remove it and clean the area thoroughly.
- 2. Install Faucet Body:** Position the faucet body and handles into the designated holes on the sink or countertop. The TiteSeal mounting technology simplifies this step by eliminating the need for putty.
- 3. Secure Faucet:** From underneath the sink, secure the faucet body and handles using the provided mounting hardware. Tighten firmly but do not overtighten.
- 4. Connect Water Lines:** Attach the hot and cold water supply lines to the corresponding inlets on the faucet. The Pfast Connect system ensures a secure and quick connection. Ensure all connections are hand-tight, then use a wrench for a final quarter-turn.
- 5. Install Soap Dispenser:** Insert the soap dispenser head through its hole and secure it from underneath with the provided nut. Attach the soap bottle and straw.
- 6. Attach Sprayer Hose:** Connect the pull-down sprayer hose to the quick-connect fitting under the faucet. Ensure it clicks securely into place. Attach the hose weight to the sprayer hose to ensure proper retraction.
- 7. Test for Leaks:** Turn on the main water supply and check all connections for leaks. Operate the faucet and sprayer to ensure proper function.

DIMENSIONS

PfISTER



- $1\frac{3}{8}''$ - $1\frac{1}{2}''$ Max Deck Hole Openings
- 3" Max Deck Thickness

Figure 3.1: Diagram showing the components and connections for installing the Pfister Hanover F5314HNY kitchen faucet.



Pforever Seal™

An advanced ceramic disc valve technology
with a never-leak guarantee.

Figure 3.2: Illustration of TiteSeal mounting technology, which simplifies installation by eliminating the need for plumber's putty or silicone.

4. OPERATING INSTRUCTIONS

Your Pfister Hanover faucet is designed for intuitive operation.

4.1 Water Flow and Temperature

- **Hot Water:** Turn the left handle counter-clockwise to increase hot water flow.
- **Cold Water:** Turn the right handle counter-clockwise to increase cold water flow.
- **Mixing Water:** Adjust both handles to achieve the desired water temperature and flow rate.

4.2 Pull-Down Sprayer

The pull-down sprayer offers two distinct spray functions:

- **Stream Mode:** Provides a steady, aerated flow for filling pots and general washing.
- **Spray Mode:** Delivers a powerful spray for rinsing dishes and cleaning the sink.

To switch between modes, press the toggle button located on the sprayer head. The AccuDock technology ensures the sprayer head retracts smoothly and securely into the spout when not in use.



TiteSeal™

Mounting technology eliminates the need for putty or silicone and simplifies installation.

Figure 4.1: The pull-down sprayer in stream mode, ideal for filling containers.



Figure 4.2: The pull-down sprayer in spray mode, effective for rinsing produce or cleaning.

4.3 Soap Dispenser

To use the soap dispenser, simply press down on the pump head. To refill, lift the pump head from the top and pour liquid soap directly into the bottle.

5. MAINTENANCE & CARE

Proper care will ensure the longevity and appearance of your Pfister faucet.

- Cleaning:** Clean the faucet regularly with a soft, damp cloth and mild soap. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the Tuscan Bronze finish.
- Aerator Maintenance:** If water flow decreases, the aerator may be clogged. Unscrew the aerator from the tip of the sprayer head, clean any debris, and reattach.
- Leak Prevention:** The Pforever Seal ceramic disc valves are designed for long-term, leak-free performance. If a leak occurs, contact customer support.

6. TROUBLESHOOTING

Refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator or debris in water lines.	Clean the aerator. Flush water lines by turning off water, disconnecting supply lines, and briefly turning on water to clear debris.
Faucet Leaks	Loose connections or worn internal components.	Check and tighten all water supply connections. If leaking persists, contact Pfister customer service for assistance.

Problem	Possible Cause	Solution
Sprayer Does Not Retract	Hose weight improperly positioned or obstruction.	Ensure the hose weight is correctly attached and positioned. Check for any obstructions under the sink preventing hose movement.
Difficulty Switching Spray Modes	Mineral buildup in sprayer head.	Soak the sprayer head in a vinegar solution to dissolve mineral buildup.

7. SPECIFICATIONS

Detailed technical specifications for the Pfister Hanover F5314HNY Kitchen Faucet.

- **Model Number:** F5314HNY
- **Finish:** Tuscan Bronze
- **Material:** Metal (Faucet Body), Ceramic (Handle Material)
- **Mounting Type:** Deck Mount
- **Hole Count:** 3 or 4-Hole Installation
- **Number of Handles:** 2
- **Spout Design:** Gooseneck, High Arc
- **Spout Height:** 7 Inches
- **Maximum Flow Rate:** 1.8 Gallons Per Minute (GPM)
- **Item Weight:** 9.1 Pounds
- **Product Dimensions:** 3.2"D x 11"W x 26.2"H
- **Included Components:** (1) faucet, (2) handle assemblies, (2) gaskets, (2) endbodies, (2) handle adapters, (1) soap pump head, (1) soap pump shank, (1) soap pump bottle and straw, (1) hose weight, (1) endbody hose

PfISTER

AccuDock™

Ensures a tight connection
to the faucet

2 Spray Functions

Stream and Spray modes

Pforever Seal®

Ceramic disc valve

Pfast Connect™

Space-saving installation




Figure 7.1: Dimensional drawing showing key measurements of the Pfister Hanover F5314HNY faucet.

8. WARRANTY & SUPPORT

Pfister stands behind the quality of its products.

8.1 Limited Lifetime Warranty

Your Pfister Hanover F5314HNY Kitchen Faucet is backed by a Limited Lifetime Warranty. This warranty covers the finish and function of the faucet for as long as you own your home, provided it is installed and maintained according to the instructions in this manual. For full warranty details, please refer to the official Pfister warranty documentation or visit the Pfister website.




Figure 8.1: Pfister Limited Lifetime Warranty emblem, signifying long-term product assurance.

8.2 Customer Support

If you have any questions, require replacement parts, or need assistance with installation or troubleshooting, please contact Pfister customer service. Contact information can typically be found on the Pfister website or on the product packaging.

Online Resources: For additional support, FAQs, and product registration, visit the official Pfister website:

www.pfisterfaucets.com