

[Manuals.plus](#) /

> [Smeg](#) /

> Smeg Cooker Capillary Clip 895090304 Instruction Manual

Smeg 895090304

Smeg Cooker Capillary Clip Instruction Manual

Model: 895090304

1. SAFETY INFORMATION

Important: Before attempting any installation or replacement, ensure the appliance is completely disconnected from the main power supply. Failure to do so may result in electric shock, injury, or damage to the appliance.

Always wear appropriate personal protective equipment, such as gloves, when handling appliance components. If you are unsure about any step, consult a qualified appliance technician.

This clip is a small component. Keep it out of reach of children to prevent choking hazards.

2. PRODUCT OVERVIEW

The Smeg Cooker Capillary Clip (Model 895090304) is a genuine replacement part designed to secure the capillary tube of a cooker's thermostat. This clip ensures the capillary tube remains in its correct position, which is crucial for accurate temperature sensing and regulation within the oven or hob.



Image 1: Genuine Smeg Cooker Capillary Clip. This image shows the compact metal clip designed to hold a capillary tube in place within a Smeg cooker.

3. INSTALLATION

This section provides general guidance for replacing a capillary clip. Specific installation steps may vary depending on your Smeg cooker model. Refer to your cooker's service manual for detailed instructions if available.

1. **Disconnect Power:** Ensure the cooker is completely unplugged from the electrical outlet or the circuit breaker is switched off.
2. **Access Area:** Carefully access the area where the capillary tube and clip are located. This may involve removing panels or other components of the cooker.
3. **Remove Old Clip:** If replacing an existing clip, gently remove the old or damaged clip. Note its orientation and position.
4. **Position Capillary Tube:** Ensure the capillary tube is correctly positioned according to your cooker's design.
5. **Install New Clip:** Place the new Smeg Capillary Clip over the capillary tube and secure it firmly in its designated mounting point. The clip should hold the tube securely without crimping or damaging it.
6. **Reassemble:** Reassemble any panels or components that were removed.
7. **Restore Power:** Once fully reassembled, restore power to the cooker.

Note: If you are not confident in performing this installation, it is recommended to seek assistance from a qualified technician.

4. MAINTENANCE

The capillary clip itself requires no routine maintenance. Periodically inspect the clip and the capillary tube it secures for any signs of damage, corrosion, or loosening. If damage is observed, replace the clip promptly to ensure proper function of the cooker's thermostat.

5. TROUBLESHOOTING

- **Clip does not fit:** Ensure you have the correct model number (895090304) for your Smeg cooker. Verify the capillary tube diameter matches the clip's design.
- **Capillary tube is loose after installation:** Recheck that the clip is fully seated and secured to its mounting point. Ensure the tube is correctly positioned within the clip.
- **Cooker temperature issues after clip replacement:** If temperature regulation problems occur immediately after replacing the clip, ensure the capillary tube itself was not damaged during the process and is correctly routed and secured. This clip is a mechanical fastener; temperature issues are more likely related to the thermostat or capillary tube itself.

6. SPECIFICATIONS

Feature	Detail
Product Name	Genuine Smeg Cooker Capillary Clip
Brand	Smeg
Model Number	895090304
ASIN	B009WSCGEO
Form Factor	Compact
Purpose	Secures cooker thermostat capillary tube

7. WARRANTY AND SUPPORT

For warranty information regarding genuine Smeg spare parts, please refer to the documentation provided with your original Smeg appliance or contact Smeg customer support directly.

If you require further assistance with the installation or identification of this part, please visit the official Smeg website or contact their customer service department. Always provide your appliance's full model and serial number when seeking support.

Smeg Official Website: www.smeg.com

© 2023 Smeg. All rights reserved.

This manual is for informational purposes only. Smeg is not responsible for any damage or injury resulting from improper installation or use of this product.