

[Manuals.plus](#) /

› [Spin Master](#) /

› Spin Master Air Hogs Link Smart Device Controller Instruction Manual - Model 6019603

Spin Master 6019603

Spin Master Air Hogs Link Smart Device Controller Instruction Manual

Model: 6019603

INTRODUCTION

The Spin Master Air Hogs Link transforms your compatible smart device into a remote control for various Air Hogs R/C vehicles. This device allows for intuitive control through a dedicated application, offering both joystick and gyroscopic flight options. It is designed to enhance your remote-controlled flying experience by leveraging the capabilities of your smartphone or tablet.

IMPORTANT SAFETY INFORMATION

- **Recommended Age:** This product is suitable for users aged 8 years and up.
- Always operate Air Hogs R/C vehicles in open, clear spaces, away from people, animals, and obstacles.
- Ensure your smart device is securely attached to the Air Hogs Link before operation.
- Do not modify the Air Hogs Link or any associated Air Hogs R/C vehicles.
- Read the instruction manual for your specific Air Hogs R/C vehicle for additional safety guidelines.

PACKAGE CONTENTS

- 1 Air Hogs Link device



Image: The retail packaging for the Air Hogs Link, displaying the device itself, a smartphone with the control app, and an Air Hogs helicopter. The packaging highlights compatibility with Apple App Store and Google Play.

SETUP

1. **Attach the Air Hogs Link to Your Smart Device:** Securely clip the Air Hogs Link device onto your smartphone or tablet. Ensure it is firmly attached to prevent accidental detachment during use. The clip is designed to accommodate various device sizes.



Image: The Air Hogs Link device connected to a smartphone, showing the in-app control interface with various flight controls and indicators.

2. Download the Application:

- For Apple iOS devices, download the free Air Hogs application from the [Apple App Store](#).
- For Android devices, download the free Air Hogs application from [Google Play](#).

3. **Connect to Your Air Hogs R/C Vehicle:** Follow the in-app instructions to pair your Air Hogs Link with your specific Air Hogs R/C vehicle. This typically involves turning on the vehicle and the Link, then initiating the connection through the app. Ensure your R/C vehicle is within range.

OPERATING INSTRUCTIONS

1. **Launch the App:** Open the Air Hogs application on your smart device. The app will guide you through the connection process if not already connected.
2. **Select Control Mode:** The app offers different control modes. You can switch between:
 - **Joystick Control:** Use virtual joysticks displayed on your screen for precise control over throttle, direction, and rotation.
 - **Gyroscopic Control:** Tilt your smart device in the desired direction to control the flight of your Air Hogs vehicle. This mode offers an immersive flying experience.

3. **Flight Controls:** Refer to the in-app tutorial for specific controls related to your Air Hogs R/C model. Common controls include:
- Throttle (controls altitude)
 - Directional movement (forward, backward, left, right)
 - Yaw (rotation around the vertical axis)
4. **Pre-Flight Check:** Before each flight, ensure the Air Hogs Link is securely attached, the app is running, and the R/C vehicle is powered on and connected. Always check for clear flight paths.

MAINTENANCE

- **Cleaning:** Wipe the Air Hogs Link with a soft, dry cloth. Do not use harsh chemicals, solvents, or abrasive materials, as these can damage the device.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Battery Care:** If your Air Hogs Link has an internal battery, ensure it is charged regularly and stored with some charge to prolong its lifespan. Avoid overcharging or fully discharging for extended periods.

TROUBLESHOOTING

Problem	Solution
Device not connecting to R/C vehicle.	• Ensure both the Air Hogs Link and the R/C vehicle are powered on. • Verify Bluetooth or other wireless connections are enabled on your smart device. • Restart the app and try connecting again. • Check for app updates in your device's app store. • Ensure the R/C vehicle's battery is sufficiently charged.
App is unresponsive or crashes.	• Close and reopen the application. • Restart your smart device. • Ensure your device's operating system is up to date. • Clear the app's cache (Android) or reinstall the app (iOS/Android).
Poor control response.	• Ensure there are no obstructions between the Air Hogs Link and the R/C vehicle. • Check the battery levels of both the Link and the R/C vehicle. • Calibrate the gyroscopic controls within the app if applicable. • Ensure you are within the recommended operating range for your R/C vehicle.

SPECIFICATIONS

- **Model Number:** 6019603
- **Product Dimensions:** 2.76 x 6.3 x 2.91 inches
- **Item Weight:** 2 pounds
- **Manufacturer Recommended Age:** 8 years and up
- **Compatibility:** Apple iOS and Android devices
- **Manufacturer:** Spinmaster

WARRANTY INFORMATION

For detailed warranty information regarding your Air Hogs Link and associated Air Hogs R/C vehicles, please refer to the documentation included with your product or visit the official Spin Master website for the most current warranty terms and conditions.

CUSTOMER SUPPORT

For further assistance, product registration, or to explore other Air Hogs products, please visit the official Air Hogs website: www.airhogs.com. You may also find FAQs and support contact information there.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B009XRFJOS>

More documents and user manuals: <https://manuals.plus/>