

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [DISPENSE-RITE](#) /
- › [Dispense-Rite 104B Box Cone Baffle Medium Instruction Manual](#)

DISPENSE-RITE 104B

Dispense-Rite 104B Box Cone Baffle Medium Instruction Manual

Model: 104B

INTRODUCTION

This manual provides comprehensive instructions for the proper setup, operation, and maintenance of your Dispense-Rite 104B Box Cone Baffle Medium. Please read this manual thoroughly before use to ensure optimal performance and longevity of the product.

PRODUCT OVERVIEW



Figure 1: Dispense-Rite 104B Box Cone Baffle Medium

The Dispense-Rite 104B Box Cone Baffle Medium is a component designed for use within a larger dispensing system, typically for cone-shaped items. It consists of a square metal plate with four integrated flexible baffles. Each baffle features radial slits that allow it to securely hold and release individual cones as needed. This product is engineered for durability and efficient dispensing in commercial or industrial settings.

SETUP

The 104B baffle is designed for integration into existing Dispense-Rite cone dispensing units. Ensure the dispenser unit is clean and free of debris before installation.

1. **Unpack:** Carefully remove the 104B baffle from its packaging. Inspect for any signs of damage during transit.
2. **Identify Orientation:** The baffle should be installed with the flexible white baffles facing upwards, ready to receive cones.
3. **Insert into Dispenser:** Slide the 104B baffle into the designated slot within your Dispense-Rite cone dispenser. Ensure it sits flush and is securely seated. Refer to your specific dispenser model's manual for precise installation steps if necessary.
4. **Test Fit:** Gently push down on the baffle to ensure it is properly installed and does not wobble.

OPERATING

Once installed, the 104B baffle facilitates the dispensing of medium-sized cones.

1. **Load Cones:** Place a stack of appropriate medium-sized cones into the dispenser unit, ensuring they rest on the baffles. The flexible slits will hold the cones in place.
2. **Dispense:** To dispense a cone, gently pull the bottom-most cone downwards. The baffle's design allows one cone to be released at a time while retaining the rest of the stack.
3. **Refill:** When the stack of cones is low, refill the dispenser as needed to maintain continuous operation.

MAINTENANCE

Regular cleaning and inspection will prolong the life of your 104B baffle.

- **Daily Cleaning:** Remove the baffle from the dispenser. Wipe down the metal plate and flexible baffles with a damp cloth and mild, food-safe detergent. Rinse thoroughly with clean water.
- **Drying:** Ensure the baffle is completely dry before re-installing it into the dispenser to prevent moisture buildup.
- **Inspection:** Periodically inspect the flexible baffles for any signs of wear, tearing, or damage. If the baffles appear worn or are not holding cones effectively, replacement may be necessary.
- **Storage:** If storing the baffle for an extended period, keep it in a clean, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cones not dispensing smoothly.	Incorrect cone size; Baffle dirty or sticky; Baffles worn.	Ensure cones are medium size as specified for 104B; Clean the baffle thoroughly; Inspect baffles for wear and replace if necessary.
Multiple cones dispense at once.	Baffles worn or damaged; Cones too small for baffle.	Inspect baffles for damage and replace if necessary; Use only medium-sized cones compatible with the 104B baffle.
Baffle does not fit into dispenser.	Incorrect baffle model; Obstruction in dispenser slot.	Verify you have the correct 104B model for your dispenser; Clear any obstructions from the dispenser slot.

SPECIFICATIONS

- **Model:** 104B
- **Manufacturer:** DISPENSE-RITE
- **Dimensions (Approximate):** 6.38 x 5.94 x 0.28 inches (L x W x H)
- **Weight (Approximate):** 3.36 ounces
- **Material:** Metal plate with flexible plastic baffles
- **Compatibility:** Designed for medium-sized cone dispensing applications.

WARRANTY INFORMATION

For warranty details regarding your Dispense-Rite 104B Box Cone Baffle Medium, please refer to the warranty

documentation provided with your original dispenser unit or contact DISPENSE-RITE customer service directly. Warranty terms typically cover manufacturing defects under normal use conditions.

CUSTOMER SUPPORT

If you require further assistance or have questions not covered in this manual, please contact DISPENSE-RITE customer support:

- **Manufacturer Website:** www.dispense-rite.com
- **General Inquiries:** Refer to the contact information on the manufacturer's official website.

When contacting support, please have your product model (104B) and any relevant purchase information ready.



© 2024 DISPENSE-RITE. All rights reserved.
This manual is subject to change without notice.